

Choose the CPACS template with return directory



Add the tool information


Integrate a Tool as a Workflow Component
Inputs and Outputs
Configure the inputs and outputs of the tool
Inputs
Outputs
Verification
Input
Data type
Handling
Constraint
CPACS initial
File
Single (consumed), Queu...
Required
Add...
Edit...
Remove
< Back
Next >
Save As ...
Save and update
Cancel



No properties are required for this tool


Integrate a Tool as a Workflow Component
Launch Settings
Currently, only one launch setting is possible
Host
Tool directory
Version
Working directory
RCE
D:\Tools\myTool
0.9
RCE temp directory
Add...
Edit...
Remove
Use a new working directory on each run
Tool Copying Behaviour
Do not copy tool
Copy tool to working directory once
Copy tool to working directory on each run
Clean up choices for working directory(ies) in workflow configuration*
Never delete working directory(ies)
Delete working directory(ies) when workflow is finished
Keep in case of failed workflow run
Delete working directory(ies) after each run of the tool
Keep in case of failed tool run
*Defines the user's choices when configuring the component
< Back
Next >
Save As ...
Save and update
Cancel



Specify the input and output CPACS names



Point to the correct python interpreter to run your tool