
## A closer look at SQNR




In general, k bits gives 
$$2^k$$
 quantization levels,

 $2^{k-1}$  levels each for positive and negative,

the quantization error is  $[-\frac{1}{2}, \frac{1}{2}]$ 
 $SQNR = 20 \log_{10} \frac{V_{max}}{V_{noise}} = 20 \log_{10} \frac{z^{k-1}}{z} = 6 \times k \ dB$ 

Here, 
$$h=4$$
  $2^{k-1}=8$   $SQNR=24dB$   
or  $k=3$   $2^{k-1}=4$   $SQNR=18dB$   
or  $k=2$   $2^{k-1}=2$   $SQNR=12dB$ 

(Signal Amplitude)
Sound Pressure Level



An Illustration of SQNR and Quantization\_Noise in Logarithmic scale (1B)

SQNR (dB) = Signal (dB) - Q\_Noise (dB)




Figure 1: Mask-to-noise ratio and signal-to-mask ratio. A qualitative view of SNR, SMR and MNR, with one dominant masker and m bits allocated to a particular critical band.

Signal Vi: Minimum of SMRi bits needed

Signal Vi: Below masking threshold, no bit needed

## **Bit Allocation in MPEG Audio Compression**

- The aim is to ensure that all quantization noise values are below the masking thresholds.
- 1. From the psychoacoustic model, calculate the *Signal-to-Mask Ratio (SMR)* in decibels (dBs) for each subband:

$$SMR = 20 \log_{10} \frac{Signal}{Minimum\_masking\_threshold}$$

- This determines the quantization, i.e. the minimum number of bits that is needed, if available. The amount of a signal above the threshold, i.e. SMR, is the amount that needs to be coded. Signals that are below the threshold do not.
- 2. Calculate *Signal-to-(quantization)-Noise Ratio (SNR)* for all signals.
  - A lookup table provides an estimate of SNR assuming a given number of quantizer levels.
- 3. *Mask-to-(quantization)-Noise Ratio (MNR)* is defined as the difference, in dB (See Figure 1).

$$MNR = SNR - SMR$$

4. Iterate until no bits left to allocate:

- Allocate bits to the subband with the lowest MNR
- Look up new estimate of SNR for the subband allocated more bits, and re-calculate MNR

## Note:

- The masking effect means we can raise the quantization noise floor around a strong sound because the noise will be masked off anyway. As indicated in Figure 1, adjusting the number of bits m allocated to a subband can move this floor up and down.
- To ensure that all the quantization noise values are inaudible, i.e., below the masking thresholds, so that all MNRs are ≥ 0, a minimum number of bits is needed. Otherwise, SNR could be too small, causing MNR to be < 0, and the quality of the compressed audio could be significantly affected.</li>
- If more bits than the minimum are allowed from the budget, allocate them anyway so as to further increase SNR. For each additional bit, we get 6 dB better SNR.