
# PWR\_SW:

Power switch pins in series with the positive battery input terminal



## M OUT:

Analog output to meter (M = +, G = -)


## R9:

Series resistance matched to meter full-scale current at +3.3volts

# SenseBit Inputs:

Unbuffered GPIO directly connected to the Trinket M0 (connect input/output signal to upper pin;

+3.3 volts and ground power available on the remaining two pins)



# CV INPUT:

-10 volt to +10 volt control voltage input to signal processing stage

