

When combine two receivers to become a 12CH receiver, you need to disable Range Check A pre-flight range check should be done before each flying session. Reflections from nearby metal fences, concrete buildings or trees can cause loss of signal both during **Failsafe** Failsafe is a useful feature which is for a preset channel output position whenever 2. 3.

FrSky Electronic Co., Ltd www.frsky-rc.com Contact us: frsky@frsky-rc.com.
Add:F-4,Building C, Zhongxiu Technology Park, No.3 Yuanxi Road, Wuxi, 214125, Jiangsu, China Technical Support: sales4tech@gmail.com