

Watch walkie-talkie manual

Please charge the product when you receive it to ensure that the product has enough power to use! If the walkie-talkie is low in power, there may be no way to call. If the walkie-talkie is not successfully called, it needs to be charged. This product must be charged using a standard 5V USB charger only. Do not use a 9V or 12V fast charger (such as Quick Charge/PD fast charging), as this results in failure to charge and may cause damage to the charging cable and battery.



This product has a built-in lithium battery, please keep away from fire and water, do not place in wet places. Do not clean directly with water, just clean the dirty area with a wet rag.

Product function description




manual x1



USB Charge x1



x2
Walkie talkie



Intercom mode: After the Walkie-talkie switch is turned on, the indicator on the watch lights up, indicating that it is in the intercom state. If there is no need to talk, please turn off the Walkie-talkie switch. You can save watch power.

Steps to use the intercom function: 1. Push up the two Walkie-talkie switches to turn on
2. Press and hold the PPT button 1 to speak

Note: 1. When one walkie talkie presses and speaks, the other one cannot press the PPT key, otherwise the other one cannot be heard.


2. Press the PPT key twice quickly, the other walkie talkie's watch will ring.

3. The communication distance in the open area is greater than 200M. When there are many obstacles, the communication distance is about 100M.

4. When using a strong radio signal nearby, it may be affected by interference and affect the call quality

When the red light on the charging cable goes out, it means that the walkie-talkie is fully charged.

Display function description:



Display screen: time display

Middle two keys function:

Left key(A): setting

Right key(B): 1. Press once to display the date;

2. Press twice to display the seconds;

3. Press three times to return to display the time

1. Set up the time: display the time, press the left button to set, then use the right button to set up the hour/minute, finish the setting by pressing the left button to complete the setting

2. Set up the date: display the date, press the left button to set, then press the right button to set up the month/day, press the left button to complete the setting

3. Set up the seconds: display the seconds, press the left button to return to zero to re-reading the seconds.