Servo Arm left Servo Head VCC **GND** MG90S Micro serve S AREFGND1312 **PWM** ensorShieldv5.0 VCC **GND Servo Arm Right** GND VCC PWM

MG90S Micro serva





