
To construct a WLAN and make the nodes communicate wirelessly.

	·
. 3).	AIM: TO Construct a WLAN & make the nodes
South	Commenicate minetersty.
	198 C. Par in Router than 11
1.	Topology:
	10.0.0.1
	Acces Paint - PT
	Access Point - PT
324 /	mminimum minimum onarran
	IIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIII
	PCO PCI Laptop
	10.0.02 10.0.0.3 10.0.0.4
	TO TO THE RESERVE OF THE PARTY
	Steps are as follows:
15	Constanct the about topology
2)	Configure PC3 & the Routers as is narmally done
3)	Configure Access Point 1 - Point 1 - 5 8 STB Name - any
1	name (WLAN here).
H)	Select WEP and give any 10 digit hex key - 1234567890
5)	Configuring PC4 & Laptop mith wineless standards. Switch off the device doing the evisting PT-HOST-NM.
6)	Switch off the device doing the everyting PT-HOST-NM.
	1 AM to the Component disted in the LHS anag
	WM P300 N wineless interface to the empty point. Switch
	on the device.
75	In the configure tab a new misuless interface would
	have keen added. Now Configure SSID, WEP, key, IP
	address and Gateway to the device.
	Observation: Pina loom event device to even when
a) I'm	Observation: Ping forom every device to every other
13	to the results.

TOPOLOGY:



OUTPUT:

