修改日期	修改人	修改內容
2014/11/12	Eric Hung	<ol> <li>於 geteventlistbyorder.cgi 裡面,新增 severity 欄位</li> <li>videoexport.cgi 的 mac 改 channel.</li> <li>getthumbnail.cgi 多一個</li> </ol>
		utc 的參數

## [Remote CGI]

CGI	Src -> Dst	Argument	Output format
AddCamera.xml	EtroCenter -> NVR	None	Refer to #1 on Page3
AddCamera.cgi	EtroCenter -> NVR	None	The output format is
			the same with
			AddCamera.xml.
			Refer to #1 on Page3
AddCameraJ.cgi	EtroCenter -> NVR	None	Refer to #2 on Page4
relate PTZ	EtroCenter -> NVR -> IP	This cgi command depends on the ptz specification of IP camera.	This output format
	camera	<ex> : http://<nvr_ip>:<remote_port>/<ip cam="" mac="">/config/<ptz< td=""><td>depends on the ptz</td></ptz<></ip></remote_port></nvr_ip></ex>	depends on the ptz
		cmd>	output from IP
			camera
getrecordlist.cgi	Playback -> NVR	1. None: output all info	Refer to #3 on Page5
		2. MAC= <mac addr=""></mac>	
		StartTime= <time64_t></time64_t>	
getthumbnail.cgi	Playback -> NVR	Id= <mac addr=""><channel></channel></mac>	A still image is output.
		utc= <time64_t></time64_t>	(JPEG)
		<ex>:</ex>	
		1.	

		http:// <nvr_ip>:<remote_port>/MAC/config/id=<mac_addr>01</mac_addr></remote_port></nvr_ip>	
		http://127.0.0.1:8080/00196C600744/config/id=00196C60074401	
geteventlistbyorder.cgi	EtroMobile -> NVR	MAC= <mac addr=""> StartTime=<time64_t></time64_t></mac>	Refer to #4 on Page6
		EventType= <eventtype></eventtype>	(As to EventType,
			please see the note in
			#4).
geteventlist.cgi	EtroCenter -> NVR	MAC= <mac addr=""> StartTime=<time64_t></time64_t></mac>	Refer to #5 on Page7.
		EventType= <eventtype></eventtype>	(About EventType,
			please see the note in
			#4 on Page6)
videoexport.cgi	Playback -> NVR	channel= <mac addr=""> Start_Time=<time64_t></time64_t></mac>	Refer to #6 on Page8
		End_Time= <time64_t></time64_t>	
videoprogress.cgi	Playback -> NVR	None	Refer to #7 on Page9
videodownload.cgi	Playback -> NVR	filename= <text file="" name=""></text>	The output format is
			an AVI file.
notify_stream.cgi	EtroCenter -> NVR	None	Refer to #8 on Page10

## [Output Format]

```
1. AddCamera.xml/AddCamera.cgi
<?xml version="1.0" encoding="UTF-8"?>
<AddCameraInfo>
    <CameraInfo TotalCamera="3">
         <camera0 cameraid="814" cameraname="EV8580Q-CD" connect_type_code="Static IP" IPAddress="10.1.21.63"</p>
mac_address="00196C600744" user="root" pass="pass" model_name="EV8580Q-CD" ptz_support=":" total_stream="1"
stream url="00196C600744" video format="196608" camera group="EtroCenter New Group"/>
         <camera1 cameraid="815" cameraname="SD20XDN2MP-WIP" connect type code="DHCP" IPAddress="10.1.21.40"</pre>
mac_address="00196C607956" user="root" pass="pass" model_name="SD20XDN2MP-WIP" ptz_support="<" total_stream="2"
stream url="00196C607956" video format="196608" camera group="EtroCenter New Group"/>
         <camera2 cameraid="816" cameraname="EV8180U-XL" connect type code="Static IP" IPAddress="10.1.21.191"</pre>
mac_address="00196C605F3C" user="root" pass="pass" model_name="EV8180U-XL" ptz_support=":" total_stream="2"
stream url="00196C605F3C" video format="196608" camera group="EtroCenter New Group"/>
    </CameraInfo>
    <StreamInfo TotalStream="0" stream port="554" http port="8080"/>
</AddCameraInfo>
```

```
3. getrecordlist.cgi
    "mac": "00196C010403",
    "CameraName": "Untitled0- 00196C010403",
    "LenType": 0,
    "ProfileID": "1",
    "duration": "1408332481~1408341419;"
    "mac": "00196C012202",
    "CameraName": "Untitled6-00196C012202",
    "LenType": 0,
    "ProfileID": "1",
    "duration": "1408332483~1408341419;"
```

```
4. geteventlistbyorder.cgi
     "mac": "00196C607956",
     "CameraName": "SD20XDN2MP-WIP",
     "eventtype": "MD",
     "duration": "1408443747~1408443921",
     "severity":"1"
     "mac": "00196C607956",
     "CameraName": "SD20XDN2MP-WIP",
     "eventtype": "MD",
     "duration": "1408443692~1408443747",
     "severity":"2"
<note>: The EventType code in argument is enumerated below:
MOTION_DETECTION =0, DIGITAL_INPUT=1, VIDEO_LOST =2, VIDEO_OPEN =3, REBOOT =4, DIGITAL_OUTPUT =5, MISSING_OBJECT = 6, EVENT_TRIGGER =7, TRANSACTION = 8,
DISK_FULL = 64, LOG_IN = 65, LOG_OUT = 66, DISCONNECT = 67, RECORDING_FAIL = 68
desc:
i). From 0~8 is the event that comes from IP camera. From the number after 64 indicates the system event which comes from Etrocenter/NVR
```

itself.

ii ). The severity variable has 4 level degree to indicate the severity of event. The number of meaning from 1 to 4 indicates critical, warning, information and system in order.

```
5. geteventlist.cgi
    "mac": "00196C600744",
    "CameraName": "EV8580Q-CD",
    "LenType": 0,
    "ProfileID": "1",
    "duration": "1408348249~1408348258;1408349950~1408350113;1408350721~1408350820",
    "EventType": "MD;MD;MD"
  },
    "mac": "00196C605F3C",
    "CameraName": "EV8180U-XL",
    "LenType": 0,
    "ProfileID": "1",
    "duration": "1408338724~1408338734;1408338824~1408339014;1408339125~1408339173",
    "EventType": "DI;DI;DI"
```

```
7. videoprogress.cgi
    "version": "0.2",
    "filelist": [
         "filename": "EV8580Q-CD-20140729_173311-20140730_100757.avi",
         "percent": "100.0%"
         "filename": "EV8580Q-CD-20140729_173311-20140730_100757_1.avi",
         "percent": "100.0%"
         "filename": "EV8580Q-CD-20140818_155049-20140818_155058.avi",
         "percent": "100.0%"
    "msg": "OK"
```

8. notify\_stream.cgi

--notifystream

time=1408556037

input1=off

md1=on

md2=off

md3=off

sd=invalid

vsignal1=on

tamper=off

MAC=00196C607956

--notifystream

<note> In remote notify\_stream.cgi, the MAC indicates the MAC address of IP camera which reside in NVR and be triggered by certain event.