


VORON 2.4 CNC TOOL-FREE TENSIONER FOR Z-AXIS BUILD GUIDE

VERSION 2024-03-25



READ BEFORE ASSEMBLY

WWW.CHAOTICLAB.XYZ



- Parts highlighted in blue are included in this CNC Tool-free Tensioner Kit.
- Parts highlighted in red are NOT included and will need to be prepared separately.



TOOL-FREE TENSIONER FOR Z-AXIS ASSEMBLY

2 sets



TOOL-FREE TENSIONER FOR Z-AXIS MIRROR ASSEMBLY

2 sets



M5X0.5MM SHIM

10 pcs

In the latest version of the VORON 2.4 CNC Parts Kit V2.0, the following new hardwear have been added:



**BUTTON HEAD CAP SCREW (BHCS)** 


M5x30 8 pcs



DROP-IN T-NUT

M5 8 pcs

EXPANDED VIEW WWW.CHAOTICLAB.XYZ



1

TOOL-FREE TENSIONER FOR Z-AXIS

WWW.CHAOTICLAB.XYZ

## **IDLER**


The kit is compatible with 13mm and 14mm idlers. Confirm the idler gear size before starting.






# REMOVE THE SCREW


Remove the screw at the position shown in the figure below.






## FOR 13MM IDLER

When using the 13mm idler gear, install the gear with the shims at both ends.








Tighten the screw

## FOR 14MM IDLER

When using the 14mm idler, there is no need to add a shim.








Tighten the screw

TOOL-FREE TENSIONER FOR Z-AXIS WWW.CHAOTICLAB.XYZ

#### **TENSION ADJUSTMENT**


Before installing the belt, rotate the thumbwheel to loosen the tensioner as shown in the figure below.



#### TIPS


The circular pattern indicates the degree of tightness. By rolling towards the smaller circle, you will loosen the tensioner. TOOL-FREE TENSIONER FOR Z AXIS

WWW.CHAOTICLAB.XYZ



TOOL-FREE TENSIONER FOR Z AXIS


WWW.CHAOTICLAB.XYZ



TOOL-FREE TENSIONER FOR Z AXIS

WWW.CHAOTICLAB.XYZ

Repeat the process to install two more tensioners on the opposite extrusion as shown.







Website www.chaoticlab.xyz

GitHub github.com/chaoticlab Discord discord.gg/uUCX666tk2