# ESP32 to ESP8266 UART Communication to Control LEDs — Full Project Documentation

## **Components Required:**

Component	Quantity
ESP32 Dev Board	1
ESP8266 NodeMCU	1
LEDs	3
220Ω Resistors	3
Jumper Wires	10+
Breadboard	1

## **Objective:**

- Send commands like "red on", "green off" etc. from ESP32 (via Serial Monitor).
- ESP8266 receives these commands via **UART** and controls LEDs accordingly.

## Wiring Diagram:

## ESP32 (Sender) to ESP8266 (Receiver):

ESP32 Pin	ESP8266 NodeMCU Pin	Purpose
GPIO17 (TX)	D2 (GPIO4 RX)	UART TX → RX
GPIO16 (RX)	D1 (GPIO5 TX)	UART RX ← TX
GND	GND	Common GND

## **ESP8266 (LED Connections):**

ESP8266 Pin	LED Color	Other End
D5 (GPIO14)	Red	220 $\Omega$ resistor → LED → GND
D6 (GPIO12)	Yellow	220 $\Omega$ resistor → LED → GND
D8 (GPIO15)	Green	220Ω resistor → LED → GND

#### **Software Tools:**

Development Board	IDE
ESP32	PlatformIO / VSCode
ESP8266	Arduino IDE

### ESP32 Code (Sender):

```
#include <Arduino.h>
HardwareSerial MySerial(1);

void setup() {
    Serial.begin(115200);
    MySerial.begin(9600, SERIAL_8N1, 16,17);
    delay(5000);
    Serial.println("Type Colour");
}

void loop() {
    if(Serial.available())
    {
        String input = Serial.readStringUntil('\n');
        MySerial.println(input);
        Serial.println("Sent : " +input);
    }
}
```

### **ESP32 (Sender) Code Explanation:**

#include <Arduino.h> // Include the core Arduino library

• This includes the Arduino library which is required to use standard Arduino functions like Serial.begin(), Serial.println(), etc.

HardwareSerial MySerial(1); // Declare UART1 for communication (ESP32 has 3 UARTs)

• ESP32 has 3 hardware serial ports (UART0, UART1, UART2). Here, UART1 is being used for communication with the ESP8266.

```
void setup() {
   Serial.begin(115200); // Initialize Serial Monitor communication at 115200 baud rate
   MySerial.begin(9600, SERIAL_8N1, 16, 17); // Initialize UART1 at 9600 baud using GPI016 (RX)
and GPI017 (TX)
```

```
delay(5000); // Wait 5 seconds for stability (good for USB serial connection)
  Serial.println("Type Colour Command like 'red on' or 'green off'"); // Instruction on Serial
Monitor
}
```

- Serial.begin(115200) sets up the communication between the ESP32 and the computer (USB Serial Monitor).
- MySerial.begin(9600, SERIAL\_8N1, 16, 17) configures UART1 with 9600 baud rate, 8 data bits, no parity, and 1 stop bit. TX is GPIO17 and RX is GPIO16.
- A delay of 5 seconds ensures everything initializes properly before communication begins.
- A message is printed to the Serial Monitor to inform the user about the command format.

```
void loop() {
  if (Serial.available()) { // Check if data is available from the Serial Monitor
    String input = Serial.readStringUntil('\n'); // Read the full string until newline character
    MySerial.println(input); // Send the string via UART1 to ESP8266
    Serial.println("Sent: " + input); // Print the sent command on Serial Monitor for
confirmation
  }
}
```

- The loop constantly checks for any input from the computer via the Serial Monitor.
- When a line is received (terminated by \n), it is read into the input string.
- This string is then sent to the ESP8266 using MySerial.println().
- The same string is printed back to the Serial Monitor for user feedback.

### ESP8266 Code (Receiver + LED Control):

```
#include <SoftwareSerial.h>
SoftwareSerial mySerial(D2,D1);
#define red D5
#define yellow D6
#define green D8
void setup() {
 mySerial.begin(9600);
 pinMode(red,OUTPUT);
 pinMode(yellow,OUTPUT);
 pinMode(green,OUTPUT);
   String command = mySerial.readStringUntil('\n');
   command.trim();
    Serial.print(" Command = " + command);
    if(command == "red on") digitalWrite(D5, HIGH);
    if(command == "red off") digitalWrite(D5,LOW);
    if(command == "yellow on") digitalWrite(D6, HIGH);
    if(command == "yellow off") digitalWrite(D6,LOW);
    if(command == "green on") digitalWrite(D8, HIGH);
    if(command == "green off") digitalWrite(D8,LOW);
```

```
#include <SoftwareSerial.h> // Include SoftwareSerial library for UART on arbitrary pins
```

• The ESP8266 generally has only one hardware serial port, so SoftwareSerial is used to create another serial port on GPIO4 and GPIO5.

```
SoftwareSerial mySerial(D2, D1); // Declare SoftwareSerial: RX=D2 (GPIO4), TX=D1 (GPIO5)
```

- Defines a SoftwareSerial object named mySerial on pins D2 (RX) and D1 (TX).
- D2 will receive data coming from ESP32's TX.

```
#define red D5  // Define 'red' LED on pin D5 (GPI014)

#define yellow D6  // Define 'yellow' LED on pin D6 (GPI012)

#define green D8  // Define 'green' LED on pin D8 (GPI015)
```

These are easy-to-read names assigned to each LED pin.

- Serial communication to the PC (USB) and ESP32 (via SoftwareSerial) is initialized.
- The LED pins are set as outputs, meaning they will provide voltage to the LEDs.

```
void loop() {
  if (mySerial.available()) { // Check if any data is available from ESP32
    String command = mySerial.readStringUntil('\n'); // Read the incoming command string till newline
```

```
command.trim(); // Remove unwanted whitespace or carriage return characters
```

Serial.println(" Command = " + command); // Print the received command on Serial Monitor for
debugging

- The program waits until a complete command is received from ESP32 via UART.
- The string is then cleaned (trimmed) to remove extra characters like \r.

```
if (command == "red on") digitalWrite(red, HIGH);  // Turn red LED ON

else if (command == "red off") digitalWrite(red, LOW);  // Turn red LED OFF

else if (command == "yellow on") digitalWrite(yellow, HIGH);  // Turn yellow LED ON

else if (command == "yellow off") digitalWrite(yellow, LOW);  // Turn yellow LED OFF

else if (command == "green on") digitalWrite(green, HIGH);  // Turn green LED ON

else if (command == "green off") digitalWrite(green, LOW);  // Turn green LED OFF

else Serial.println("Unknown Command");  // Print this if an unexpected command arrives
}
```

- The command is compared to expected strings such as "red on", "yellow off", etc.
- When a match is found, the appropriate LED pin is turned ON or OFF.
- If no match is found, it prints "Unknown Command" to help debugging.

### Steps to Implement:

}

### 1. Hardware Connections:

Connect ESP32 UART TX/RX to ESP8266 UART RX/TX (cross-connected). Common Ground between ESP32 & ESP8266. Connect 3 LEDs with  $220\Omega$  resistors to D5, D6, D8 of ESP8266.

#### 2. Flash ESP8266:

Open **Arduino IDE** → Select:

- Board: "NodeMCU 1.0 (ESP-12E Module)"
- Port: Your ESP8266 COM port.
- Paste ESP8266 Code, compile & upload.

### 3. Flash ESP32:

Open PlatformIO (VSCode)  $\rightarrow$  Select:

- Board: "ESP32 Dev Module"
- Paste **ESP32 Code**, compile & upload.

## 4. Serial Monitor Settings:

```
ESP32 Serial Monitor: 115200 baud → Type: red on, red off, yellow on, green off, etc.
```

ESP8266 Serial Monitor: 115200 baud (Optional for debugging).

### 5. Test:

```
Type red on \rightarrow Red LED turns ON.
Type yellow off \rightarrow Yellow LED turns OFF.
Works for Green as well.
```

### Notes:

- 1. Important: Always connect the GND of ESP32 and ESP8266 together.
- 2. Use **separate USB cables** for programming each board.
- 3. Remove ESP32's UART connection from ESP8266 during **flashing** to avoid interference.
- 4. After flashing, reconnect wires for UART.







