

# **Myriad 2 SHAVE Assembly**

**Programming Guide** 

v1.01 / February 2018

Intel<sup>®</sup> Movidius™ Confidential



## **Copyright and Proprietary Information Notice**

Copyright © 2018 Movidius, an Intel company. All rights reserved. This document contains confidential and proprietary information that is the property of Intel Movidius. All other product or company names may be trademarks of their respective owners.

Intel Movidius 2200 Mission College Blvd M/S SC11-201 Santa Clara, CA 95054 http://www.movidius.com/



## **Table of Contents**

1 Introduction	4
2 General structure of an .asm file	
3 Calling convention	
4 Looping	
5 Branching	
6 Predicate execution of instructions	
7 Predicate execution of instructions	
8 Accumulator	
9 SIMD	
10 Deinterleave / Swizzle	
11 Alignvec / Shiv	
12 Tips and tricks	
13 Assembly Optimization Guide	



#### 1 Introduction

This document is intended to be a programmer's guide on working with assembly language.

#### 2 General structure of an .asm file

- .version <versionNumber>; set, macro, include, other preprocessor directives.
- .data section data elements that are declared with an initial value (.data .data.example).
- .code section the instruction codes (.code .text.example).
- .end

### 3 Calling convention

The main purpose of these calling conventions is to allow programs compiled with moviCompile to call functions written in SHAVE assembly, and vice-versa. The programmer must ensure that the Stack pointer register, Link register and all of the preserved registers have the same values at the return of the handwritten assembly function as they had at the entry point.

#### **Registers:**

- Stack pointer register IRF register I19 is reserved as a dedicated stack pointer and should never be modified except to allocate and free space for stack variables.
- Link Register IRF register I30 is used both to store the address to which control flow should jump when a function is called, and the return address to which control flow should jump after a function has completed execution.
- Preserved IRF registers (i20,...,i29,i31) and VRF registers (v24,...,v31).

Up to 8 scalar parameters may be passed via the IRF, using registers i11, i12, ..., i18. Register i18 is also used to store the return value for a method call.

Up to 8 vector parameters may be passed via the VRF, using registers v16, v17, ..., v23. Register v23 is also used to store the return value for a method call if the return value is one of the above types.

If a method accepts more than 8 parameters, then parameters from 9 and onwards must be passed via the stack.

#### **Example:**

```
int Example(int a, int b, int c, int d, int e, int f,int g,int h,int
i,int j)

i18 = a;
i17 = b;...
i11 = h;
read i from i19
read j from i19 + sizeof(i)
```

At the end of the function, i18 should contain the value returned by Example.



## 4 Looping

You may use BRU.RPL (a variable number of times) or BRU.RPS (a constant number of times) to create a loop. Or you may use different jump instructions (BRU.BRA, BRU.JMP) with a condition or counter to create a conditional loop.

#### Example 1:

#### Example 2:

## 5 Branching

The basic implementation of an IF..THEN..ELSE statement will look like this:

```
lsu0.ldil i0 0x0
                      || lsu1.ldih i0 0x0
                      || lsu1.ldih i1 0x0
lsu0.ldil i1 0x3
                      || lsul.ldih i2 0x0
lsu0.ldil i2 0x0
cmu.cmii.i32 i0,i1
peu.pc1c EQ
                      || bru.bra L branch1
peu.pclc NEQ
                      || bru.bra L branch2
nop 6
L branch1:
/\overline{/} do branch 1 operations
iau.add i2,i2,3
iau.add i3,i2,i2
bru.bra L end // make sure you jump over branch 2
nop 6
L branch2:
/\overline{/} do branch 2 operations
iau.add i2,i2,1
iau.add i3, i2, i2
L end:
```

If your branches are not so complicated, better avoid those BRU.BRA and those nops and do something like this:



or:

#### 6 Predicate execution of instructions

PEU instructions operate on the condition code (CC) registers. The CC register has dedicated fields for condition codes generated by the CMU, SAU and IAU.

#### **Example:**

#### 7 Predicate execution of instructions

You may predicate individual units, by using PEU.PCCX or PEU.PCIX. Each unit has a corresponding slot, which must be set to one if we want to predicate that unit.

```
// if i1== i2 all the operations will be executed
// else only the lsu1 operation will be executed
iau.sub i0 i1 i2
peu.pcix.EQ 0x9  || iau.operation || vau.operation ||
lsu1.operation
// this 0x9 is 1001 în binary, IAU and VAU slots are set to 1
```

Or even predicate Vector Elements to generate a VRF write enable for the current VAU/SAU/LSU0/LSU1 instruction.



```
// v0 = 1 2 1 3 // only if v0.x > v1.x v2.x will be increased with 5 // v1 = 1 1 1 1 1 // v2 = 0 0 0 0 cmu.cmvv.i32 v0 v1 peu.pvv32 gt || vau.add.i32 v2 v2 5 // v2 = 0 5 0 5
```

#### 8 Accumulator

Accumulators are used within the VAU and SAU and allow for power-efficient accumulation of values.

Suppose we have two matrices- int A[4][4] and int B[4][4] and we want to:

```
compute C[4] where C[i] = A[0][i]*B[0][i]+A[1][i]*B[1][i]-A[2][i]*B[2][i]-A[3][i]*B[3][i]
```

Use accumulator on VAU unit:

```
vau.macpz.i32 v0 v4
vau.macp.i32 v1 v5
vau.macn.i32 v2 v6
vau.macnw.i32 v14 v3 v7
```

#### instead of this:

```
vau.mul.i32  v8  v0  v4
vau.mul.i32  v9  v1  v5
vau.mul.i32  v10  v2  v6
vau.mul.i32  v11  v3  v7
vau.add.i32  v12  v8  v9
nop
vau.add.i32  v13  v10  v11
nop 2
vau.sub.i32  v14  v12  v13
```

#### 9 SIMD

Use SIMD (Single Instruction Multiple Data) to increase the performance of your code.

Suppose we want to add two arrays: int A[4] and int B[4].

We can do this by using IRF registers and 4 IAU. ADD instructions or we can do this by using VRF registers and a single VAU. ADD instruction.

#### Do this:



instead of this:

## 10 Deinterleave / Swizzle

Let's say we have two VRF registers and we want to save their elements from odd positions into a certain location and their elements from even positions into another location. This is how we can do this easily:

If you want to multiply all elements of a VRF with the first element of another VRF, do this:

```
cmu.vszm.word v0,v0,[0000] // fill v0 with v0.0 vau.mul.i32 v1,v1,v0
```

or better this:

or

```
vau.mul.i32 v1 v1 v0 || lsu1.swzmv4.word [0000]
```

## 11 Alignvec / Shiv

Let's say we have a VRF register, an IRF register and we want to output a combination of these two. Vout = IRF Vin[0] Vin[1] Vin[2]

## 12 Tips and tricks

- Minimize the number of memory accesses. We need to have a very good reason to read the same memory location multiple times. This has very big impact in the number of cycles, if the kernel will be used in a bigger project.
- ➤ Use preserved registers without saving them on the stack. If you need more IRF registers but you have lots of spare V registers, just use VRF registers as temporary storage if your application permits it.



- Don't forget to move the registers back to their proper places before exiting your handcrafted function!
- Avoid many small data transfers. Instead, use a single large data transfer. If possible, use one VRF register instead of four 32-bit IRF registers.
- Avoid floating point use if it's not absolutely necessary. Latency for integer types is lower and precision is higher, and the power consumption is probably lower too (operations in floating point incorporate significant more HW logic).
- If you have a full 32-bit number and you need to divide by x, you can simply do a multiply with the precalculated 1/x value. This is faster because multiplication is faster than division.
- ➤ Use BRU.RPI or BRU.RPIM instead of doing a loop if you have only one instruction to repeat several times. This will keep your code size smaller.

## 13 Assembly Optimization Guide

#### > Step 0 – Starting from c implementation

For the purpose of this guide we will take in consideration example 011 from mdk/examples /Progressive.

When writing assembly code, we need to take in consideration the initial .c code.

The main purpose of writing a simple and efficient code is meeting the need to process as many values we can at a time.

#### Step 1 – Translation

The initial goal for writing assembly code is to write it in simple steps.

The first written code in assembly should include all the latency of the instructions used, and it should have a linear implementation. (no parallelization)

This type of writing is for the need of debugging first. If we have a very optimized code, it is very hard to debug the problems that appear at implementing asm code.

First step in the assembly implementation will include also many comments related to the functionality.

#### Step 2 – Removing "nop's" and parallelizing the asm code

In the second step we want to remove unnecessary "nop's" that are present in the code from the first step. Unnecessary in this case means that the functionality will be the same even without some of the "nop's". We start parallelizing the instruction by moving some LSUO instructions on the LSUO unit and put them in parallel.



Removing the nop's from the delay slot of the loop is another thing that is needed to be done. You will see that we don't have nop 7 at the end of the loop anymore. Instead of them we will have functional code from part of the loop. This means that we only moved the label of the main loop up a few instructions, but maintaining the 7 delay slot of the bru.rpl instruction.

#### > Step 3 – Loop parallelization: changing instructions in order to have less instructions in a loop

To achieve the best performance of the written asm code, the loop dimension should be given based on the most used unit.

In our simple code it is mandatory to take in consideration the VAU unit, that is used in 7 instructions plus another 9 instructions that are used to write out in a vrf register the result of our operations.

The main goal is to have the loop consisting of as little as possible number of instructions, so in our case the code from STEP 2 has 7+9 instructions that will give the loop a dimension consisting of 16 instructions.

For the purpose of this guide we will consider optimizing it at full capacity, and not take the precision in consideration.

The change of VAU.MAC with VAU.MUL and VAU.ADD will have the end result of reducing the number of instructions in the loop to 13 instructions.

#### Step 4 – Loop parallelization: making the loop based only on the principal unit used

In order to achieve this end-result code, it is very useful to have different registers used for the results of the instructions, the registers used for inputs, should be different, then the ones used for the results, in this way we can parallelize the code better. It should work like a chain: the output from one instruction, should be the input for other instructions.

It is necessary to have in mind, that a function consists from a LOAD part, a PROCESS part and a STORE part. The structure of parallelizing should be the following:

- LOAD
- LOAD + PROCESSING
- LOAD + PROCESSING + STORE in the main loop parallelizing

This structure of optimizing an asm code can be achieved by parallelizing blocks, and removing them from the loop. In this situation, an overhead will be created, but the number of instructions from the loop will get reduced.

Depending on the code, this action of parallelizing and removing from the loop can consist of fewer steps. In the STEP4 asm code, all the steps are marked to be easy to understand.

10