

A Technical Summary of Motor Fundamentals, Control, and Selection

Synthesized from eight sources on DC, brushless, and stepper motors, their drivers, and engineering selection

DC and Brushless Motor Fundamentals

A DC motor turns electricity into motion, and inside it you find a casing that holds two permanent magnets, a central shaft, a spinning core wrapped in coils of wire, a ring called a commutator split into segments, and small brushes that press against that ring to keep the electricity flowing [5]. When electricity flows through a coil of wire it acts like a magnet, and reversing the direction of the electricity flips which end is north and which is south [5], [4]; just like ordinary magnets, opposite poles pull together and matching poles push apart, and that constant push and pull is what spins the shaft [5]. A single coil can get stuck, so most motors use at least three coils spaced evenly around the core so the motion stays smooth, and the brushes switch the electricity from coil to coil as it turns; flipping the power supply makes the motor spin the other way [5]. The spinning core is built from thin stacked metal sheets rather than one solid piece, which keeps the motor from wasting energy as heat [5]. A brushless motor does the same job but uses three sets of wires instead of brushes, and because nothing rubs, it runs more efficiently and lasts much longer, which is why it shows up in drones, computer fans, and cordless drills [6]. In the common “outrunner” style the outer shell spins around stationary coils and delivers plenty of turning force [6]. Its three wires plug into an electronic speed controller (ESC), which rapidly switches the power on and off to create a rotating magnetic pull; a typical motor pairs twelve coils against fourteen magnets so they never line up perfectly and the motor keeps chasing alignment [6]. The controller sends short on-off pulses about fifty times a second, and the wider those pulses are, the faster the motor spins; it figures out where the rotor is either with a sensor or by reading the small voltage the spinning magnets create, which is why these motors twitch and beep for a moment at startup [6]. A brushless motor is easy to run from an Arduino and a simple knob, using the built-in servo library to send those timing pulses [6].

Stepper Motors and How They Move

A stepper motor moves in tiny, exact increments: every electrical pulse turns it one “step,” so the number of pulses sets how far it turns and how fast you send them sets the speed, and it can spin freely, inch along step by step, or stop and firmly hold a position—which makes it perfect for 3D printers, CNC machines, and precision valves [3], [4]. A standard stepper takes 200 steps to make one full turn, so each step is 1.8 degrees, and a great feature is that its tiny error (about 0.05 degrees) never piles up no matter how many steps it takes [3], [4]. A complete setup includes a computer or controller for the “brains,” a part that counts out the pulses and smoothly speeds the motor up and slows it down, and a driver that actually powers the motor coils [3]. There are three kinds of stepper, and the most common is the “hybrid,” which combines a permanent magnet with finely toothed parts; the trick to its precision is that the spinning part has slightly more teeth than the surrounding frame, so they can never all line up at once and the motor can settle into very fine positions [3], [4]. More teeth mean more precision and smoother, quieter motion, so high-resolution models cut each step in half [3]. There are several ways to power the coils, ranging from the simplest (one coil at a time, which is rougher) up to “microstepping,” which feeds the coils gradually for the smoothest, finest motion, though it trades away some strength [3], [4]. A motor’s speed-versus-strength chart shows what it can actually do, and pushing far more electricity through it than rated gives no extra strength and can even ruin its magnets [3]. Steppers naturally lose a little strength at high speeds, which is partly fixed by running them at a higher supply voltage [3]. Each step makes the motor “ring” or wobble slightly, so it runs best with a sensible load attached, and a vibration trouble spot near 200 Hz is simply avoided or passed through quickly [3]. Steppers usually run “open-loop” with no position check, but Oriental Motor’s AlphaStep adds a built-in sensor that quietly corrects the motor the instant it drifts off, giving very tight accuracy [3].

Driving and Programming a Stepper

A NEMA 17 (a common size named for its 1.7-inch faceplate) has four wires that must be powered in a careful sequence, which is exactly why it needs a driver chip rather than just plugging into power [8]. The widely used A4988 driver lets you cap how much current reaches the motor and supports fine microstepping; the DRV8825 is a near drop-in upgrade with more current and finer steps, and the TMC2208 adds whisper-quiet operation and even smoother motion [8]. On each driver you set the current limit by turning a small dial and checking a reference voltage, and each pulse to the STEP pin moves the motor one step in whichever direction the DIR pin selects [8]. You can program it directly in Arduino by toggling that pin with a delay that sets the speed, or use the popular AccelStepper library to get smooth speeding-up and slowing-down and to coordinate several motors at once, while an Arduino CNC shield can run up to four motors together [8].

Motor Drivers and the H-Bridge

A motor driver is basically a power booster: a small controller like an Arduino only puts out a few volts and very little current, so it can’t run a motor directly without underpowering it or even damaging itself, and the driver uses a separate power supply to deliver what the motor really needs [7]. Drivers are built around an “H-bridge” of four switches—flipping one diagonal pair spins the motor one way and the other pair spins it the other way, but turning everything on at once causes a damaging short circuit, which is exactly the hazard the Cornell Cup guide warns against [7], [1]. Popular driver chips range from cheap basic ones (like the L293D and L298N) to more efficient, cooler-running types (like the TB6612FNG) and heavy-duty high-current ones (like the VNH2SP30) [7]. The more efficient MOSFET-based drivers waste far less power and heat than the older transistor type, so they’re the better pick for bigger or battery-powered projects [7]. Picking a driver comes down to four things: the motor’s voltage, its current draw, what the project is for, and how it’s powered [7].

Controlling Motors: Speed, Feedback, and Stopping

A motor control system translates a simple command like “run at half speed forward” into the exact signals the motor needs, and smarter systems add a sensor that watches the actual speed and nudges the command until the motor does what it was told [1]. The main trick for controlling speed is to switch the power on and off very rapidly so the motor feels an average—spend more time “on” and it runs faster—because the motor reacts too slowly to notice the individual flickers [1]. There are two common ways to encode that signal: one uses a separate wire to set direction and gives finer speed control, while the other packs both into a single wire to save a pin but with less precision [1]. The same H-bridge can also let the motor coast gently to a stop or brake it hard, though hard braking causes voltage spikes that can wear the motor out, so the example robot coasts by default [1]. Real-world testing showed that off-the-shelf drivers often don’t live up to their spec sheets, so the team picked the inexpensive Cytron driver over a pricier one for its lower cost, lighter weight, and solid performance, and in software they mapped the command range cleanly to speed, ignored tiny speed values that would just stall the motor, and wired the left and right motors as mirror images [1].

Choosing the Right Motor

Choosing a motor starts by turning fuzzy goals into numbers—the example robot’s “fast and agile” became a target speed and acceleration—which then translate into how fast the wheels must turn and how much turning force is needed, with the hardest demand coming during acceleration;

that force also has to stay low enough that the wheels grip instead of slipping [2]. Its sideways-rolling mecanum wheels nudge the targets a bit higher and work because their angled rollers come in mirror pairs whose pushes combine to move the robot forward, sideways, or in a spin [2]. The chosen operating point has to fall inside the motor's safe zone on its performance chart so it doesn't overheat, and the team also has to avoid slamming full voltage onto a stopped motor, which would spike the current and could damage the gears [2]. Because the wheels need lots of force at a low speed but motors naturally spin fast with little force, a gearbox bridges the gap, trading speed for force at a small efficiency cost [2]. Every bit of mechanical demand also draws extra electrical power because nothing is perfectly efficient, and a quick heat check confirmed the motor would stay comfortably below its temperature limit [2]. Sensors like encoders are added when other parts of the system need to know the motor's position or speed, and the final pick weighs cost, delivery time, size, and weight in a scoring chart—where favoring strength and efficiency pointed to one motor but prioritizing fast delivery picked another, showing there's no single perfect motor, only the best fit for clearly chosen priorities [2].

References

- [1] Cornell Cup USA presented by Intel, "Motor Controller Guide," Cornell Univ., Ithaca, NY. [Accessed: Jun. 16, 2026].
- [2] Cornell Cup USA presented by Intel, "Motor Selection Guide," Cornell Univ., Ithaca, NY. [Accessed: Jun. 16, 2026].
- [3] Oriental Motor U.S.A. Corp., "Basics of Stepper Motors." <https://www.orientalmotor.com/stepper-motors/technology/stepper-motor-basics.html> [Accessed: Jun. 16, 2026].
- [4] The Engineering Mindset, "How does a Stepper Motor work?" YouTube. <https://www.youtube.com/watch?v=09Mpkjcr0bo> [Accessed: Jun. 16, 2026].
- [5] The Engineering Mindset, "How does a DC Motor work?" YouTube. <https://www.youtube.com/watch?v=GQatiB-JHdI> [Accessed: Jun. 16, 2026].
- [6] The Engineering Mindset, "How does a Brushless Motor work?" YouTube. <https://www.youtube.com/watch?v=yiD5nCfmbV0> [Accessed: Jun. 16, 2026].
- [7] SD Robotics, "Motor Driver — What is a Motor Driver and How it Works." YouTube. <https://www.youtube.com/watch?v=PVyAcgYkzDs> [Accessed: Jun. 16, 2026].
- [8] How To Mechatronics (D. Pajak), "How To Control Stepper Motors with Arduino." YouTube. https://www.youtube.com/watch?v=7spK_BkMJys [Accessed: Jun. 16, 2026].