
Software:

Kali-Linux:

Follow the steps below:

- 1. Open the linkk right here: https://re4son-kernel.com/re4son-pi-kernel/
- 2. Scroll down until you see the downloads

Download the file that maches your pi version.



3. Download the Balena Etcher software and open it.
Select a SD card and your Kali-linux OS
hit FLASH

- 4. When the flashing is done take the sd card and put it into the pi and start it up.
- 5. The user name is root and the password is toor
- 6. Open the terminal and type: psswd and type a new password.

And it s done.