




EXPLODED			
DIAGRAM	FIXTURE	PART NUMBER	DESCRIPTION
REF STATIC			
1	FLEXSTANDFXILSWHT	PTK203010140Z	Extension pole (BOM#1)
2	FLEXSTANDFXILSWHT	PTK207010002Z	Clear PC cover (inner tube) (BOM#2)
2	FLEXSTANDFXILSWHT	PTK209020083Z	Screw_KM3x6mm White
3	FLEXSTANDFXILSWHT	PTK5101020001Z	LED PCB (BOM#3)
3	FLEXSTANDFXILSWHT	PTK209010001Z	Screw_PM3x6mm White
3	FLEXSTANDFXILSWHT	PTK403020108Z	Outer box L1390*W600*H110mm
4	FLEXSTANDFXILSWHT	PTK203010139Z	Inner tube (BOM#4)
4	FLEXSTANDFXILSWHT	PTK406020004BZ	Carry bag (Base plate) L600*W585*H45mm
5	FLEXSTANDFXILSWHT	PTK202020013Z	Wire pressing plate C_L13*W6*H5mm (BOM#5)
5	FLEXSTANDFXILSWHT	PTK209030106Z	Screw_M5x8mm White
5	FLEXSTANDFXILSWHT	PTK209070015Z	Screw nut M3_5.5x4mm White
5	FLEXSTANDFXILSWHT	PTK403020096Z	Color box L225*W88*H500mm
6	FLEXSTANDFXILSWHT	PTK202020011Z	Wire pressing plate A_L13*W13*H6mm (BOM#6)
6	FLEXSTANDFXILSWHT	PTK302050005Z	Double-sided adhesive tape
6	FLEXSTANDFXILSWHT	PTK209070011Z	Screw nut M3_5.5x2.4mm White
7	FLEXSTANDFXILSWHT	PTK206050296Z	Plastic clip (BOM#7)
7	FLEXSTANDFXILSWHT	PTK209020032Z	Washer White
8	FLEXSTANDFXILSWHT	PTK202020018Z	Side plate for the inner tube (BOM#8)
8	FLEXSTANDFXILSWHT	PTK209020045Z	Screw_KB3x8mm White
9	FLEXSTANDFXILSWHT	PTK209080001Z	Rubber washer (BOM#9)
9	FLEXSTANDFXILSWHT	PTK209010037Z	Screw PM3x14mm Black
10	FLEXSTANDFXILSWHT	PTK206050295Z	Adapter_L56.7*W56.2*H20mm (BOM#10)
10	FLEXSTANDFXILSWHT	PTK209010055Z	Screw_PM3x14mm White
10	FLEXSTANDFXILSWHT	PTK403020097Z	Color box L225*W88*H280mm
11	FLEXSTANDFXILSWHT	PTK204020019Z	Adapter_L85.4*W68.2*H45.5mm (BOM#11)
11	FLEXSTANDFXILSWHT	PTK129010002Z	Fuse 1A_250V
12	FLEXSTANDFXILSWHT	PTK209050054Z	Bracket Screw_L65xH22_M8x22mm White (BOM#12)
12	FLEXSTANDFXILSWHT	PTK209020099Z	Screw_KM4x8mm White
12	FLEXSTANDFXILSWHT	PTK209010038Z	Screw_PM3x14mm White
13	FLEXSTANDFXILSWHT	PTK202020010BZ	Index pin_L36*W8*H7 (BOM#13)
13	FLEXSTANDFXILSWHT	PTK209010096Z	Screw_PA3x8mm White
14	FLEXSTANDFXILSWHT	PTK209110003BZ	Tension spring (BOM#14)
14	FLEXSTANDFXILSWHT	PTK209010012Z	ScrewPB_3x12mm Black
15	FLEXSTANDFXILSWHT	PTK202020135Z	Fixed column_φ20*H19mm (BOM#15)
15	FLEXSTANDFXILSWHT	PTK209010071Z	Screw PM_3x5mm Black
15	FLEXSTANDFXILSWHT	PTK406820006AZ	Plastic bag L800xW650xT0.04mm
16	FLEXSTANDFXILSWHT	PTK202020134Z	Connecting adapter_L64*W20*H14mm (BOM#16)
16	FLEXSTANDFXILSWHT	PTK209100043Z	ABS stand-off
17	FLEXSTANDFXILSWHT	PTK202020136Z	Pressing plate_L24*W16*H5.3mm (BOM#17)
17	FLEXSTANDFXILSWHT	PTK209020009Z	Screw_KM3x5mm White
18	FLEXSTANDFXILSWHT	PTK207010001Z	Clear PC cover (outer tube) (BOM#18)
18	FLEXSTANDFXILSWHT	PTK209030109Z	Screw_M5x6mm
18	FLEXSTANDFXILSWHT	PTK403820017Z	Edge protection
19	FLEXSTANDFXILSWHT	PTK5101020002Z	LED PCB (outer tube) (BOM#19)
19	FLEXSTANDFXILSWHT	PTZ209020012Z	Screw_KM3x14mm Black
20	FLEXSTANDFXILSWHT	PTK203010138Z	Outer tube (BOM#20)
20	FLEXSTANDFXILSWHT	PTK209080040Z	Washer Black
20	FLEXSTANDFXILSWHT	PTK209080002Z	Lock washer_ID3xOD6mm
20	FLEXSTANDFXILSWHT	PTK403020099Z	Color box L160*W64*H420mm
21	FLEXSTANDFXILSWHT	PTK209100181Z	Hexagonal aluminum column_H5xM3x45 (BOM#21)
21	FLEXSTANDFXILSWHT	PTK209020016Z	Screw_KM4x8mm Black
21	FLEXSTANDFXILSWHT	PTK302050082Z	packing strap W13.5mm_T0.8mm
21	FLEXSTANDFXILSWHT	PTK403020098Z	Color box L203*W66*H243mm
22	FLEXSTANDFXILSWHT	PTK5701010022AAZ	MPCB (BOM#22)
22	FLEXSTANDFXILSWHT	PTK209030108Z	Screw_M4x6mm
22	FLEXSTANDFXILSWHT	PTK403020107Z	Outer box L1412*W622*H116mm
23	FLEXSTANDFXILSWHT	PTK209120007Z	Knob cap_φ7*4.5mm (BOM#23)
23	FLEXSTANDFXILSWHT	PTK209020005Z	Screw_KM3x6mm Black
23	FLEXSTANDFXILSWHT	PTK406820052AZ	Plastic bag L1800xW250xT0.04mm
24	FLEXSTANDFXILSWHT	PTK202020012Z	Fixing plate_L13*W6*H5mm (BOM#24)
25	FLEXSTANDFXILSWHT	PTK130010021Z	Power supply (BOM#25)
25	FLEXSTANDFXILSWHT	PTK301010042Z	Allen key
26	FLEXSTANDFXILSWHT	PTK209100182Z	Hexagonal aluminum column_H5xM3x45 (BOM#26)
26	FLEXSTANDFXILSWHT	PTK209040016Z	Screw PWM3x8mm Black
27	FLEXSTANDFXILSWHT	PTK5101070003Z	DMX & USB board (BOM#27)

27	FLEXSTANDFXILSWHT	PTK209070026Z	Screw nut M5_8.8x5mm White
27	FLEXSTANDFXILSWHT	PTK209010034Z	Screw PM3x8mm Black
28	FLEXSTANDFXILSWHT	PTK209120010Z	USB back-up plate (BOM#28)
28	FLEXSTANDFXILSWHT	PTK209020100Z	Screw_KM3x10
28	FLEXSTANDFXILSWHT	PTK403820015Z	Paperboard
29	FLEXSTANDFXILSWHT	PTK206050297Z	Bump-out for the 2.4G module (BOM#29)
29	FLEXSTANDFXILSWHT	PTK209030107Z	Screw_M5x35mm White
29	FLEXSTANDFXILSWHT	PTK406820014AZ	Plastic bag L300xW250xT0.04mm
29	FLEXSTANDFXILSWHT	PTK403020102Z	Color box L203*W66*H463mm
30	FLEXSTANDFXILSWHT	PTK201050142Z	Top cover for the control box (BOM#30)
30	FLEXSTANDFXILSWHT	PTK406020002BZ	Carry bag L1550xW160xH65mm
31	FLEXSTANDFXILSWHT	PTK5102010002Z	433Hz wireless receive module (BOM#31)
31	FLEXSTANDFXILSWHT	PTK209010035Z	Screw_PM3x10mm Black
32	FLEXSTANDFXILSWHT	PTK203010141Z	Main casing for the control box (BOM#32)
33	FLEXSTANDFXILSWHT	PTK121010001Z	Power socket (input) (BOM#33)
34	FLEXSTANDFXILSWHT	PTK121010038Z	Power socket (output) (BOM#34)
35	FLEXSTANDFXILSWHT	PTK201120026Z	Fixing plate for the tension spring (BOM#35)
36	FLEXSTANDFXILSWHT	PTK202020014Z	Strengthen tube (BOM#36)
37	FLEXSTANDFXILSWHT	PTK204020020Z	Side plate for the outer tube (BOM#37)
38	FLEXSTANDFXILSWHT	PTK201050143Z	Base plate _L550*W547.2*H8mm (BOM#38)
39	FLEXSTANDFXILSWHT	PTK209050056Z	Bottom Bracket Screw 39xH24_M10x18mm Black (BOM#39)
39	FLEXSTANDFXILSWHT	PTK209050015Z	Bottom Bracket Screw 39xH24_M10x18mm Black (BOM#39)
40	FLEXSTANDFXILSWHT	PTK209120009Z	Rubber feet (BOM#40)
41	FLEXSTANDFXILSWHT	PTK131010001Z	Power cable (BOM#41)
42	FLEXSTANDFXILSWHT	PTK209050033Z	Top Bracket Screw_L65xH30_M10x15mm Black (BOM#42)