

EXPLODED DIAGRAM		DESCRIPTION
REF STATIC		DESCRIPTION
1	PTJ61103653A	GEL FRAME (BOM#1)
2	PTJ39900013	SILICONE TUBE (BOM#2)
3	PTJ61103651	GEL FRAME FIXING PLATE (BOM#3)
4	PTJ31000591A	GEL FRAME LOCK HOLDER (BOM#4)
5	PTJ61101083	GEL FRAME LOCK (BOM#5)
6	PTJ32500045	SPRING (BOM#6)
7	PTJ62000521A	LENS COVER (BOM#7)
8	PTJ61008876	LENS HOLDER (BOM#8)
9	PTJ32300242	LENS ASSEMBLY (BOM#9)
10	PTJ61103648	ZOOM LENS BARN DOOR (BOM#10)
11	PTJ31001168	ZOOM HOLDER (BOM#11)
12	PTJ39900058	MAGNET (BOM#12)
13	PTJ32300241	ZOOM ASSEMBLY (BOM#13)
14	PTJ31001170	ZOOM BEARING ASSEMBLY (BOM#14)
15	PTJ61102289A	BELT PLATE (BOM#15)
16	PTJ32301284	PENTAPRISM (BOM#16)
17	PTJ31000411C	PRISM HOLDER ASSEMBLY (BOM#17)
18	PTJ32400117	PRISM TIMING BELT (BOM#18)
19	PTJ61005849	FROST HOLDER B (BOM#19)
20	PTJ34100120	DOUBLE-SIDED TAPE FOR FILTER (BOM#20)
21	PTJ32200587	1degree FILTER (BOM#21)
22	PTJ31000419A	FROST FLANGE ASSEMBLY (BOM#22)
23	PTJ31000105A	ZOOM TIMING BELT PULLEY (BOM#23)
24	PTJ61005854	FROST CONNECTOR (BOM#24)
25	PTJ32500082	FROST TENSION SPRING (BOM#25)
26	PTJ31000071	FROST HOLDER A (BOM#26)
27	PTJ61103652A	CONNECTOR PLATE (BOM#27)
28	PTJ32100269	PRISM SLIDER WHEEL STAND OFF (BOM#28)
29	PTJ32100131	SLIDER WHEEL (BOM#29)
30	PTJ62100238	BLACK SILICONE POSITIONING SLEEVE (BOM#30)
31	PTJ32100346	PRISM POSITIONING MAST (BOM#31)
32	PTJ61005848	FROST HOLDER A (BOM#32)
33	PTJ31000243B	ZOOM SLIDER BAR A (BOM#33)
34	PTJ21001106	HALL ELEMENT POSITIONING PLATE (BOM#34)
35	PTJ32100040	STAND OFF (BOM#35)
36	PTJ32500075A	PRISM TORSION SPRING (BOM#36)
37	PTJ32100347	FROST POSITIONING MAST A (BOM#37)
38	PTJ31000589	FOCUSING HOLDER (BOM#38)
39	PTJ34100075	TINGLE FOR POWER CABLE (BOM#39)
40	PTJ32300240	FOCUSING LENS ASSEMBLY (BOM#40)
41	PTJ31001171	ZOOM BEARING ASSEMBLY B (BOM#41)
42	PTJ31000572	SLIDER BAR HOLDER B (BOM#42)
43	PTJ61008881	FRONT MAIN SUPPORT PLATE (BOM#43)
44	PTJ61103633	SLIDER BAR STIFFENING PLATE (BOM#44)
45	PTJ31000024A	SLIDING BEARING (BOM#45)
46	PTJ33100151	MOTOR-PRISM ROTATION (BOM#46)
47	PTJ33100146	MOTOR-PRISM REVOLUTION (BOM#47)
48	PTJ33100147	MOTOR-FROST (BOM#48)
49	PTJ32400118	ZOOM TIMING BELT (BOM#49)
50	PTJ31000335A	ZOOM SLIDER WHEEL (BOM#50)
51	PTJ32100303	ZOOM SLIDER WHEEL STANDOFF (BOM#51)
52	PTJ32001362	FLEECE RING (BOM#52)
53	PTJ61108133A	SLIDER BAR HOLDER (BOM#53)

54	PTJ32600023	RUBBER RING (BOM#54)
55	PTJ61108135A	RIGHT FRONT HEAD HOLDER (BOM#55)
56	PTJ32600021	RUBBER RING (BOM#56)
57	PTJ34100119	THREAD TAPE HOLDER (BOM#57)
58	PTJ33100169	STEPPER MOTOR (BOM#58)
59	PTJ61102730	FOCUSING BELT ADJUSTING PLATE (BOM#59)
60	PTJ32100272	FOCUS SLIDER WHEEL STANDOFF (BOM#60)
61	PTJ32400045	PRISM TIMING BELT (BOM#61)
62	PTJ61108136A	LEFT FRONT HEAD HOLDER (BOM#62)
63	PTJ21003981	HALL ELEMENT LOCATER FOR ZOOM (BOM#63)
64	PTJ21001130D	ZOOM MOTOR DRIVE PCB (BOM#64)
65	PTJ61103634A	PCB HOLDER FOR FRONT HEAD (BOM#65)
66	PTJ32000873	FLEECE RING (BOM#66)
67	PTJ31001226	GOBOS SHUTTER MODULES (BOM#67)
68	PTJ31000112	IRIS DRIVING WHEEL (BOM#68)
69	PTJ61103638	MOTOR PLATE (BOM#69)
70	PTJ32100276	FIXATION FOR MAGNET (BOM#70)
71	PTJ39900056	MAGNET (BOM#71)
72	PTJ32100275	LOCATOR FOR ROTATINIG DISK (BOM#72)
73	PTJ33100188	MOTOR-IRIS (BOM#73)
74	PTJ33100145	STEPPER MOTOR (BOM#74)
75 76	PTJ33100167	MOTOR (BOM#75)
76	PTJ31000118	DRIVE WHEEL (BOM#76)
77 70	PTJ31000414	BEARING ASSEMBLY FOR ROTATINIG DISK (BOM#77)
78 70	PTJ61102292	LEFT FAST-LOCK BUCKLE (BOM#78)
79 80	PTJ61103639	HOLDER (BOM#79) THREAD TAPE HOLDER (BOM#80)
81	PTJ34100044 PTJ61102735	RIGHT FAST-LOCK BUCKLE (BOM#81)
82	PTJ61102733	SHUTTER DB HEAD HOLDER (BOM#82)
83	PTJ31000124	DRIVEN GEAR FOR ROTATINIG DISK (BOM#83)
84	PTJ32400101	TIMING BELT (BOM#84)
85	PTJ32700076	MYLAR (BOM#85)
86	PTJ21003972B	SHUTTER MOTOR DRIVE PCB (BOM#86)
87	PTJ39900058	MAGNET (BOM#87)
88	PTJ39900063	MAGNET (BOM#88)
89	PTJ31001224	ROTATION GOBOS WHEEL (BOM#89)
92	PTJ32400119	HODER WHEEL TIMING BELT (BOM#92)
93	PTJ32400078	COLOR WHEEL TIMING BELT (BOM#93)
94	PTJ31000382	SPOT FLANGE ASSEMBLY (BOM#94)
95	PTJ31000566	SPOT PULLEY (BOM#95)
96	PTJ31000565	SPOT SILDING BEARING (BOM#96)
97	PTJ32400098	RSPOT TIMING BELT (BOM#97)
98	PTJ32400080	RSPOT TIMING BELT B (BOM#98)
99	PTJ61103061	SPOT SUPPORT PLATE (BOM#99)
100	PTJ31000383A	ROTATION FLANGE ASSEMBLY (BOM#100)
101	PTJ61103066	GOBOS (BOM#101)
102	PTJ61003650	SPOT PRESSING PLATE (BOM#102)
104	PTJ61004626A	COLOR WHEEL (BOM#104)
105	PTJ31000048	COLOR WHEEL FLANGE (BOM#105)
106	PTJ32300239	LENS ASSEMBLY (BOM#106)
107	PTJ61102735	RIGHT FAST-LOCK BUCKLE (BOM#107)
108	PTJ32100075	STAND OFF (BOM#108)
109	PTJ21001305	HALL ELEMENT TESTING BOARD (BOM#109)
110	PTJ21001303	HALL ELEMENT TESTING BOARD B (BOM#110)
111	PTJ31000127	DRIVING WHEEL FOR HODER WHEEL (BOM#111)
112	PTJ31000413	SLIDING WHEEL ASSEMBLY FOR GOBOS (BOM#112)

113	PTJ31000128	DRIVING WHEEL FOR ROTARY (BOM#113)
114	PTJ31000106	ROTATION DRIVING WHEEL FOR GOBOS (BOM#114)
115	PTJ32100349	SPOT POSITIONING PIN (BOM#115)
116	PTJ21001306A	HALL ELEMENT TESTING BOARD (BOM#116)
117	PTJ61102292	LEFT FAST-LOCK BUCKLE (BOM#117)
118	PTJ61103740B	MOTOR PLATE FOR GOBOS (BOM#118)
119	PTJ32700075	MYLAR FOR GOBOS (BOM#119)
120	PTJ21001133A	MOTOR ADAPTER PCB FOR GOBOS (BOM#120)
121	PTJ33100165	STEPPER MOTOR FOR ANIMATION WHEEL (BOM#121)
122	PTJ33100166	STEPPER MOTOR FOR COLOR WHEEL (BOM#122)
123	PTJ33100097B	STEPPER MOTOR FOR ROTATING WHEEL AND ANIMATION WHEEL (BOM#123)
124	PTJ33100181B	STEPPER MOTOR FOR GOBOS WHEEL (BOM#124)
125	PTJ33100091	STEPPER MOTOR FOR STATIC WHEEL (BOM#125)
126	PTJ61004624	WIRES HOLDER FOR GOBOS (BOM#126)
127	PTJ32200496	OPTICAL RING FOR GOBOS (BOM#127)
128	PTJ61103624	CMY COVER (BOM#128)
129	PTJ32100255	HEX STANDOFF (BOM#129)
130	PTJ32400115	CMY TIMING BELT (BOM#130)
131	PTJ31000340	CMY SLIDER WHEEL (BOM#131)
132	PTJ31000107	CMY BELT PULLEY (BOM#132)
133	PTJ32100204	SLIDER WHEEL C (BOM#133)
134	PTJ32100205	SLIDER WHEEL D (BOM#134)
135	PTJ32100203	SLIDER WHEEL A (BOM#135)
136	PTJ32100248	SLIDER WHEEL B (BOM#136)
137	PTJ31000851A	CMY SLIDER A (BOM#137)
138	PTJ31000853A	CMY SLIDER C (BOM#138)
139	PTJ31000852A	CMY SLIDER B (BOM#139)
140	PTJ31000854A	CMY SLIDER D (BOM#140)
141	PTJ32202464A	CYAN COLOR FILTER (BOM#141)
142	PTJ32202465A	MAGENTA COLOR FILTER (BOM#142)
143	PTJ32202466A	YELLOW COLOR FILTER (BOM#143)
144	PTJ32202463A	CTO COLOR FILTER (BOM#144)
145	PTJ61102715 PTJ61102716	CMY SLIDER BAR HOLDER A (BOM#145)
146 147	PTJ32500076	CMY SLIDER BAR HOLDER B (BOM#146) E TYPE CLAMP SPRING (BOM#147)
147	PTJ31001222	CMY SLIDER BAR (BOM#148)
149	PTJ32000940	METAL BUCKLE (BOM#149)
150	PTJ32100248	SLIDER WHEEL B (BOM#150)
151	PTJ39900042	TRAVEL SWITCH (BOM#151)
152	PTJ32100200	POSITIONING STAND OFF A (BOM#152)
153	PTJ32100200	POSITIONING STAND OFF C (BOM#153)
154	PTJ32100201	POSITIONING STAND OFF D (BOM#154)
155	PTJ61103622	CMY DRIVE MOTOR BOARD (BOM#155)
156	PTJ61102292	LEFT FAST-LOCK BUCKLE (BOM#156)
157	PTJ61102735	RIGHT FAST-LOCK BUCKLE (BOM#157)
158	PTJ61003140	MOTOR SUBPLATE (BOM#158)
159	PTJ33100151A	MOTOR-PRISM ROTATION (BOM#159)
160	PTJ32700073	CMY MYLAR (BOM#160)
161	PTJ21001135	CMY ADAPTER PLATE (BOM#161)
162	PTJ32700085A	MYLAR (BOM#162)
163	PTJ61108138	LEFT HEAD HOLDER (BOM#163)
164	PTJ31000518	LOCATING PIN (BOM#164)
165	PTJ31000155	MODULE SLIDER (BOM#165)
166	PTJ32000940	METAL BUCKLE (BOM#166)
167	PTJ61004605	DRIVE MOTOR HOLDER (BOM#167)
168	PTJ21003969	DRIVE PCB FOR HEAD (BOM#168)

4.60	DT1C4400427	DIGUT HEAD HOLDED (DOLAHAGO)
169	PTJ61108137	RIGHT HEAD HOLDER (BOM#169)
170	PTJ34100075	TINGLE FOR POWER CABLE (BOM#170)
171	PTJ61103650	BARN DOOR (BOM#171)
172	PTJ61108139	MAIN SUPPORT PLATE FOR HEAD (BOM#172)
173	PTJ32100344	CONNECTOR (BOM#173)
174	PTJ61103644	HEAD HOLDER STIFFENING PLATE (BOM#174)
175	PTJ32100345	REAR STAND OFF (BOM#175)
176	PTJ32300238	LENS ASSEMBLY (BOM#176)
177	PTJ32600303	SILICONE RING FOR LENS (BOM#177)
178	PTJ32700074 PTJ21003974	MYLAR (BOM#178)
179 180	PTJ21003974 PTJ21003975	LED PCB (BOM#179) DRIVE PCB A (BOM#180)
181	PTJ21003975 PTJ21003976	DRIVE PCB A (BOM#180) DRIVE PCB B (BOM#181)
182	PTJ61103654	HEAT SINK (BOM#182)
183	PTJ62100211	ANTI-LOOSENING RUBBER SLEEVE (BOM#183)
184	PTJ62000517	REAR COVER FOR HEAD (BOM#184)
185	PTJ32000317 PTJ32000778	BM WAISTED SHANK SCREW (BOM#185)
186	PTJ326000778	SILICA LOOP (BOM#186)
187	PTJ6200053	FRONT COVER FOR HEAD (BOM#187)
188	PTJ32000320A PTJ32000939	BOLT (BOM#188)
189	PTJ62000535	REAR SIDE COVER FOR HEAD (BOM#189)
190	PTJ62000518A	FRONT SIDE COVER FOR HEAD (BOM#199)
191	PTJ34100041	SAFETY ROPE (BOM#191)
192	PTJ32700032A	MYLAR (BOM#192)
193	PTJ32000778	BM WAISTED SHANK SCREW (BOM#193)
194	PTJ62000516A	RIGHT ARM COVER (BOM#194)
195	PTJ62100211	ANTI-LOOSENING RUBBER SLEEVE (BOM#195)
196	PTJ61102708A	FIXING PLATE FOR ARM COVER (BOM#196)
197	PTJ32500008	TENSION SPRING (BOM#197)
198	PTJ32100208A	SPRING HOLDER (BOM#198)
199	PTJ31000129A	PAN/TILT DRIVE WHEEL (BOM#199)
200	PTJ61102312A	TILT DRIVE MOTOR BOARD (BOM#200)
201	PTJ33100168	STEPPER MOTOR (BOM#201)
202	PTJ21001548	PAN/TILT MAGNETIC POSITIONING PLATE (BOM#202)
203	PTJ62100212	HANDLE SHEATH (BOM#203)
204	PTJ61103032	TILT LOCK (BOM#204)
205	PTJ31000208	BALL (BOM#205)
206	PTJ61003162	STOPPER (BOM#206)
207	PTJ31000188	FAST-LOCK HOLDER (BOM#207)
208	PTJ31000187A	FAST-LOCK SLIDER (BOM#208)
209	PTJ32000288	CM SCREW (BOM#209)
210	PTJ32000908	ELASTIC MEDIUM (BOM#210)
211	PTJ32400116	TILT TIMING BELT (BOM#211)
212	PTJ31000417	TILT GEAR ASSEMBLY (BOM#212)
213	PTJ31000420	DAMP ASSEMBLY (BOM#213)
214	PTJ61102306A	TILT STOPPER (BOM#214)
215	PTJ61103649	TILT LIMITE PLATE (BOM#215)
216	PTJ61004596	CARD FOR ARM COVER (BOM#216)
217	PTJ61104367	SUPPORT PLATE FOR GEAR ASSEMBLY (BOM#217)
218	PTJ61103627B	INNER ARM COVER (BOM#218)
219	PTJ31000418	TILT LEAD ASSEMBLY (BOM#219)
220	PTJ61104366C	THREADED SUPPORT PLATE (BOM#220)
221	PTJ61104185	THREADED CONNECTING PLATE (BOM#221)
222	PTJ39900058	MAGNET (BOM#222)
223	PTJ21001105A	HALL ELEMENT POSITIONING PLATE A (BOM#223)
224	PTJ61003169	TILT BUNDLE CABLE PLATE (BOM#224)

233 PTJ21000993 HALL ELEMENT FOR PAN (BOM#234) 234 PTJ32100011 SPACER SUPPORT (BOM#234) 235 PTJ32000801 CM SCREW (BOM#235) 236 PTJ39900056 MAGNET (BOM#236) 237 PTJ61101746 SEPARATION BLADE (BOM#237) 238 PTJ32100080 POSITIONING PLUNGER (BOM#238) 239 PTJ31010225 PAN GEAR ASSEMBLY (BOM#239) 240 PTJ61103218A PAN STOPPER (BOM#240) 241 PTJ61103623 PAN LOCK (BOM#241) 242 PTJ611032311 PAN DRIVE MOTOR BOARD (BOM#242) 243 PTJ32400120 PAN TIMING BELT (BOM#243) 244 PTJ34000115A THERMAL PADS (BOM#244) 245 PTJ62000660 WIRE COVER (BOM#245) 246 PTJ32000346 LOCKNUT (BOM#246) 247 PTJ32000381 LOCKING WASHER (BOM#247) 248 PTJ61103632A SUPPORT PLATE FOE BASE (BOM#248) 249 PTJ32100210 STAND OFF FOR BASE (BOM#248) 250 PTJ21003878A ETHERNET PCB (BOM#250) 251 PTJ33000506A POWER SUPPLY (BOM#251) 252 PTJ61103630A STIFFENING PLATE FOR BASE (BOM#252) 253 PTJ61108243 BASE (BOM#253) 254 PTJ3260003B FOOT (BOM#253) 255 PTJ61108817 LOCKING PLATE (BOM#256) 257 PTJ3200089A HM SCREW (BOM#255) 258 PTJ61108817 LOCKING PLATE (BOM#256) 260 PTJ61103752 ANTENNA (BOM#259) 261 PTJ62000590 ANTENNA (BOM#259) 262 PTJ61103642 ANTENNA (BOM#259) 263 PTJ62000907A ANTENNA (BOM#256) 264 PTJ61103571A POWER SUPPLY (BOM#266) 265 PTJ33300053 IP POWER RIVING PLATE (BOM#266) 266 PTJ61103641 HEAT SINK NALY (BOM#266) 267 PTJ33300050 FUSE HANDLE SINK NALY (BOM#266) 268 PTJ21004726 ETHERNET CONNECTOR (BOM#266) 269 PTJ21003733 DMX XLR SOCKET (BOM#266) 270 PTJ61103641 HEAT SINK NET (BOM#267) 271 PTJ61103640 HEAT SINK NET (BOM#277) 272 PTJ61103625 HANDLE SUPPORT PLATE (BOM#267) 273 PTJ61103626 HANDLE SUPPORT PLATE (BOM#277) 274 PTJ61100311 BMCB (BOM#275) 275 PTJ62000514A BASE COVER (BOM#275) 276 PTJ21003971B MPCB (BOM#275) 277 PTJ62100111 BUTTON COVER (BOM#277) 278 PTJ62000111 BUTTON COVER (BOM#277) 278 PTJ62000111 BUTTON COVER (BOM#277)	226 PTI61103628 CLUMP WEIGHT FOR ARM (BOM#226) 227 PTI62000515A LEFT ARM COVER (BOM#227) 228 PTI62000512A FRONT ARM COVER (BOM#228) 230 PTI61004599A MAIN SUPPORT PLATE FOR ARM (BOM#230) 231 PTI61101584B X HALL ELEMENT FOR POSITIONING PLATE (BOM#232) 233 PTI21000993 HALL ELEMENT FOR POSITIONING PLATE (BOM#233) 234 PTI32100011 SPACER SUPPORT (BOM#234) 235 PTI322000801 CM SCREW (BOM#235) 236 PTI39900056 MAGNET (BOM#236) 237 PTI61101746 SEPARATION BLADE (BOM#237) 238 PTI32100080 POSITIONING PLUNCER (BOM#237) 239 PTI31001225 PAN GEAR ASSEMBLY (BOM#239) 240 PTI61102318A PAN STOPPER (BOM#240) 241 PTI61103623 PAN STOPPER (BOM#241) 242 PTI9161002311 PAN DRIVE MOTOR BOARD (BOM#242) 243 PTI32400120 PAN TIMING BELT (BOM#243) 244 PTI32000346 LOCKNUT (BOM#245) 245 PTI62000660 WIRE COVER (BOM#246)			
PTI62000515A	PTI62000515A	225	PTJ21003968A	PAN/TILT STEP MOTOR DRIVER (BOM#225)
PTI62000512A FRONT ARM COVER (BOM#228)	PTIGEODOS12A FRONT ARM COVER (BOM#228)	226	PTJ61103628	•
229 PTJ62000513A REAR ARM COVER (BOM#229) 230 PTJ61004599A MAIN SUPPORT PLATE FOR ARM (BOM#230) 231 PTJ61103647A SPINDLE HOLDER (BOM#231) 232 PTJ61101584B X HALL ELEMENT PAN POSITIONING PLATE (BOM#2. 233 PTJ21000993 HALL ELEMENT FOR PAN (BOM#2.33) 234 PTJ32100011 SPACER SUPPORT (BOM#2.34) 235 PTJ32000801 CM SCREW (BOM#2.35) 236 PTJ39900056 MAGNET (BOM#2.36) 237 PTJ61101746 SEPARATION BLADE (BOM#2.37) 238 PTJ32100080 POSITIONING PLUNGER (BOM#2.38) 239 PTJ31001225 PAN GEAR ASSEMBLY (BOM#2.39) 240 PTJ61102318A PAN STOPPER (BOM#2.40) 241 PTJ61103623 PAN IOCK (BOM#2.41) 242 PTJ61102311 PAN DRIVE MOTOR BOARD (BOM#2.42) 243 PTJ32400120 PAN TIMING BELT (BOM#2.43) 244 PTJ34000115A THERMAL PADS (BOM#2.44) 245 PTJ62000660 WIRE COVER (BOM#2.45) 246 PTJ32000346 LOCKNUT (BOM#2.45) 247 PTJ32000346 LOCKNUT (BOM#2.46) 248 PTJ61103632A SUPPORT PLATE FOE BASE (BOM#2.48) 249 PTJ32100210 STAND OFF FOR BASE (BOM#2.49) 250 PTJ21003878A ETHERNET PCB (BOM#2.49) 251 PTJ33000506A POWER SUPPLY (BOM#2.51) 252 PTJ61103630A STIFFENING PLATE FOR BASE (BOM#2.49) 253 PTJ611082.43 BASE (BOM#2.53) 254 PTJ62000089 FOOT (BOM#2.53) 255 PTJ6110818 ORGER SUPPLY (BOM#2.55) 256 PTJ61108817 LOCKING PLATE FOR BASE (BOM#2.50) 257 PTJ6100841 BASE (BOM#2.53) 258 PTJ61108418 OMEGA BARCKET (BOM#2.55) 259 PTJ61000364 LOCKING PLATE (BOM#2.56) 260 PTJ61103571A POWER SUPPLY (BOM#2.56) 261 PTJ62000090 ANTENNA HOLDER (BOM#2.66) 262 PTJ61103571A POWER SOCKET PLATE (BOM#2.66) 263 PTJ62000097 ANTENNA HOLDER (BOM#2.66) 264 PTJ61103642 ANTENNA FIXING PLATE (BOM#2.66) 265 PTJ63000036 POWER SOCKET PLATE (BOM#2.65) 266 PTJ6100364 ANTENNA SOCKET (BOM#2.67) 270 PTJ61103640 HEAT SINK NET HOLDER (BOM#2.67) 271 PTJ61103641 HEAT SINK NET HOLDER (BOM#2.67) 272 PTJ61103640 HEAT SINK NET HOLDER (BOM#2.77) 273 PTJ61103621 HANDLE SUPPORT PLATE-RIGHT (BOM#2.73) 274 PTJ62000511A HANDLE (BOM#2.75) 275 PTJ62000511A HANDLE (BOM#2.75) 276 PTJ62000511A HANDLE (BOM#2.75)	PTI62000513A REAR ARM COVER (BOM#229)	227	PTJ62000515A	LEFT ARM COVER (BOM#227)
230 PTI61004599A MAIN SUPPORT PLATE FOR ARM (BOM#230) 231 PTI611013647A SPINDLE HOLDER (BOM#231) 232 PTI61101384B X HALL ELEMENT PAN POSTITONING PLATE (BOM#23 233 PTI21000993 HALL ELEMENT FOR PAN (BOM#233) 234 PTI32100011 SPACER SUPPORT (BOM#234) 235 PTI32000801 CM SCREW (BOM#235) 236 PTI39900056 MAGNET (BOM#236) 237 PTI61101746 SEPARATION BLADE (BOM#237) 238 PTI32100080 POSITIONING PLUNGER (BOM#238) 239 PTI31001225 PAN GEAR ASSEMBLY (BOM#238) 240 PTI61102311A PAN STOPPER (BOM#240) 241 PTI61103623 PAN LOCK (BOM#241) 242 PTI61103211 PAN DRIVE MOTOR BOARD (BOM#242) 243 PTI32400120 PAN TIMING BELT (BOM#243) 244 PTI34000115A THERMAL PADS (BOM#244) 245 PTI62000660 WIRE COVER (BOM#245) 246 PTI32000346 LOCKNUT (BOM#245) 247 PTI32000381 LOCKING WASHER (BOM#247) 248 PTI3100311 STAND OFF FOR BASE (BOM#249) 250 PTI21003878A ETHERNET PCB (BOM#250) 251 PTI310630A STIFFENING PLATE FOR BASE (BOM#252) 252 PTI61108630A STIFFENING PLATE FOR BASE (BOM#252) 253 PTI61108243 BASE (BOM#253) 254 PTI32600003B FOOT (BOM#254) 255 PTI61108817 LOCKING PLATE FOR BASE (BOM#252) 256 PTI61108817 LOCKING PLATE (BOM#256) 257 PTI32000809A HM SCREW (BOM#258) 259 PTI7200076 ANTENNA (BOM#259) 260 PTI61103571A POWER SOCKET (BOM#261) 261 PTI62000590 ANTENNA HOLDER (BOM#263) 262 PTI61103642 ANTENNA HOLDER (BOM#264) 263 PTI62000097A ANTENNA HOLDER (BOM#264) 265 PTI33300062 FUSE HOLDER (BOM#266) 266 PTI61103642 ANTENNA SNAP (BOM#263) 267 PTI33300062 FUSE HOLDER (BOM#266) 268 PTI121001426 ETHERNET CONNECTOR (BOM#266) 279 PTI36100371A POWER SOCKET PLATE (BOM#266) 270 PTI61103644 HEAT SINK NET (BOM#267) 271 PTI61103640 HEAT SINK NET (BOM#277) 272 PTI61103646 HAD SINK NET (BOM#277) 273 PTI61103647 HAD SINK NET (BOM#277) 274 PTI61000511A HANDLE (BOM#277) 275 PTI62000511A HANDLE SUPPORT PLATE-LEFT (BOM#272) 276 PTI21000371B MPCB (BOM#275) 277 PTI61100311 BUTTON COVER (BOM#277) 278 PTI61200092 FRONT BASE COVER (BOM#277)	PTJ61004599A	228	PTJ62000512A	, ,
231 PTI61103647A SPINDLE HOLDER (BOM#231) 232 PTI61101584B X HALL ELEMENT PAN POSITIONING PLATE (BOM#2: 233 PTI21000993 HALL ELEMENT FOR PAN (BOM#233) 234 PTI32100011 SPACER SUPPORT (BOM#234) 235 PTI32000801 CM SCREW (BOM#236) 237 PTI61101746 SEPARATION BLADE (BOM#236) 238 PTI32100080 POSITIONING PLUNGER (BOM#237) 238 PTI32100080 POSITIONING PLUNGER (BOM#238) 239 PTI31011225 PAN GEAR ASSEMBLY (BOM#239) 240 PTI61102311A PAN STOPPER (BOM#240) 241 PTI61103623 PAN LOCK (BOM#241) 242 PTI61102311 PAN DRIVE MOTOR BOARD (BOM#242) 243 PTI32400120 PAN TIMING BELT (BOM#243) 244 PTI344000115A THERMAL PADS (BOM#244) 245 PTI62000660 WIRE COVER (BOM#245) 246 PTI32000346 LOCKNUT (BOM#246) 247 PTI32000341 LOCKING WASHER (BOM#247) 248 PTI61103632A SUPPORT PLATE FOE BASE (BOM#248) 249 PTI32100210 STAND OFF FOR BASE (BOM#249) 250 PTI21003878A ETHERNET PCB (BOM#250) 251 PTI33000506A POWER SUPPLY (BOM#250) 252 PTI6110630A STIFFENING PLATE FOR BASE (BOM#252) 253 PTI61108243 BASE (BOM#253) 254 PTI36100038 FOOT (BOM#255) 255 PTI61106103 CLAMP LOCK (BOM#255) 256 PTI61108817 LOCKING PLATE FOR BASE (BOM#255) 256 PTI61108817 LOCKING PLATE (BOM#255) 257 PTI3200009A HM SCREW (BOM#257) 258 PTI6110813 CLAMP LOCK (BOM#257) 259 PTI7200076 ANTENNA (BOM#257) 260 PTI61103642 ANTENNA (BOM#256) 261 PTI62000590 ANTENNA HOLDER (BOM#266) 262 PTI61103642 ANTENNA SUPPORT PLATE (BOM#260) 263 PTI62000590 ANTENNA HOLDER (BOM#264) 264 PTI61103771A POWER SOCKET PLATE (BOM#262) 265 PTI33300053 IP POWER IN/OUT SOCKET (BOM#265) 266 PTI61103640 HEAT SINK NET HOLDER (BOM#264) 270 PTI61103640 HEAT SINK NET HOLDER (BOM#270) 271 PTI61103640 HEAT SINK NET HOLDER (BOM#271) 272 PTI61103640 HEAT SINK NET HOLDER (BOM#272) 273 PTI61103640 HEAT SINK NET HOLDER (BOM#272) 274 PTI62000511A HANDLE SUPPORT PLATE (BOM#272) 275 PTI62000511A HANDLE SUPPORT PLATE REGHT (BOM#272) 276 PTI21003971B MPCB (BOM#275) 277 PTI62100311 BUTTON COVER (BOM#277) 278 PTI62000511 HANDLE SUPPORT PLATE-REGHT (BOM#272)	PTJ61103647A SPINDLE HOLDER (BOM#231)	229	PTJ62000513A	REAR ARM COVER (BOM#229)
232	PTJ61101584B	230	PTJ61004599A	MAIN SUPPORT PLATE FOR ARM (BOM#230)
233 PTJ21000993 HALL ELEMENT FOR PAN (BOM#234) 234 PTJ32100011 SPACER SUPPORT (BOM#234) 235 PTJ32000801 CM SCREW (BOM#235) 236 PTJ39900056 MAGNET (BOM#236) 237 PTJ61101746 SEPARATION BLADE (BOM#237) 238 PTJ32100080 POSITIONING PLUNGER (BOM#238) 239 PTJ31010225 PAN GEAR ASSEMBLY (BOM#239) 240 PTJ61103218A PAN STOPPER (BOM#240) 241 PTJ61103623 PAN LOCK (BOM#241) 242 PTJ611032311 PAN DRIVE MOTOR BOARD (BOM#242) 243 PTJ32400120 PAN TIMING BELT (BOM#243) 244 PTJ34000115A THERMAL PADS (BOM#244) 245 PTJ62000660 WIRE COVER (BOM#245) 246 PTJ32000346 LOCKNUT (BOM#246) 247 PTJ32000381 LOCKING WASHER (BOM#247) 248 PTJ61103632A SUPPORT PLATE FOE BASE (BOM#248) 249 PTJ32100210 STAND OFF FOR BASE (BOM#248) 250 PTJ21003878A ETHERNET PCB (BOM#250) 251 PTJ33000506A POWER SUPPLY (BOM#251) 252 PTJ61103630A STIFFENING PLATE FOR BASE (BOM#252) 253 PTJ61108243 BASE (BOM#253) 254 PTJ3260003B FOOT (BOM#253) 255 PTJ61108817 LOCKING PLATE (BOM#256) 257 PTJ3200089A HM SCREW (BOM#255) 258 PTJ61108817 LOCKING PLATE (BOM#256) 260 PTJ61103752 ANTENNA (BOM#259) 261 PTJ62000590 ANTENNA (BOM#259) 262 PTJ61103642 ANTENNA (BOM#259) 263 PTJ62000907A ANTENNA (BOM#256) 264 PTJ61103571A POWER SUPPLY (BOM#266) 265 PTJ33300053 IP POWER RIVING PLATE (BOM#266) 266 PTJ61103641 HEAT SINK NALY (BOM#266) 267 PTJ33300050 FUSE HANDLE SINK NALY (BOM#266) 268 PTJ21004726 ETHERNET CONNECTOR (BOM#266) 269 PTJ21003733 DMX XLR SOCKET (BOM#266) 270 PTJ61103641 HEAT SINK NET (BOM#267) 271 PTJ61103640 HEAT SINK NET (BOM#277) 272 PTJ61103625 HANDLE SUPPORT PLATE (BOM#267) 273 PTJ61103626 HANDLE SUPPORT PLATE (BOM#277) 274 PTJ61100311 BMCB (BOM#275) 275 PTJ62000514A BASE COVER (BOM#275) 276 PTJ21003971B MPCB (BOM#275) 277 PTJ62100111 BUTTON COVER (BOM#277) 278 PTJ62000111 BUTTON COVER (BOM#277) 278 PTJ62000111 BUTTON COVER (BOM#277)	PTJ21000993	231	PTJ61103647A	
234 PTJ32100011 SPACER SUPPORT (BOM#234) 235 PTJ32000801 CM SCREW (BOM#235) 236 PTJ39900056 MAGNET (BOM#236) 237 PTJ61101746 SEPARATION BLADE (BOM#237) 238 PTJ32100080 POSITIONING PLUNGER (BOM#238) 239 PTJ31001225 PAN GEAR ASSEMBLY (BOM#239) 240 PTJ61102311A PAN STOPPER (BOM#240) 241 PTJ61103623 PAN LOCK (BOM#241) 242 PTJ61102311 PAN DRIVE MOTOR BOARD (BOM#242) 243 PTJ32400120 PAN TIMING BELT (BOM#243) 244 PTJ34000115A THERMAL PADS (BOM#244) 245 PTJ62000660 WIRE COVER (BOM#245) 246 PTJ32000346 LOCKNUT (BOM#246) 247 PTJ32000346 LOCKNUT (BOM#246) 249 PTJ32100210 STAND OFF FOR BASE (BOM#247) 248 PTJ61103632A SUPPORT PLATE FOB BASE (BOM#248) 250 PTJ21003878A ETHERNET PCB (BOM#250) 251 PTJ33000506A POWER SUPPLY (BOM#251) 252 PTJ61103630A STIFFENING PLATE FOR BASE (BOM#252) 253 PTJ61108243 BASE (BOM#254) 255 PTJ6110813 CLAMP LOCK (BOM#255) 256 PTJ6110817 LOCKING PLATE (BOM#255) 257 PTJ32000099A HM SCREW (BOM#257) 258 PTJ6110818 OMEGA BRACKET (BOM#250) 259 PTJ72000076 ANTENNA (BOM#259) 260 PTJ61101752 ANTENNA (BOM#259) 261 PTJ6200099A ANTENNA (BOM#259) 262 PTJ61103642 ANTENNA (BOM#259) 263 PTJ6200099A ANTENNA (BOM#259) 264 PTJ61103571A POWER SUPPORT PLATE (BOM#260) 265 PTJ33300053 IP POWER NING PLATE (BOM#264) 266 PTJ61103571A POWER SUPPORT PLATE (BOM#266) 267 PTJ33300052 FUSE HOLDER (BOM#267) 268 PTJ61103641 HEAT SINK NET (BOM#267) 279 PTJ61103640 HEAT SINK NET (BOM#267) 270 PTJ61103641 HEAT SINK NET (BOM#267) 271 PTJ61103640 HEAT SINK NET (BOM#267) 272 PTJ61103641 HEAT SINK NET (BOM#267) 273 PTJ61103625 HANDLE SUPPORT PLATE (BOM#267) 274 PTJ61103640 HEAT SINK NET (BOM#277) 275 PTJ61000514A BASE COVER (BOM#277) 276 PTJ62000514A BASE COVER (BOM#277) 277 PTJ621000111 BUTTON COVER (BOM#277) 278 PTJ6200051 FROM PLATE SINCH PLATE GROM#277) 278 PTJ6200051 FROM PLATE SINCH BUTTON COVER (BOM#277) 277 PTJ62100111 BUTTON COVER (BOM#277) 278 PTJ6200051 FROM PLATE SINCH PLATE GROM#277) 278 PTJ6200051 FROM PLATE SINCH PLATE GROM#277) 278 PTJ6200051 FROM PLATE SINCH PLATE SIGHT (BOM#278)	PTJ32100011 SPACER SUPPORT (BOM#234)	232	PTJ61101584B	X HALL ELEMENT PAN POSITIONING PLATE (BOM#232)
235 PTJ32000801 CM SCREW (BOM#235) 236 PTJ39900056 MAGNET (BOM#236) 237 PTI61101746 SEPARATION BLADE (BOM#237) 238 PTJ32100080 POSITIONING PLUNGER (BOM#238) 239 PTJ31001225 PAN GEAR ASSEMBLY (BOM#239) 240 PTJ61102318A PAN STOPPER (BOM#240) 241 PTJ61103623 PAN LOCK (BOM#241) 242 PTJ61102311 PAN DRIVE MOTOR BOARD (BOM#242) 243 PTJ32400120 PAN TIMING BELT (BOM#243) 244 PTJ34000115A THERMAL PADS (BOM#244) 245 PTJ62000660 WIRE COVER (BOM#245) 246 PTJ32000346 LOCKNUT (BOM#246) 247 PTJ32000381 LOCKING WASHER (BOM#247) 248 PTJ61103632A SUPPORT PLATE FOE BASE (BOM#248) 249 PTJ32100210 STAND OFF FOR BASE (BOM#249) 250 PTJ21003878A ETHERNET PCB (BOM#250) 251 PTJ33000506A POWER SUPPLY (BOM#251) 252 PTJ61103630A STIFFENING PLATE FOR BASE (BOM#252) 253 PTJ61108243 BASE (BOM#253) 254 PTJ32600003B FOOT (BOM#254) 255 PTJ61108817 LOCKING PLATE FOR BASE (BOM#255) 256 PTJ61108817 LOCKING PLATE (BOM#255) 257 PTJ32000809A HM SCREW (BOM#255) 258 PTJ61108181 OMEGA BRACKET (BOM#259) 260 PTJ6110752 ANTENNA (BOM#259) 260 PTJ6110752 ANTENNA (BOM#259) 261 PTJ62000590 ANTENNA (BOM#259) 262 PTJ61103642 ANTENNA (BOM#256) 263 PTJ62000990 ANTENNA HOLDER (BOM#261) 264 PTJ6100371A POWER SOCKET PLATE (BOM#262) 265 PTJ33300053 IP POWER NAPPORT PLATE (BOM#262) 266 PTJ61103642 ANTENNA SNAP (BOM#263) 267 PTJ33300062 FUSE HOLDER (BOM#263) 268 PTJ21001426 ETHERNET CONNECTOR (BOM#265) 269 PTJ21003733 DMX XLR SOCKET (BOM#266) 267 PTJ33300062 FUSE HOLDER (BOM#270) 271 PTJ61103640 HEAT SINK NET (HOLDER (BOM#272) 273 PTJ61103641 HEAT SINK NET HOLDER (BOM#272) 274 PTJ62000511A HANDLE SUPPORT PLATE-EIGT (BOM#272) 275 PTJ62000511A HANDLE SUPPORT PLATE-EIGT (BOM#273) 276 PTJ1200371B MPCB (BOM#277) 277 PTJ62100111 BUTTON COVER (BOM#278)	235 PTJ32000801 CM SCREW (BOM#235) 236 PTJ39900056 MAGNET (BOM#236) 237 PTJ61101746 SEPARATION BLADE (BOM#237) 238 PTJ32100080 POSITIONING PLUNGER (BOM#238) 239 PTJ31001225 PAN GEAR ASSEMBLY (BOM#239) 240 PTJ61102318A PAN STOPPER (BOM#240) 241 PTJ61103623 PAN LOCK (BOM#241) 242 PTJ61102311 PAN DRIVE MOTOR BOARD (BOM#242) 243 PTJ32400120 PAN TIMING BELT (BOM#243) 244 PTJ34000115A THERMAL PADS (BOM#244) 245 PTJ62000660 WIRE COVER (BOM#245) 246 PTJ32000346 LOCKNUT (BOM#246) 247 PTJ32000381 LOCKING WASHER (BOM#247) 248 PTJ61103632A SUPPORT PLATE FOE BASE (BOM#248) 250 PTJ21003878A ETHERNET PCB (BOM#250) 251 PTJ33000506A POWER SUPPLY (BOM#251) 252 PTJ61103630A STIFFENING PLATE FOR BASE (BOM#252) 253 PTJ61108243 BASE (BOM#253) 254 PTJ32600003B FOOT (BOM#254) 255 PTJ61108137 LOCKING PLATE (BOM#255) 256 PTJ61108817 LOCKING PLATE (BOM#255) 257 PTJ32000309A HM SCREW (BOM#257) 258 PTJ61108181 OMEGA BRACKET (BOM#256) 259 PTJ72000076 ANTENNA (BOM#257) 250 PTJ610371A POWER SUPPLY (BOM#256) 251 PTJ62000090 ANTENNA HOLDER (BOM#261) 252 PTJ61103642 ANTENNA SUPPORT PLATE (BOM#262) 253 PTJ61103642 ANTENNA SUPPORT PLATE (BOM#262) 264 PTJ610371A POWER SOCKET PLATE (BOM#262) 265 PTJ63000590 ANTENNA HOLDER (BOM#263) 266 PTJ61103642 ANTENNA SUPPORT PLATE (BOM#262) 267 PTJ33300063 POWER SOCKET PLATE (BOM#262) 268 PTJ63000590 REAR BASE PLATE (BOM#266) 267 PTJ33300062 FUSE HOLDER (BOM#266) 268 PTJ130371A POWER SOCKET PLATE (BOM#262) 269 PTJ1003733 DMX XLR SOCKET (BOM#266) 260 PTJ61103640 HEAT SINK NET HOLDER (BOM#277) 271 PTJ61103640 HEAT SINK NET HOLDER (BOM#277) 272 PTJ61103640 HEAT SINK NET HOLDER (BOM#277) 273 PTJ61103641 HEAT SINK NET HOLDER (BOM#277) 274 PTJ62000511A HANDLE SUPPORT PLATE-LEFT (BOM#272) 275 PTJ61103625 HANDLE SUPPORT PLATE-LEFT (BOM#272) 276 PTJ61000511A HANDLE (BOM#275) 277 PTJ62100111 BUTTON COVER (BOM#278) 278 PTJ612000517	233	PTJ21000993	, ,
236 PTJ39900056 MAGNET (BOM#236) 237 PTJ61101746 SEPARATION BLADE (BOM#237) 238 PTJ3100080 POSITIONING PLUNGER (BOM#238) 239 PTJ31001225 PAN GEAR ASSEMBLY (BOM#239) 240 PTJ61102318A PAN STOPPER (BOM#240) 241 PTJ61103623 PAN LOCK (BOM#241) 242 PTJ61102311 PAN DRIVE MOTOR BOARD (BOM#242) 243 PTJ32400120 PAN TIMING BELT (BOM#243) 244 PTJ3400115A THERMAL PADS (BOM#244) 245 PTJ62000660 WIRE COVER (BOM#245) 246 PTJ32000346 LOCKNUT (BOM#246) 247 PTJ32000381 LOCKING WASHER (BOM#247) 248 PTJ61103632A SUPPORT PLATE FOE BASE (BOM#248) 249 PTJ32100210 STAND OFF FOR BASE (BOM#249) 250 PTJ21003878A ETHERNET PCB (BOM#250) 251 PTJ33000506A POWER SUPPLY (BOM#251) 252 PTJ61108243 BASE (BOM#253) 254 PTJ3260003B FOOT (BOM#254) 255 PTJ6110813 CLAMP LOCK (BOM#256) 256 PTJ61108817 LOCKING PLATE (BOM#256) 257 PTJ32000809A HM SCREW (BOM#259) 258 PTJ61108818 OMEGA BRACKET (BOM#258) 259 PTJ72000076 ANTENNA (BOM#259) 260 PTJ61101752 ANTENNA FIXING PLATE (BOM#260) 261 PTJ62000590 ANTENNA FIXING PLATE (BOM#261) 262 PTJ61103642 ANTENNA SUPPORT PLATE (BOM#262) 263 PTJ6200097A ANTENNA SUPPORT PLATE (BOM#262) 264 PTJ61103571A POWER SOCKET PLATE (BOM#262) 265 PTJ33300053 IP POWER N/OUT SOCKET (BOM#265) 266 PTJ61103641 HEAT SINK NET (BOM#267) 271 PTJ61103641 HEAT SINK NET HOLDER (BOM#269) 272 PTJ61103641 HEAT SINK NET HOLDER (BOM#277) 273 PTJ61103645 HANDLE SUPPORT PLATE (BOM#269) 274 PTJ61103641 HEAT SINK NET (BOM#277) 275 PTJ61103641 HEAT SINK NET (BOM#277) 276 PTJ61103645 HANDLE SUPPORT PLATE (BOM#277) 277 PTJ61103641 HEAT SINK NET (BOM#277) 278 PTJ61000111 BUTTON COVER (BOM#277) 278 PTJ6100011 BUTTON COVER (BOM#277) 278 PTJ6100011 BUTTON COVER (BOM#278)	236 PTJ39900056 MAGNET (BOM#236) 237 PTI61101746 SEPARATION BLADE (BOM#237) 238 PTJ32100080 POSITIONING PLUNGER (BOM#238) 239 PTJ31001225 PAN GEAR ASSEMBLY (BOM#239) 240 PTI61102318A PAN STOPPER (BOM#240) 241 PTJ61103623 PAN LOCK (BOM#241) 242 PTJ61102311 PAN DRIVE MOTOR BOARD (BOM#242) 243 PTJ32400120 PAN TIMING BELT (BOM#243) 244 PTJ34000115A THERMAL PADS (BOM#244) 245 PTJ62000660 WIRE COVER (BOM#245) 246 PTJ32000346 LOCKNUT (BOM#246) 247 PTJ32000381 LOCKING WASHER (BOM#247) 248 PTJ61103632A SUPPORT PLATE FOE BASE (BOM#248) 250 PTJ21003878A ETHERNET PCB (BOM#250) 251 PTJ33000506A POWER SUPPLY (BOM#251) 252 PTJ61103630A STIFFENING PLATE FOR BASE (BOM#252) 253 PTJ61108243 BASE (BOM#253) 254 PTJ32600003B FOOT (BOM#254) 255 PTJ6110817 LOCKING PLATE (BOM#255) 256 PTJ61108817 LOCKING PLATE (BOM#257) 258 PTJ61108817 LOCKING PLATE (BOM#257) 258 PTJ61108818 OMEGA BRACKET (BOM#258) 259 PTJ72000076 ANTENNA HOLDER (BOM#258) 260 PTJ61103571A POWER SUPPLY (BOM#256) 261 PTJ6200090 ANTENNA HOLDER (BOM#260) 262 PTJ61103571A POWER SUPPLY (BOM#263) 264 PTJ61103571A POWER SOCKET PLATE (BOM#264) 265 PTJ33300053 IP POWER IN/OUT SOCKET (BOM#264) 266 PTJ61103571A POWER SOCKET PLATE (BOM#264) 267 PTJ33300053 IP POWER IN/OUT SOCKET (BOM#265) 268 PTJ61103642 ANTENNA HOLDER (BOM#263) 269 PTJ61103571A POWER SOCKET PLATE (BOM#266) 260 PTJ61103571A POWER SOCKET PLATE (BOM#266) 261 PTJ6200090 RARE BASE PLATE (BOM#266) 262 PTJ61103640 HEAT SINK NET HOLDER (BOM#277) 273 PTJ61103640 HEAT SINK NET HOLDER (BOM#277) 274 PTJ61103640 HEAT SINK NET HOLDER (BOM#277) 275 PTJ61103640 HEAT SINK NET HOLDER (BOM#277) 276 PTJ61103641 HEAT SINK NET HOLDER (BOM#277) 277 PTJ61103640 HEAT SINK NET HOLDER (BOM#277) 278 PTJ611003611 BUTTON COVER (BOM#277) 279 PTJ61100327 USB ADAPTER PLATE (BOM#278) 279 PTJ61000511A HANDLE (BOM#277) 270 PTJ61103647 HANDLE (BOM#277) 271 PTJ61103647 HANDLE (BOM#277) 272 PTJ61100367 HANDLE SUPPORT PLATE-LEFT (BOM#273) 274 PTJ62000511A HANDLE (BOM#277) 275 PTJ62000511A HANDLE (BOM#277) 276 PTJ62000511A HANDLE (BOM#278)	234	PTJ32100011	SPACER SUPPORT (BOM#234)
237 PTJ61101746 SEPARATION BLADE (BOM#237) 238 PTJ32100080 POSITIONING PLUNGER (BOM#238) 239 PTJ31001225 PAN GEAR ASSEMBLY (BOM#239) 240 PTJ6110231BA PAN STOPPER (BOM#240) 241 PTJ61103623 PAN LOCK (BOM#241) 242 PTJ61102311 PAN DRIVE MOTOR BOARD (BOM#242) 243 PTJ32400120 PAN TIMING BELT (BOM#243) 244 PTJ34000115A THERMAL PADS (BOM#244) 245 PTJ6200660 WIRE COVER (BOM#245) 246 PTJ32000346 LOCKNUT (BOM#245) 247 PTJ32000381 LOCKING WASHER (BOM#247) 248 PTJ61103632A SUPPORT PLATE FOE BASE (BOM#248) 249 PTJ32100210 STAND OFF FOR BASE (BOM#249) 250 PTJ21003878A ETHERNET PCB (BOM#250) 251 PTJ33000506A POWER SUPPLY (BOM#251) 252 PTJ61103630A STIFFENING PLATE FOR BASE (BOM#252) 253 PTJ61108243 BASE (BOM#253) 254 PTJ32600003B FOOT (BOM#254) 255 PTJ61108103 CLAMP LOCK (BOM#255) 256 PTJ61108817 LOCKING PLATE (BOM#256) 257 PTJ32000809A HM SCREW (BOM#255) 258 PTJ61108181 OMEGA BRACKET (BOM#258) 259 PTJ72000076 ANTENNA (BOM#259) 260 PTJ61101752 ANTENNA (BOM#259) 261 PTJ62000590 ANTENNA FIXING PLATE (BOM#260) 262 PTJ61103642 ANTENNA SUPPORT PLATE (BOM#261) 263 PTJ6200097A ANTENNA SUPPORT PLATE (BOM#262) 264 PTJ61103642 ANTENNA SUPPORT PLATE (BOM#262) 265 PTJ33300053 IP POWER SOCKET PLATE (BOM#265) 266 PTJ61103641 HEAT SINK NET HOLDER (BOM#266) 267 PTJ33300062 FUSE HOLDER (BOM#267) 270 PTJ61103641 HEAT SINK NET HOLDER (BOM#269) 271 PTJ61103641 HEAT SINK NET HOLDER (BOM#277) 272 PTJ61103641 HEAT SINK NET (BOM#271) 273 PTJ61103641 HEAT SINK NET (BOM#272) 274 PTJ6103642 HADLE SUPPORT PLATE (BOM#272) 275 PTJ6103664 HADLE SUPPORT PLATE (BOM#272) 276 PTJ61103641 HEAT SINK NET (BOM#277) 277 PTJ61103641 HEAT SINK NET (BOM#275) 278 PTJ61103642 HADLE SUPPORT PLATE (BOM#272) 279 PTJ61103641 HEAT SINK NET (BOM#275) 270 PTJ61103640 HEAT SINK NET (BOM#277) 271 PTJ61103641 HEAT SINK NET (BOM#277) 272 PTJ61103642 HADLE SUPPORT PLATE (BOM#278) 273 PTJ61103640 HEAT SINK NET (BOM#277) 274 PTJ62000514A BASE COVER (BOM#277) 275 PTJ62000514A BASE COVER (BOM#277) 276 PTJ12000111 BUTTON COVER (BOM#278)	237 PTJ61101746 SEPARATION BLADE (BOM#237) 238 PTJ32100080 POSITIONING PLUNGER (BOM#238) 239 PTJ31001225 PAN GEAR ASSEMBLY (BOM#239) 240 PTJ61102318A PAN STOPPER (BOM#240) 241 PTJ61103623 PAN LOCK (BOM#241) 242 PTJ61102311 PAN DRIVE MOTOR BOARD (BOM#242) 243 PTJ32400120 PAN TIMING BELT (BOM#243) 244 PTJ34000115A THERMAL PADS (BOM#243) 245 PTJ62000660 WIRE COVER (BOM#245) 246 PTJ32000346 LOCKNUT (BOM#246) 247 PTJ32000381 LOCKINUT (BOM#246) 249 PTJ32100210 STAND OFF FOR BASE (BOM#248) 249 PTJ21003878A ETHERNET PCB (BOM#250) 250 PTJ21003878A ETHERNET PCB (BOM#250) 251 PTJ33000506A POWER SUPPLY (BOM#251) 252 PTJ61103630A STIFFENING PLATE FOR BASE (BOM#252) 253 PTJ61108243 BASE (BOM#253) 254 PTJ3260003B FOOT (BOM#255) 255 PTJ61108103 CLAMP LOCK (BOM#255) 256 PTJ6110817 LOCKING PLATE (BOM#255) 257 PTJ61108818 OMEGA BRACKET (BOM#258) 258 PTJ61108818 OMEGA BRACKET (BOM#258) 259 PTJ72000076 ANTENNA FIXING PLATE (BOM#258) 260 PTJ61101752 ANTENNA FIXING PLATE (BOM#260) 261 PTJ62000590 ANTENNA FIXING PLATE (BOM#261) 262 PTJ61103571A POWER SUPPLY (BOM#262) 263 PTJ62000097A ANTENNA BUPPORT PLATE (BOM#264) 265 PTJ33300053 IP POWER IN/OUT SOCKET (BOM#265) 266 PTJ61103571A POWER SUPPLY (BOM#277) 268 PTJ21003733 DMX XLR SOCKET (PLATE (BOM#266) 270 PTJ61103641 HEAT SINK NET (BOM#277) 271 PTJ61103646 HANDLE (BOM#277) 272 PTJ61103626 HANDLE SUPPORT PLATE (BOM#270) 273 PTJ61103627 HARDLE SUPPORT PLATE (BOM#271) 274 PTJ61103641 HEAT SINK NET (BOM#277) 275 PTJ61103642 FIRSTENT CONNECTOR (BOM#273) 276 PTJ121003733 DMX XLR SOCKET (PLATE (BOM#274) 277 PTJ61103640 HEAT SINK NET (BOM#277) 278 PTJ611003671 HANDLE (BOM#275) 279 PTJ611003671 FARSTEN COVER (BOM#277) 278 PTJ611003671 FARSTEN COVER (BOM#277) 279 PTJ611003671 FARSTEN COVER (BOM#277) 278 PTJ612000511 HANDLE (BOM#276) 277 PTJ6100371 FARSTEN COVER (BOM#277) 278 PTJ61000877 HARDLE SUPPORT PLATE-RIGHT (BOM#273) 279 PTJ611003677 USB ADAPTER PLATE (BOM#278) 279 PTJ21000877 USB ADAPTER PLATE (BOM#279)	235	PTJ32000801	,
238 PTJ31001025 PAN GEAR ASSEMBLY (BOM#239) 239 PTJ311001225 PAN GEAR ASSEMBLY (BOM#239) 240 PTJ61102318A PAN STOPPER (BOM#240) 241 PTJ61103623 PAN LOCK (BOM#241) 242 PTJ61102311 PAN DRIVE MOTOR BOARD (BOM#242) 243 PTJ32400120 PAN TIMING BELT (BOM#243) 244 PTJ3000015A THERMAL PADS (BOM#244) 245 PTJ62000660 WIRE COVER (BOM#245) 246 PTJ32000346 LOCKNUT (BOM#246) 247 PTJ32000381 LOCKING WASHER (BOM#247) 248 PTJ61103632A SUPPORT PLATE FOE BASE (BOM#249) 250 PTJ21003878A ETHERNET PCB (BOM#250) 251 PTJ33000506A POWER SUPPLY (BOM#251) 252 PTJ61103630A STIFFENING PLATE FOR BASE (BOM#252) 253 PTJ61108243 BASE (BOM#253) 254 PTJ32600003B FOOT (BOM#254) 255 PTJ6110817 LOCKING PLATE (BOM#255) 256 PTJ6110817 LOCKING PLATE (BOM#257) 258 PTJ6100818 <td>238 PTJ32100080 POSITIONING PLUNGER (BOM#238) 239 PTJ31001225 PAN GEAR ASSEMBLY (BOM#239) 240 PTJ6110231BA PAN STOPPER (BOM#240) 241 PTJ61103623 PAN LOCK (BOM#241) 242 PTJ61102311 PAN DRIVE MOTOR BOARD (BOM#242) 243 PTJ32400120 PAN TIMING BELT (BOM#243) 244 PTJ3400015A THERMAL PADS (BOM#244) 245 PTJ62000660 WIRE COVER (BOM#245) 246 PTJ32000346 LOCKNUT (BOM#246) 247 PTJ32000381 LOCKING WASHER (BOM#247) 248 PTJ61103632A SUPPORT PLATE FOE BASE (BOM#248) 249 PTJ32100210 STAND OFF FOR BASE (BOM#249) 250 PTJ21003878A ETHERNET PCB (BOM#250) 251 PTJ33000506A POWER SUPPLY (BOM#251) 252 PTJ61103630A STIFEFNING PLATE FOR BASE (BOM#252) 253 PTJ61108243 BASE (BOM#253) 254 PTJ32600003B FOOT (BOM#254) 255 PTJ61106103 CLAMP LOCK (BOM#255) 256 PTJ61108817 LOCKING PLATE (BOM#256) 257 PTJ32000809A HM SCREW (BOM#257) 258 PTJ61108818 OMEGA BRACKET (BOM#258) 259 PTJ72000076 ANTENNA (BOM#259) 260 PTJ61103642 ANTENNA FIXING PLATE (BOM#260) 261 PTJ62000590 ANTENNA (BOM#256) 262 PTJ61103642 ANTENNA FIXING PLATE (BOM#261) 263 PTJ62000097A ANTENNA HOLDER (BOM#263) 264 PTJ6110371A POWER SOCKET PLATE (BOM#264) 265 PTJ33300065 IP POWER IN/OUT SOCKET (BOM#265) 266 PTJ61103642 ANTENNA SNAP (BOM#263) 267 PTJ33300066 FUSE HOLDER (BOM#266) 268 PTJ6100097A ANTENNA SNAP (BOM#266) 269 PTJ121003733 DMX XLR SOCKET (PLATE (BOM#265) 270 PTJ61103640 HEAT SINK NET HOLDER (BOM#277) 271 PTJ61103640 HEAT SINK NET HOLDER (BOM#277) 272 PTJ61103640 HEAT SINK NET HOLDER (BOM#277) 273 PTJ61103640 HEAT SINK NET HOLDER (BOM#277) 274 PTJ62000511A HANDLE (BOM#277) 275 PTJ62000511A HANDLE (BOM#277) 276 PTJ21000373 MPCB (BOM#277) 277 PTJ62100111 BUTTON COVER (BOM#277) 278 PTJ62100111 BUTTON COVER (BOM#277) 279 PTJ62100027 USB ADAPTER PLATE (BOM#278) 279 PTJ62100027 HEAT (BOM#279)</td> <td>236</td> <td>PTJ39900056</td> <td></td>	238 PTJ32100080 POSITIONING PLUNGER (BOM#238) 239 PTJ31001225 PAN GEAR ASSEMBLY (BOM#239) 240 PTJ6110231BA PAN STOPPER (BOM#240) 241 PTJ61103623 PAN LOCK (BOM#241) 242 PTJ61102311 PAN DRIVE MOTOR BOARD (BOM#242) 243 PTJ32400120 PAN TIMING BELT (BOM#243) 244 PTJ3400015A THERMAL PADS (BOM#244) 245 PTJ62000660 WIRE COVER (BOM#245) 246 PTJ32000346 LOCKNUT (BOM#246) 247 PTJ32000381 LOCKING WASHER (BOM#247) 248 PTJ61103632A SUPPORT PLATE FOE BASE (BOM#248) 249 PTJ32100210 STAND OFF FOR BASE (BOM#249) 250 PTJ21003878A ETHERNET PCB (BOM#250) 251 PTJ33000506A POWER SUPPLY (BOM#251) 252 PTJ61103630A STIFEFNING PLATE FOR BASE (BOM#252) 253 PTJ61108243 BASE (BOM#253) 254 PTJ32600003B FOOT (BOM#254) 255 PTJ61106103 CLAMP LOCK (BOM#255) 256 PTJ61108817 LOCKING PLATE (BOM#256) 257 PTJ32000809A HM SCREW (BOM#257) 258 PTJ61108818 OMEGA BRACKET (BOM#258) 259 PTJ72000076 ANTENNA (BOM#259) 260 PTJ61103642 ANTENNA FIXING PLATE (BOM#260) 261 PTJ62000590 ANTENNA (BOM#256) 262 PTJ61103642 ANTENNA FIXING PLATE (BOM#261) 263 PTJ62000097A ANTENNA HOLDER (BOM#263) 264 PTJ6110371A POWER SOCKET PLATE (BOM#264) 265 PTJ33300065 IP POWER IN/OUT SOCKET (BOM#265) 266 PTJ61103642 ANTENNA SNAP (BOM#263) 267 PTJ33300066 FUSE HOLDER (BOM#266) 268 PTJ6100097A ANTENNA SNAP (BOM#266) 269 PTJ121003733 DMX XLR SOCKET (PLATE (BOM#265) 270 PTJ61103640 HEAT SINK NET HOLDER (BOM#277) 271 PTJ61103640 HEAT SINK NET HOLDER (BOM#277) 272 PTJ61103640 HEAT SINK NET HOLDER (BOM#277) 273 PTJ61103640 HEAT SINK NET HOLDER (BOM#277) 274 PTJ62000511A HANDLE (BOM#277) 275 PTJ62000511A HANDLE (BOM#277) 276 PTJ21000373 MPCB (BOM#277) 277 PTJ62100111 BUTTON COVER (BOM#277) 278 PTJ62100111 BUTTON COVER (BOM#277) 279 PTJ62100027 USB ADAPTER PLATE (BOM#278) 279 PTJ62100027 HEAT (BOM#279)	236	PTJ39900056	
PTI31001225	239 PTJ31001225 PAN GEAR ASSEMBLY (BOM#239) 240 PTJ61102318A PAN STOPPER (BOM#240) 241 PTJ61103623 PAN LOCK (BOM#241) 242 PTJ61102311 PAN DRIVE MOTOR BOARD (BOM#242) 243 PTJ32400120 PAN TIMING BELT (BOM#243) 244 PTJ34000115A THERMAL PADS (BOM#244) 245 PTJ62000660 WIRE COVER (BOM#245) 246 PTJ32000346 LOCKNUT (BOM#246) 247 PTJ32000381 LOCKING WASHER (BOM#247) 248 PTJ61103632A SUPPORT PLATE FOE BASE (BOM#248) 249 PTJ32100210 STAND OFF FOR BASE (BOM#249) 250 PTJ21003878A ETHERNET PCB (BOM#250) 251 PTJ33000506A POWER SUPPLY (BOM#251) 252 PTJ61108630A STIFFENING PLATE FOR BASE (BOM#252) 253 PTJ61108243 BASE (BOM#253) 254 PTJ32600038 FOOT (BOM#254) 255 PTJ61108137 LOCKING PLATE (BOM#255) 256 PTJ61108817 LOCKING PLATE (BOM#255) 257 PTJ32000809A HM SCREW (BOM#257) 258 PTJ61108818 OMEGA BRACKET (BOM#258) 259 PTJ7200076 ANTENNA (BOM#259) 260 PTJ61101752 ANTENNA (BOM#259) 261 PTJ62000590 ANTENNA (BOM#253) 264 PTJ61103642 ANTENNA SUPPORT PLATE (BOM#260) 265 PTJ63300053 IP POWER SOCKET PLATE (BOM#262) 266 PTJ61103571A POWER SOCKET PLATE (BOM#262) 267 PTJ33300062 FUSE HOLDER (BOM#263) 266 PTJ61103671 APOWER SOCKET PLATE (BOM#264) 267 PTJ33300062 FUSE HOLDER (BOM#267) 278 PTJ61103641 HEAT SINK NET HOLDER (BOM#268) 279 PTJ61103640 HEAT SINK NET HOLDER (BOM#269) 271 PTJ61103641 HEAT SINK NET HOLDER (BOM#270) 273 PTJ61103645 HANDLE SUPPORT PLATE-LEFT (BOM#272) 274 PTJ6103651 HADLE SUPPORT PLATE-LEFT (BOM#272) 275 PTJ62000511A HANDLE (BOM#275) 276 PTJ21000971B MPCB (BOM#275) 277 PTJ62100111 BUTTON COVER (BOM#277) 278 PDJ6100027 USB ADAPTER PLATE (BOM#278) 279 PTJ21000827 USB ADAPTER PLATE (BOM#279)		PTJ61101746	
240 PTJ61102318A PAN STOPPER (BOM#240) 241 PTJ61103623 PAN LOCK (BOM#241) 242 PTJ61102311 PAN DRIVE MOTOR BOARD (BOM#242) 243 PTJ3400115A THERMAL PADS (BOM#243) 244 PTJ34000115A THERMAL PADS (BOM#245) 245 PTJ62000660 WIRE COVER (BOM#245) 246 PTJ32000381 LOCKING WASHER (BOM#247) 248 PTJ61103632A SUPPORT PLATE FOE BASE (BOM#248) 249 PTJ32100210 STAND OFF FOR BASE (BOM#249) 250 PTJ21303878A ETHERNET PCB (BOM#250) 251 PTJ33000506A POWER SUPPLY (BOM#251) 252 PTJ61103630A STIFFENING PLATE FOR BASE (BOM#252) 253 PTJ61108243 BASE (BOM#253) 254 PTJ32600003B FOOT (BOM#254) 255 PTJ61108817 LOCKING PLATE (BOM#255) 256 PTJ61108817 LOCKING PLATE (BOM#255) 257 PTJ32000809A HM SCREW (BOM#257) 258 PTJ61108818 OMEGA BRACKET (BOM#258) 260 PTJ61103642	240 PTJ61102318A PAN STOPPER (BOM#240) 241 PTJ61103623 PAN LOCK (BOM#241) 242 PTJ611032311 PAN DRIVE MOTOR BOARD (BOM#242) 243 PTJ34000120 PAN TIMING BELT (BOM#243) 244 PTJ34000115A THERMAL PADS (BOM#244) 245 PTJ62000660 WIRE COVER (BOM#245) 246 PTJ32000381 LOCKING WASHER (BOM#247) 248 PTJ61103632A SUPPORT PLATE FOE BASE (BOM#248) 249 PTJ32100210 STAND OFF FOR BASE (BOM#250) 250 PTJ21003878A ETHERNET PCB (BOM#250) 251 PTJ33000506A POWER SUPPLY (BOM#251) 252 PTJ61103630A STIFFENING PLATE FOR BASE (BOM#252) 253 PTJ61108243 BASE (BOM#253) 254 PTJ32600003B FOOT (BOM#254) 255 PTJ61108817 LOCKING PLATE (BOM#256) 257 PTJ32000809A HM SCREW (BOM#257) 258 PTJ61103817 LOCKING PLATE (BOM#259) 260 PTJ6110752 ANTENNA FIXING PLATE (BOM#261) 261 PTJ620		PTJ32100080	
241 PTJ61103623 PAN LOCK (BOM#241) 242 PTJ61102311 PAN DRIVE MOTOR BOARD (BOM#242) 243 PTJ32400120 PAN TIMING BELT (BOM#243) 244 PTJ32000360 WIRE COVER (BOM#244) 245 PTJ62000660 WIRE COVER (BOM#245) 246 PTJ32000346 LOCKING WASHER (BOM#247) 248 PTJ32100210 STAND OFF FOR BASE (BOM#249) 249 PTJ32100210 STAND OFF FOR BASE (BOM#249) 250 PTJ21003878A ETHERNET PCB (BOM#250) 251 PTJ33000506A POWER SUPPLY (BOM#251) 252 PTJ61108243 BASE (BOM#253) 253 PTJ61108243 BASE (BOM#253) 254 PTJ3200003B FOOT (BOM#254) 255 PTJ6110817 LOCKING PLATE (BOM#255) 256 PTJ6110817 LOCKING PLATE (BOM#255) 256 PTJ61108817 LOCKING PLATE (BOM#257) 258 PTJ61108817 LOCKING PLATE (BOM#258) 259 PTJ72000076 ANTENNA (BOM#259) 260 PTJ61103642 ANTENNA FIXING PLA	241 PTJ61103623 PAN LOCK (BOM#241) 242 PTJ61102311 PAN DRIVE MOTOR BOARD (BOM#242) 243 PTJ32400120 PAN TIMING BELT (BOM#243) 244 PTJ34000115A THERMAL PADS (BOM#244) 245 PTJ62000660 WIRE COVER (BOM#245) 246 PTJ32000346 LOCKNUT (BOM#246) 247 PTJ32000381 LOCKING WASHER (BOM#247) 248 PTJ61103632A SUPPORT PLATE FOE BASE (BOM#248) 249 PTJ32100210 STAND OFF FOR BASE (BOM#249) 250 PTJ21003878A ETHERNET PCB (BOM#250) 251 PTJ33000506A POWER SUPPLY (BOM#251) 252 PTJ61108243 BASE (BOM#253) 254 PTJ32600003B FOOT (BOM#253) 255 PTJ6110813 CLAMP LOCK (BOM#255) 256 PTJ61108817 LOCKING PLATE (BOM#256) 257 PTJ32000809A HM SCREW (BOM#257) 258 PTJ6108818 OMEGA BRACKET (BOM#258) 259 PTJ72000076 ANTENNA SUPPORT PLATE (BOM#261) 261 PTJ62000590 <td< td=""><td></td><td></td><td></td></td<>			
242 PTJ61102311 PAN DRIVE MOTOR BOARD (BOM#242) 243 PTJ32400120 PAN TIMING BELT (BOM#243) 244 PTJ34000115A THERMAL PADS (BOM#244) 245 PTJ62000660 WIRE COVER (BOM#245) 246 PTJ32000346 LOCKNUT (BOM#246) 247 PTJ32000381 LOCKING WASHER (BOM#247) 248 PTJ61103632A SUPPORT PLATE FOE BASE (BOM#248) 250 PTJ21003878A ETHERNET PCB (BOM#250) 251 PTJ33000506A POWER SUPPLY (BOM#251) 252 PTJ61103630A STIFFENING PLATE FOR BASE (BOM#252) 253 PTJ61108243 BASE (BOM#253) 254 PTJ32600003B FOOT (BOM#254) 255 PTJ61106103 CLAMP LOCK (BOM#255) 256 PTJ61108817 LOCKING PLATE (BOM#256) 257 PTJ320000809A HM SCREW (BOM#257) 258 PTJ61108818 OMEGA BRACKET (BOM#258) 259 PTJ72000076 ANTENNA (BOM#259) 260 PTJ61101752 ANTENNA SUPPORT PLATE (BOM#260) 261 PTJ62000590	242 PTJ61102311 PAN DRIVE MOTOR BOARD (BOM#242) 243 PTJ32400120 PAN TIMING BELT (BOM#243) 244 PTJ34000115A THERMAL PADS (BOM#244) 245 PTJ62000660 WIRE COVER (BOM#245) 246 PTJ32000346 LOCKNUT (BOM#246) 247 PTJ32000381 LOCKING WASHER (BOM#247) 248 PTJ61103632A SUPPORT PLATE FOE BASE (BOM#248) 259 PTJ21003878A ETHERNET PCB (BOM#250) 250 PTJ21003878A ETHERNET PCB (BOM#251) 251 PTJ33000506A POWER SUPPLY (BOM#251) 252 PTJ61108243 BASE (BOM#253) 253 PTJ61108243 BASE (BOM#253) 254 PTJ3260003B FOOT (BOM#254) 255 PTJ61108817 LOCKING PLATE (BOM#255) 256 PTJ61108817 LOCKING PLATE (BOM#257) 258 PTJ61108818 OMEGA BRACKET (BOM#257) 259 PTJ72000076 ANTENNA (BOM#259) 260 PTJ61103642 ANTENNA FULL (BOM#261) 261 PTJ6103642 ANTENNA FULL (BO			•
243 PTJ32400120 PAN TIMING BELT (BOM#243) 244 PTJ34000115A THERMAL PADS (BOM#244) 245 PTJ62000660 WIRE COVER (BOM#245) 246 PTJ32000346 LOCKNUT (BOM#246) 247 PTJ32000381 LOCKING WASHER (BOM#247) 248 PTJ61103632A SUPPORT PLATE FOE BASE (BOM#248) 249 PTJ32100210 STAND OFF FOR BASE (BOM#250) 250 PTJ21003878A ETHERNET PCB (BOM#250) 251 PTJ33000506A POWER SUPPLY (BOM#251) 252 PTJ61103630A STIFFENING PLATE FOR BASE (BOM#252) 253 PTJ61108243 BASE (BOM#253) 254 PTJ32600003B FOOT (BOM#254) 255 PTJ6110817 LOCKING PLATE (BOM#255) 256 PTJ61108817 LOCKING PLATE (BOM#255) 257 PTJ32000809A HM SCREW (BOM#257) 258 PTJ61108818 OMEGA BRACKET (BOM#255) 259 PTJ72000076 ANTENNA (BOM#257) 260 PTJ61103642 ANTENNA FIXING PLATE (BOM#260) 261 PTJ62000590	243 PTJ32400120 PAN TIMING BELT (BOM#243) 244 PTJ34000115A THERMAL PADS (BOM#244) 245 PTJ62000660 WIRE COVER (BOM#245) 246 PTJ32000346 LOCKNUT (BOM#246) 247 PTJ32000381 LOCKING WASHER (BOM#247) 248 PTJ61103632A SUPPORT PLATE FOE BASE (BOM#248) 250 PTJ21003878A ETHERNET PCB (BOM#250) 251 PTJ33000506A POWER SUPPLY (BOM#251) 252 PTJ61108243 BASE (BOM#253) 254 PTJ32600003B FOOT (BOM#254) 255 PTJ6110817 LOCKING PLATE (BOM#255) 256 PTJ61108817 LOCKING PLATE (BOM#255) 257 PTJ32000809A HM SCREW (BOM#257) 258 PTJ61108818 OMEGA BRACKET (BOM#258) 259 PTJ72000076 ANTENNA (BOM#259) 260 PTJ61103542 ANTENNA FIXING PLATE (BOM#260) 261 PTJ62000590 ANTENNA SUPPORT PLATE (BOM#261) 262 PTJ61103642 ANTENNA SNAP (BOM#263) 264 PTJ6103571A POW			
244 PTJ34000115A THERMAL PADS (BOM#244) 245 PTJ62000660 WIRE COVER (BOM#245) 246 PTJ32000346 LOCKNUT (BOM#246) 247 PTJ32000381 LOCKING WASHER (BOM#247) 248 PTJ61103632A SUPPORT PLATE FOE BASE (BOM#248) 249 PTJ32100210 STAND OFF FOR BASE (BOM#249) 250 PTJ21003878A ETHERNET PCB (BOM#250) 251 PTJ33000506A POWER SUPPLY (BOM#251) 252 PTJ61103630A STIFFENING PLATE FOR BASE (BOM#252) 253 PTJ61108243 BASE (BOM#253) 254 PTJ32600003B FOOT (BOM#254) 255 PTJ61106103 CLAMP LOCK (BOM#254) 255 PTJ61108817 LOCKING PLATE (BOM#256) 257 PTJ32000809A HM SCREW (BOM#257) 258 PTJ61108818 OMEGA BRACKET (BOM#258) 260 PTJ61101752 ANTENNA FIXING PLATE (BOM#260) 261 PTJ62000590 ANTENNA SUPPORT PLATE (BOM#261) 262 PTJ6103642 ANTENNA SUPPORT PLATE (BOM#262) 263 PTJ6	244 PTJ34000115A THERMAL PADS (BOM#244) 245 PTJ62000660 WIRE COVER (BOM#245) 246 PTJ32000346 LOCKNUT (BOM#246) 247 PTJ32000381 LOCKING WASHER (BOM#247) 248 PTJ61103632A SUPPORT PLATE FOE BASE (BOM#248) 249 PTJ32100210 STAND OFF FOR BASE (BOM#249) 250 PTJ21003878A ETHERNET PCB (BOM#250) 251 PTJ33000506A POWER SUPPLY (BOM#251) 252 PTJ61103630A STIFFENING PLATE FOR BASE (BOM#252) 253 PTJ61108243 BASE (BOM#253) 254 PTJ32600003B FOOT (BOM#254) 255 PTJ6110817 LOCKING PLATE (BOM#255) 256 PTJ61108817 LOCKING PLATE (BOM#255) 257 PTJ32000809A HM SCREW (BOM#257) 258 PTJ61108818 OMEGA BRACKET (BOM#258) 259 PTJ72000076 ANTENNA (BOM#259) 260 PTJ61103752 ANTENNA HOLDER (BOM#260) 261 PTJ62000590 ANTENNA SUPPORT PLATE (BOM#262) 263 PTJ62000590			, ,
245 PTJ62000660 WIRE COVER (BOM#245) 246 PTJ32000346 LOCKNUT (BOM#246) 247 PTJ32000381 LOCKING WASHER (BOM#247) 248 PTJ61103632A SUPPORT PLATE FOE BASE (BOM#248) 249 PTJ32100210 STAND OFF FOR BASE (BOM#250) 250 PTJ21003878A ETHERNET PCB (BOM#250) 251 PTJ33000506A POWER SUPPLY (BOM#251) 252 PTJ61103630A STIFFENING PLATE FOR BASE (BOM#252) 253 PTJ61108243 BASE (BOM#253) 254 PTJ32600033B FOOT (BOM#254) 255 PTJ61106103 CLAMP LOCK (BOM#255) 256 PTJ61108817 LOCKING PLATE (BOM#256) 257 PTJ32000809A HM SCREW (BOM#257) 258 PTJ61103818 OMEGA BRACKET (BOM#258) 259 PTJ72000076 ANTENNA HOLDER (BOM#259) 260 PTJ61101752 ANTENNA HOLDER (BOM#261) 261 PTJ62000590 ANTENNA SUPPORT PLATE (BOM#262) 263 PTJ62000597A ANTENNA SNAP (BOM#263) 264 PTJ61103571A <td>245 PTJ62000660 WIRE COVER (BOM#245) 246 PTJ32000346 LOCKNUT (BOM#246) 247 PTJ32000381 LOCKING WASHER (BOM#247) 248 PTJ61103632A SUPPORT PLATE FOE BASE (BOM#248) 249 PTJ32100210 STAND OFF FOR BASE (BOM#249) 250 PTJ21003878A ETHERNET PCB (BOM#250) 251 PTJ33000506A POWER SUPPLY (BOM#251) 252 PTJ61108243 BASE (BOM#253) 253 PTJ61108243 BASE (BOM#253) 254 PTJ32000003B FOOT (BOM#254) 255 PTJ61106103 CLAMP LOCK (BOM#255) 256 PTJ61108817 LOCKING PLATE (BOM#256) 257 PTJ32000809A HM SCREW (BOM#257) 258 PTJ61108818 OMEGA BRACKET (BOM#258) 259 PTJ72000076 ANTENNA (BOM#259) 260 PTJ61101752 ANTENNA FIXING PLATE (BOM#260) 261 PTJ62000590 ANTENNA SUPPORT PLATE (BOM#262) 262 PTJ61103642 ANTENNA SUPPORT PLATE (BOM#264) 265 PTJ33300053 IP</td> <td></td> <td></td> <td></td>	245 PTJ62000660 WIRE COVER (BOM#245) 246 PTJ32000346 LOCKNUT (BOM#246) 247 PTJ32000381 LOCKING WASHER (BOM#247) 248 PTJ61103632A SUPPORT PLATE FOE BASE (BOM#248) 249 PTJ32100210 STAND OFF FOR BASE (BOM#249) 250 PTJ21003878A ETHERNET PCB (BOM#250) 251 PTJ33000506A POWER SUPPLY (BOM#251) 252 PTJ61108243 BASE (BOM#253) 253 PTJ61108243 BASE (BOM#253) 254 PTJ32000003B FOOT (BOM#254) 255 PTJ61106103 CLAMP LOCK (BOM#255) 256 PTJ61108817 LOCKING PLATE (BOM#256) 257 PTJ32000809A HM SCREW (BOM#257) 258 PTJ61108818 OMEGA BRACKET (BOM#258) 259 PTJ72000076 ANTENNA (BOM#259) 260 PTJ61101752 ANTENNA FIXING PLATE (BOM#260) 261 PTJ62000590 ANTENNA SUPPORT PLATE (BOM#262) 262 PTJ61103642 ANTENNA SUPPORT PLATE (BOM#264) 265 PTJ33300053 IP			
246 PTJ32000346 LOCKNUT (BOM#246) 247 PTJ32000381 LOCKING WASHER (BOM#247) 248 PTJ61103632A SUPPORT PLATE FOE BASE (BOM#248) 249 PTJ32100210 STAND OFF FOR BASE (BOM#249) 250 PTJ21003878A ETHERNET PCB (BOM#250) 251 PTJ33000506A POWER SUPPLY (BOM#251) 252 PTJ6110830A STIFFENING PLATE FOR BASE (BOM#252) 253 PTJ61108243 BASE (BOM#253) 254 PTJ32600003B FOOT (BOM#254) 255 PTJ61106103 CLAMP LOCK (BOM#255) 256 PTJ61108817 LOCKING PLATE (BOM#256) 257 PTJ32000809A HM SCREW (BOM#257) 258 PTJ61108818 OMEGA BRACKET (BOM#258) 259 PTJ72000076 ANTENNA (BOM#259) 260 PTJ61101752 ANTENNA FIXING PLATE (BOM#260) 261 PTJ62000590 ANTENNA SUPPORT PLATE (BOM#262) 263 PTJ6200097A ANTENNA SNAP (BOM#263) 264 PTJ61103642 ANTENNA SNAP (BOM#266) 265 PTJ33300063	246 PTJ32000346 LOCKNUT (BOM#246) 247 PTJ32000381 LOCKING WASHER (BOM#247) 248 PTJ61103632A SUPPORT PLATE FOE BASE (BOM#248) 249 PTJ32100210 STAND OFF FOR BASE (BOM#249) 250 PTJ21003878A ETHERNET PCB (BOM#250) 251 PTJ33000506A POWER SUPPLY (BOM#251) 252 PTJ61108243 BASE (BOM#253) 253 PTJ61108243 BASE (BOM#253) 254 PTJ3260003B FOOT (BOM#254) 255 PTJ61106103 CLAMP LOCK (BOM#255) 256 PTJ61108817 LOCKING PLATE (BOM#256) 257 PTJ32000809A HM SCREW (BOM#257) 258 PTJ61108818 OMEGA BRACKET (BOM#258) 259 PTJ72000076 ANTENNA FIXING PLATE (BOM#260) 261 PTJ621000590 ANTENNA FIXING PLATE (BOM#261) 262 PTJ61103642 ANTENNA SUPPORT PLATE (BOM#262) 263 PTJ6200097A ANTENNA SNAP (BOM#263) 264 PTJ61003571A POWER SOCKET PLATE (BOM#266) 265 PTJ33300062			•
247 PTJ32000381 LOCKING WASHER (BOM#247) 248 PTJ61103632A SUPPORT PLATE FOE BASE (BOM#248) 249 PTJ32100210 STAND OFF FOR BASE (BOM#249) 250 PTJ21003878A ETHERNET PCB (BOM#250) 251 PTJ33000506A POWER SUPPLY (BOM#251) 252 PTJ61103630A STIFFENING PLATE FOR BASE (BOM#252) 253 PTJ61108243 BASE (BOM#253) 254 PTJ32600003B FOOT (BOM#254) 255 PTJ6110817 LOCKING PLATE (BOM#255) 256 PTJ61108817 LOCKING PLATE (BOM#257) 258 PTJ61108818 OMEGA BRACKET (BOM#257) 258 PTJ61108818 OMEGA BRACKET (BOM#258) 259 PTJ72000076 ANTENNA (BOM#259) 260 PTJ61101752 ANTENNA FIXING PLATE (BOM#260) 261 PTJ62000590 ANTENNA SUPPORT PLATE (BOM#261) 262 PTJ61103642 ANTENNA SNAP (BOM#263) 264 PTJ61103571A POWER SOCKET PLATE (BOM#264) 265 PTJ33300053 IP POWER IN/OUT SOCKET (BOM#266) 266	247 PTJ32000381 LOCKING WASHER (BOM#247) 248 PTJ61103632A SUPPORT PLATE FOE BASE (BOM#248) 249 PTJ32100210 STAND OFF FOR BASE (BOM#249) 250 PTJ21003878A ETHERNET PCB (BOM#250) 251 PTJ33000506A POWER SUPPLY (BOM#251) 252 PTJ61108243 BASE (BOM#253) 253 PTJ61108243 BASE (BOM#253) 254 PTJ32600003B FOOT (BOM#254) 255 PTJ61108817 LOCKING PLATE (BOM#256) 256 PTJ61108817 LOCKING PLATE (BOM#256) 257 PTJ32000809A HM SCREW (BOM#257) 258 PTJ61108818 OMEGA BRACKET (BOM#258) 259 PTJ72000076 ANTENNA (BOM#259) 260 PTJ61101752 ANTENNA FIXING PLATE (BOM#260) 261 PTJ62000590 ANTENNA SUPPORT PLATE (BOM#262) 263 PTJ62000097A ANTENNA SNAP (BOM#263) 264 PTJ61103571A POWER SOCKET PLATE (BOM#266) 265 PTJ33300062 FUSE HOLDER (BOM#267) 268 PTJ21003733			, ,
248 PTJ61103632A SUPPORT PLATE FOE BASE (BOM#248) 249 PTJ32100210 STAND OFF FOR BASE (BOM#249) 250 PTJ21003878A ETHERNET PCB (BOM#250) 251 PTJ33000506A POWER SUPPLY (BOM#251) 252 PTJ61103630A STIFFENING PLATE FOR BASE (BOM#252) 253 PTJ61108243 BASE (BOM#253) 254 PTJ32600003B FOOT (BOM#254) 255 PTJ61106103 CLAMP LOCK (BOM#255) 256 PTJ61108817 LOCKING PLATE (BOM#256) 257 PTJ32000809A HM SCREW (BOM#257) 258 PTJ61101752 ANTENNA (BOM#259) 260 PTJ61101752 ANTENNA FIXING PLATE (BOM#260) 261 PTJ62000590 ANTENNA SUPPORT PLATE (BOM#261) 262 PTJ61103642 ANTENNA SUPPORT PLATE (BOM#262) 263 PTJ6200097A ANTENNA SNAP (BOM#263) 264 PTJ61103571A POWER SOCKET PLATE (BOM#264) 265 PTJ33300062 FUSE HOLDER (BOM#267) 266 PTJ61003733 IP POWER IN/OUT SOCKET (BOM#268) 269	248 PTJ61103632A SUPPORT PLATE FOE BASE (BOM#248) 249 PTJ32100210 STAND OFF FOR BASE (BOM#249) 250 PTJ21003878A ETHERNET PCB (BOM#250) 251 PTJ33000506A POWER SUPPLY (BOM#251) 252 PTJ61108243 BASE (BOM#253) 253 PTJ61108243 BASE (BOM#253) 254 PTJ32600003B FOOT (BOM#254) 255 PTJ6110817 LOCKING PLATE (BOM#255) 256 PTJ61108817 LOCKING PLATE (BOM#255) 257 PTJ32000809A HM SCREW (BOM#257) 258 PTJ61108818 OMEGA BRACKET (BOM#258) 259 PTJ72000076 ANTENNA (BOM#257) 260 PTJ61101752 ANTENNA FIXING PLATE (BOM#260) 261 PTJ62000590 ANTENNA SUPPORT PLATE (BOM#261) 262 PTJ61103642 ANTENNA SNAP (BOM#263) 264 PTJ61103571A POWER SOCKET PLATE (BOM#264) 265 PTJ33300053 IP POWER IN/OUT SOCKET (BOM#265) 266 PTJ33300062 FUSE HOLDER (BOM#267) 268 PTJ21001426			,
249 PTJ32100210 STAND OFF FOR BASE (BOM#249) 250 PTJ21003878A ETHERNET PCB (BOM#250) 251 PTJ33000506A POWER SUPPLY (BOM#251) 252 PTJ61108243 BASE (BOM#253) 253 PTJ61108243 BASE (BOM#253) 254 PTJ32600003B FOOT (BOM#254) 255 PTJ61106103 CLAMP LOCK (BOM#255) 256 PTJ61108817 LOCKING PLATE (BOM#256) 257 PTJ32000809A HM SCREW (BOM#257) 258 PTJ61108818 OMEGA BRACKET (BOM#258) 259 PTJ72000076 ANTENNA (BOM#259) 260 PTJ61101752 ANTENNA FIXING PLATE (BOM#260) 261 PTJ62000590 ANTENNA SUPPORT PLATE (BOM#261) 262 PTJ61103642 ANTENNA SNAP (BOM#263) 264 PTJ61103571A POWER SOCKET PLATE (BOM#264) 265 PTJ33300053 IP POWER IN/OUT SOCKET (BOM#265) 266 PTJ61202090 REAR BASE PLATE (BOM#266) 267 PTJ3330062 FUSE HOLDER (BOM#267) 268 PTJ21003733 <td< td=""><td>249 PTJ32100210 STAND OFF FOR BASE (BOM#249) 250 PTJ21003878A ETHERNET PCB (BOM#250) 251 PTJ33000506A POWER SUPPLY (BOM#251) 252 PTJ61103630A STIFFENING PLATE FOR BASE (BOM#252) 253 PTJ61108243 BASE (BOM#253) 254 PTJ32600003B FOOT (BOM#254) 255 PTJ61106103 CLAMP LOCK (BOM#255) 256 PTJ61108817 LOCKING PLATE (BOM#256) 257 PTJ32000809A HM SCREW (BOM#257) 258 PTJ61108818 OMEGA BRACKET (BOM#258) 259 PTJ72000076 ANTENNA (BOM#259) 260 PTJ6110752 ANTENNA FIXING PLATE (BOM#260) 261 PTJ62000590 ANTENNA HOLDER (BOM#261) 262 PTJ61103642 ANTENNA SNAP (BOM#263) 263 PTJ6200097A ANTENNA SNAP (BOM#263) 264 PTJ61103571A POWER SOCKET PLATE (BOM#264) 265 PTJ33300053 IP POWER IN/OUT SOCKET (BOM#265) 266 PTJ61200290 REAR BASE PLATE (BOM#267) 267 PTJ33300062<</td><td></td><td></td><td>•</td></td<>	249 PTJ32100210 STAND OFF FOR BASE (BOM#249) 250 PTJ21003878A ETHERNET PCB (BOM#250) 251 PTJ33000506A POWER SUPPLY (BOM#251) 252 PTJ61103630A STIFFENING PLATE FOR BASE (BOM#252) 253 PTJ61108243 BASE (BOM#253) 254 PTJ32600003B FOOT (BOM#254) 255 PTJ61106103 CLAMP LOCK (BOM#255) 256 PTJ61108817 LOCKING PLATE (BOM#256) 257 PTJ32000809A HM SCREW (BOM#257) 258 PTJ61108818 OMEGA BRACKET (BOM#258) 259 PTJ72000076 ANTENNA (BOM#259) 260 PTJ6110752 ANTENNA FIXING PLATE (BOM#260) 261 PTJ62000590 ANTENNA HOLDER (BOM#261) 262 PTJ61103642 ANTENNA SNAP (BOM#263) 263 PTJ6200097A ANTENNA SNAP (BOM#263) 264 PTJ61103571A POWER SOCKET PLATE (BOM#264) 265 PTJ33300053 IP POWER IN/OUT SOCKET (BOM#265) 266 PTJ61200290 REAR BASE PLATE (BOM#267) 267 PTJ33300062<			•
250 PTJ21003878A ETHERNET PCB (BOM#250) 251 PTJ33000506A POWER SUPPLY (BOM#251) 252 PTJ61103630A STIFFENING PLATE FOR BASE (BOM#252) 253 PTJ61108243 BASE (BOM#253) 254 PTJ32600003B FOOT (BOM#254) 255 PTJ61106103 CLAMP LOCK (BOM#255) 256 PTJ61108817 LOCKING PLATE (BOM#256) 257 PTJ32000809A HM SCREW (BOM#257) 258 PTJ61108818 OMEGA BRACKET (BOM#258) 259 PTJ72000076 ANTENNA (BOM#259) 260 PTJ61101752 ANTENNA FIXING PLATE (BOM#260) 261 PTJ62000590 ANTENNA HOLDER (BOM#261) 262 PTJ61103642 ANTENNA SNAP (BOM#263) 264 PTJ61103571A POWER SOCKET PLATE (BOM#264) 265 PTJ33300053 IP POWER IN/OUT SOCKET (BOM#265) 266 PTJ61202090 REAR BASE PLATE (BOM#266) 267 PTJ33300062 FUSE HOLDER (BOM#267) 268 PTJ21003733 DMX XLR SOCKET(SPIN) (BOM#268) 270 PTJ6110364	250 PTJ21003878A ETHERNET PCB (BOM#250) 251 PTJ33000506A POWER SUPPLY (BOM#251) 252 PTJ61103630A STIFFENING PLATE FOR BASE (BOM#252) 253 PTJ61108243 BASE (BOM#253) 254 PTJ32600003B FOOT (BOM#254) 255 PTJ61106103 CLAMP LOCK (BOM#255) 256 PTJ61108817 LOCKING PLATE (BOM#256) 257 PTJ32000809A HM SCREW (BOM#257) 258 PTJ61108818 OMEGA BRACKET (BOM#258) 259 PTJ72000076 ANTENNA (BOM#259) 260 PTJ61101752 ANTENNA FIXING PLATE (BOM#260) 261 PTJ62000590 ANTENNA HOLDER (BOM#261) 262 PTJ61103642 ANTENNA SUPPORT PLATE (BOM#262) 263 PTJ62000097A ANTENNA SNAP (BOM#263) 264 PTJ61103571A POWER SOCKET PLATE (BOM#264) 265 PTJ33300053 IP POWER IN/OUT SOCKET (BOM#265) 266 PTJ61202090 REAR BASE PLATE (BOM#267) 267 PTJ333300062 FUSE HOLDER (BOM#277) 270 PTJ6110			
251 PTJ33000506A POWER SUPPLY (BOM#251) 252 PTJ61103630A STIFFENING PLATE FOR BASE (BOM#252) 253 PTJ61108243 BASE (BOM#253) 254 PTJ32600003B FOOT (BOM#254) 255 PTJ61106103 CLAMP LOCK (BOM#255) 256 PTJ61108817 LOCKING PLATE (BOM#256) 257 PTJ32000809A HM SCREW (BOM#257) 258 PTJ61108818 OMEGA BRACKET (BOM#258) 259 PTJ72000076 ANTENNA (BOM#259) 260 PTJ61101752 ANTENNA FIXING PLATE (BOM#260) 261 PTJ62000590 ANTENNA SUPPORT PLATE (BOM#261) 262 PTJ61103642 ANTENNA SNAP (BOM#263) 264 PTJ61103571A POWER SOCKET PLATE (BOM#264) 265 PTJ33300053 IP POWER IN/OUT SOCKET (BOM#265) 266 PTJ61202090 REAR BASE PLATE (BOM#266) 267 PTJ33300062 FUSE HOLDER (BOM#267) 268 PTJ21001426 ETHERNET CONNECTOR (BOM#268) 270 PTJ61103641 HEAT SINK NET HOLDER (BOM#270) 271 <t< td=""><td>251 PTJ33000506A POWER SUPPLY (BOM#251) 252 PTJ61103630A STIFFENING PLATE FOR BASE (BOM#252) 253 PTJ61108243 BASE (BOM#253) 254 PTJ32600003B FOOT (BOM#254) 255 PTJ61106103 CLAMP LOCK (BOM#255) 256 PTJ61108817 LOCKING PLATE (BOM#256) 257 PTJ32000809A HM SCREW (BOM#257) 258 PTJ61108818 OMEGA BRACKET (BOM#258) 259 PTJ72000076 ANTENNA (BOM#259) 260 PTJ6110752 ANTENNA FIXING PLATE (BOM#260) 261 PTJ62000590 ANTENNA SUPPORT PLATE (BOM#261) 262 PTJ61103642 ANTENNA SNAP (BOM#263) 264 PTJ61103571A POWER SOCKET PLATE (BOM#264) 265 PTJ33300053 IP POWER IN/OUT SOCKET (BOM#265) 266 PTJ61202090 REAR BASE PLATE (BOM#266) 267 PTJ33300062 FUSE HOLDER (BOM#267) 268 PTJ21003733 DMX XLR SOCKET(SPIN) (BOM#268) 269 PTJ61103641 HEAT SINK NET HOLDER (BOM#271) 271 <</td><td></td><td>PTJ32100210</td><td></td></t<>	251 PTJ33000506A POWER SUPPLY (BOM#251) 252 PTJ61103630A STIFFENING PLATE FOR BASE (BOM#252) 253 PTJ61108243 BASE (BOM#253) 254 PTJ32600003B FOOT (BOM#254) 255 PTJ61106103 CLAMP LOCK (BOM#255) 256 PTJ61108817 LOCKING PLATE (BOM#256) 257 PTJ32000809A HM SCREW (BOM#257) 258 PTJ61108818 OMEGA BRACKET (BOM#258) 259 PTJ72000076 ANTENNA (BOM#259) 260 PTJ6110752 ANTENNA FIXING PLATE (BOM#260) 261 PTJ62000590 ANTENNA SUPPORT PLATE (BOM#261) 262 PTJ61103642 ANTENNA SNAP (BOM#263) 264 PTJ61103571A POWER SOCKET PLATE (BOM#264) 265 PTJ33300053 IP POWER IN/OUT SOCKET (BOM#265) 266 PTJ61202090 REAR BASE PLATE (BOM#266) 267 PTJ33300062 FUSE HOLDER (BOM#267) 268 PTJ21003733 DMX XLR SOCKET(SPIN) (BOM#268) 269 PTJ61103641 HEAT SINK NET HOLDER (BOM#271) 271 <		PTJ32100210	
252 PTJ61103630A STIFFENING PLATE FOR BASE (BOM#252) 253 PTJ61108243 BASE (BOM#253) 254 PTJ32600003B FOOT (BOM#254) 255 PTJ61106103 CLAMP LOCK (BOM#255) 256 PTJ61108817 LOCKING PLATE (BOM#256) 257 PTJ32000809A HM SCREW (BOM#257) 258 PTJ61108818 OMEGA BRACKET (BOM#258) 259 PTJ72000076 ANTENNA (BOM#259) 260 PTJ61101752 ANTENNA FIXING PLATE (BOM#260) 261 PTJ62000590 ANTENNA SUPPORT PLATE (BOM#2661) 262 PTJ61103642 ANTENNA SUPPORT PLATE (BOM#262) 263 PTJ62000097A ANTENNA SNAP (BOM#263) 264 PTJ61103571A POWER SOCKET PLATE (BOM#264) 265 PTJ33300053 IP POWER IN/OUT SOCKET (BOM#265) 266 PTJ61202090 REAR BASE PLATE (BOM#266) 267 PTJ33300062 FUSE HOLDER (BOM#267) 268 PTJ21001426 ETHERNET CONNECTOR (BOM#278) 270 PTJ61103641 HEAT SINK NET HOLDER (BOM#270) 271	252 PTJ61103630A STIFFENING PLATE FOR BASE (BOM#252) 253 PTJ61108243 BASE (BOM#253) 254 PTJ32600003B FOOT (BOM#254) 255 PTJ61106103 CLAMP LOCK (BOM#255) 256 PTJ61108817 LOCKING PLATE (BOM#256) 257 PTJ32000809A HM SCREW (BOM#257) 258 PTJ61108818 OMEGA BRACKET (BOM#258) 259 PTJ72000076 ANTENNA (BOM#259) 260 PTJ61101752 ANTENNA FIXING PLATE (BOM#260) 261 PTJ62000590 ANTENNA HOLDER (BOM#261) 262 PTJ61103642 ANTENNA SUPPORT PLATE (BOM#262) 263 PTJ62000097A ANTENNA SNAP (BOM#263) 264 PTJ61103571A POWER SOCKET PLATE (BOM#264) 265 PTJ33300053 IP POWER IN/OUT SOCKET (BOM#265) 266 PTJ61202090 REAR BASE PLATE (BOM#266) 267 PTJ33300062 FUSE HOLDER (BOM#267) 268 PTJ21003733 DMX XLR SOCKET (SPIN) (BOM#268) 269 PTJ61103641 HEAT SINK NET HOLDER (BOM#270) 271			,
253 PTJ61108243 BASE (BOM#253) 254 PTJ32600003B FOOT (BOM#254) 255 PTJ61106103 CLAMP LOCK (BOM#255) 256 PTJ61108817 LOCKING PLATE (BOM#256) 257 PTJ32000809A HM SCREW (BOM#257) 258 PTJ61108818 OMEGA BRACKET (BOM#258) 259 PTJ72000076 ANTENNA (BOM#259) 260 PTJ61101752 ANTENNA FIXING PLATE (BOM#260) 261 PTJ62000590 ANTENNA HOLDER (BOM#261) 262 PTJ61103642 ANTENNA SUPPORT PLATE (BOM#262) 263 PTJ6200097A ANTENNA SNAP (BOM#263) 264 PTJ61103571A POWER SOCKET PLATE (BOM#264) 265 PTJ33300053 IP POWER IN/OUT SOCKET (BOM#265) 266 PTJ61202090 REAR BASE PLATE (BOM#266) 267 PTJ33300062 FUSE HOLDER (BOM#267) 268 PTJ21003733 DMX XLR SOCKET(5PIN) (BOM#268) 269 PTJ21003733 DMX XLR SOCKET(5PIN) (BOM#270) 271 PTJ61103641 HEAT SINK NET (BOM#271) 272 PTJ61103	253 PTJ61108243 BASE (BOM#253) 254 PTJ32600003B FOOT (BOM#254) 255 PTJ61106103 CLAMP LOCK (BOM#255) 256 PTJ61108817 LOCKING PLATE (BOM#256) 257 PTJ32000809A HM SCREW (BOM#257) 258 PTJ61108818 OMEGA BRACKET (BOM#258) 259 PTJ72000076 ANTENNA (BOM#259) 260 PTJ61101752 ANTENNA FIXING PLATE (BOM#260) 261 PTJ62000590 ANTENNA BOM#263) 262 PTJ61103642 ANTENNA SUPPORT PLATE (BOM#261) 263 PTJ62000097A ANTENNA SNAP (BOM#263) 264 PTJ61103571A POWER SOCKET PLATE (BOM#264) 265 PTJ33300053 IP POWER IN/OUT SOCKET (BOM#265) 266 PTJ61202090 REAR BASE PLATE (BOM#266) 267 PTJ33300062 FUSE HOLDER (BOM#267) 268 PTJ21003733 DMX XLR SOCKET(SPIN) (BOM#268) 269 PTJ26103641 HEAT SINK NET HOLDER (BOM#270) 271 PTJ61103626 HANDLE SUPPORT PLATE-LEFT (BOM#272) 273 PTJ			
254 PTJ32600003B FOOT (BOM#254) 255 PTJ61106103 CLAMP LOCK (BOM#255) 256 PTJ61108817 LOCKING PLATE (BOM#256) 257 PTJ32000809A HM SCREW (BOM#257) 258 PTJ61108818 OMEGA BRACKET (BOM#258) 259 PTJ72000076 ANTENNA (BOM#259) 260 PTJ61101752 ANTENNA FIXING PLATE (BOM#260) 261 PTJ62000590 ANTENNA HOLDER (BOM#261) 262 PTJ61103642 ANTENNA SUPPORT PLATE (BOM#262) 263 PTJ62000097A ANTENNA SNAP (BOM#263) 264 PTJ61103571A POWER SOCKET PLATE (BOM#264) 265 PTJ33300053 IP POWER IN/OUT SOCKET (BOM#265) 266 PTJ61202090 REAR BASE PLATE (BOM#266) 267 PTJ33300062 FUSE HOLDER (BOM#267) 268 PTJ21001426 ETHERNET CONNECTOR (BOM#268) 269 PTJ21003733 DMX XLR SOCKET(5PIN) (BOM#270) 271 PTJ61103641 HEAT SINK NET (BOM#271) 272 PTJ61103626 HANDLE SUPPORT PLATE-LEFT (BOM#272) 273	254 PTJ32600003B FOOT (BOM#254) 255 PTJ61106103 CLAMP LOCK (BOM#255) 256 PTJ61108817 LOCKING PLATE (BOM#256) 257 PTJ32000809A HM SCREW (BOM#257) 258 PTJ61108818 OMEGA BRACKET (BOM#258) 259 PTJ72000076 ANTENNA (BOM#259) 260 PTJ61101752 ANTENNA FIXING PLATE (BOM#260) 261 PTJ62000590 ANTENNA HOLDER (BOM#261) 262 PTJ61103642 ANTENNA SNAP (BOM#263) 263 PTJ62000097A ANTENNA SNAP (BOM#263) 264 PTJ61103571A POWER SOCKET PLATE (BOM#264) 265 PTJ33300053 IP POWER IN/OUT SOCKET (BOM#265) 266 PTJ61202090 REAR BASE PLATE (BOM#266) 267 PTJ33300062 FUSE HOLDER (BOM#267) 268 PTJ21001426 ETHERNET CONNECTOR (BOM#268) 269 PTJ21003733 DMX XLR SOCKET(SPIN) (BOM#269) 270 PTJ61103641 HEAT SINK NET HOLDER (BOM#270) 271 PTJ61103626 HANDLE SUPPORT PLATE-LEFT (BOM#272) 273			
255 PTJ61106103 CLAMP LOCK (BOM#255) 256 PTJ61108817 LOCKING PLATE (BOM#256) 257 PTJ32000809A HM SCREW (BOM#257) 258 PTJ61108818 OMEGA BRACKET (BOM#258) 259 PTJ72000076 ANTENNA (BOM#259) 260 PTJ61101752 ANTENNA FIXING PLATE (BOM#260) 261 PTJ62000590 ANTENNA HOLDER (BOM#261) 262 PTJ61103642 ANTENNA SUPPORT PLATE (BOM#262) 263 PTJ62000097A ANTENNA SNAP (BOM#263) 264 PTJ61103571A POWER SOCKET PLATE (BOM#264) 265 PTJ33300053 IP POWER IN/OUT SOCKET (BOM#265) 266 PTJ61202090 REAR BASE PLATE (BOM#266) 267 PTJ33300062 FUSE HOLDER (BOM#267) 268 PTJ21001426 ETHERNET CONNECTOR (BOM#268) 269 PTJ21003733 DMX XLR SOCKET(5PIN) (BOM#270) 271 PTJ61103641 HEAT SINK NET HOLDER (BOM#271) 272 PTJ61103626 HANDLE SUPPORT PLATE-LEFT (BOM#272) 273 PTJ6103625 HANDLE SUPPORT PLATE-RIGHT (BOM#273)	255 PTJ61106103 CLAMP LOCK (BOM#255) 256 PTJ61108817 LOCKING PLATE (BOM#256) 257 PTJ32000809A HM SCREW (BOM#257) 258 PTJ61108818 OMEGA BRACKET (BOM#258) 259 PTJ72000076 ANTENNA (BOM#259) 260 PTJ61101752 ANTENNA FIXING PLATE (BOM#260) 261 PTJ62000590 ANTENNA SUPPORT PLATE (BOM#261) 262 PTJ61103642 ANTENNA SUPPORT PLATE (BOM#262) 263 PTJ62000097A ANTENNA SNAP (BOM#263) 264 PTJ61103571A POWER SOCKET PLATE (BOM#264) 265 PTJ33300053 IP POWER IN/OUT SOCKET (BOM#265) 266 PTJ61202090 REAR BASE PLATE (BOM#266) 267 PTJ333300062 FUSE HOLDER (BOM#267) 268 PTJ21001426 ETHERNET CONNECTOR (BOM#268) 269 PTJ21003733 DMX XLR SOCKET(SPIN) (BOM#270) 271 PTJ61103640 HEAT SINK NET HOLDER (BOM#270) 272 PTJ61103626 HANDLE SUPPORT PLATE-LEFT (BOM#272) 273 PTJ61003625 HANDLE SUPPORT PLATE-RIGHT (BOM#273)			
256 PTJ61108817 LOCKING PLATE (BOM#256) 257 PTJ32000809A HM SCREW (BOM#257) 258 PTJ61108818 OMEGA BRACKET (BOM#258) 259 PTJ72000076 ANTENNA (BOM#259) 260 PTJ61101752 ANTENNA FIXING PLATE (BOM#260) 261 PTJ62000590 ANTENNA HOLDER (BOM#261) 262 PTJ61103642 ANTENNA SUPPORT PLATE (BOM#262) 263 PTJ62000097A ANTENNA SNAP (BOM#263) 264 PTJ61103571A POWER SOCKET PLATE (BOM#264) 265 PTJ33300053 IP POWER IN/OUT SOCKET (BOM#265) 266 PTJ61202090 REAR BASE PLATE (BOM#266) 267 PTJ333300062 FUSE HOLDER (BOM#267) 268 PTJ21001426 ETHERNET CONNECTOR (BOM#268) 269 PTJ21003733 DMX XLR SOCKET(5PIN) (BOM#269) 270 PTJ61103641 HEAT SINK NET HOLDER (BOM#270) 271 PTJ61103626 HANDLE SUPPORT PLATE-LEFT (BOM#272) 273 PTJ6103625 HANDLE SUPPORT PLATE-RIGHT (BOM#273) 274 PTJ62000514A BASE COVER (BOM#274)	256 PTJ61108817 LOCKING PLATE (BOM#256) 257 PTJ32000809A HM SCREW (BOM#257) 258 PTJ61108818 OMEGA BRACKET (BOM#258) 259 PTJ72000076 ANTENNA (BOM#259) 260 PTJ61101752 ANTENNA FIXING PLATE (BOM#260) 261 PTJ62000590 ANTENNA HOLDER (BOM#261) 262 PTJ61103642 ANTENNA SUPPORT PLATE (BOM#262) 263 PTJ62000097A ANTENNA SNAP (BOM#263) 264 PTJ61103571A POWER SOCKET PLATE (BOM#264) 265 PTJ33300053 IP POWER IN/OUT SOCKET (BOM#265) 266 PTJ61202090 REAR BASE PLATE (BOM#266) 267 PTJ333300062 FUSE HOLDER (BOM#267) 268 PTJ21001426 ETHERNET CONNECTOR (BOM#268) 269 PTJ21003733 DMX XLR SOCKET(5PIN) (BOM#269) 270 PTJ61103641 HEAT SINK NET HOLDER (BOM#271) 271 PTJ61103626 HANDLE SUPPORT PLATE-LEFT (BOM#272) 273 PTJ61103625 HANDLE SUPPORT PLATE-RIGHT (BOM#273) 274 PTJ62000514A BASE COVER (BOM#274)			· · · · · · · · · · · · · · · · · · ·
257 PTJ32000809A HM SCREW (BOM#257) 258 PTJ61108818 OMEGA BRACKET (BOM#258) 259 PTJ72000076 ANTENNA (BOM#259) 260 PTJ61101752 ANTENNA FIXING PLATE (BOM#260) 261 PTJ62000590 ANTENNA HOLDER (BOM#261) 262 PTJ61103642 ANTENNA SUPPORT PLATE (BOM#262) 263 PTJ62000097A ANTENNA SNAP (BOM#263) 264 PTJ61103571A POWER SOCKET PLATE (BOM#264) 265 PTJ33300053 IP POWER IN/OUT SOCKET (BOM#265) 266 PTJ61202090 REAR BASE PLATE (BOM#266) 267 PTJ33300062 FUSE HOLDER (BOM#267) 268 PTJ21001426 ETHERNET CONNECTOR (BOM#268) 269 PTJ21003733 DMX XLR SOCKET(5PIN) (BOM#269) 270 PTJ61103641 HEAT SINK NET HOLDER (BOM#270) 271 PTJ61103626 HANDLE SUPPORT PLATE-LEFT (BOM#272) 273 PTJ61103625 HANDLE SUPPORT PLATE-RIGHT (BOM#273) 274 PTJ62000514A BASE COVER (BOM#274) 275 PTJ62000511A HANDLE (BOM#276) <tr< td=""><td>257 PTJ32000809A HM SCREW (BOM#257) 258 PTJ61108818 OMEGA BRACKET (BOM#258) 259 PTJ72000076 ANTENNA (BOM#259) 260 PTJ61101752 ANTENNA FIXING PLATE (BOM#260) 261 PTJ62000590 ANTENNA HOLDER (BOM#261) 262 PTJ61103642 ANTENNA SUPPORT PLATE (BOM#262) 263 PTJ62000097A ANTENNA SNAP (BOM#263) 264 PTJ61103571A POWER SOCKET PLATE (BOM#264) 265 PTJ33300053 IP POWER IN/OUT SOCKET (BOM#265) 266 PTJ61202090 REAR BASE PLATE (BOM#266) 267 PTJ33300062 FUSE HOLDER (BOM#267) 268 PTJ21001426 ETHERNET CONNECTOR (BOM#268) 269 PTJ21003733 DMX XLR SOCKET(5PIN) (BOM#269) 270 PTJ61103641 HEAT SINK NET HOLDER (BOM#270) 271 PTJ61103626 HANDLE SUPPORT PLATE-LEFT (BOM#272) 273 PTJ61103625 HANDLE SUPPORT PLATE-RIGHT (BOM#273) 274 PTJ62000511A HANDLE (BOM#275) 275 PTJ62000511A HANDLE (BOM#276)</td><td></td><td></td><td></td></tr<>	257 PTJ32000809A HM SCREW (BOM#257) 258 PTJ61108818 OMEGA BRACKET (BOM#258) 259 PTJ72000076 ANTENNA (BOM#259) 260 PTJ61101752 ANTENNA FIXING PLATE (BOM#260) 261 PTJ62000590 ANTENNA HOLDER (BOM#261) 262 PTJ61103642 ANTENNA SUPPORT PLATE (BOM#262) 263 PTJ62000097A ANTENNA SNAP (BOM#263) 264 PTJ61103571A POWER SOCKET PLATE (BOM#264) 265 PTJ33300053 IP POWER IN/OUT SOCKET (BOM#265) 266 PTJ61202090 REAR BASE PLATE (BOM#266) 267 PTJ33300062 FUSE HOLDER (BOM#267) 268 PTJ21001426 ETHERNET CONNECTOR (BOM#268) 269 PTJ21003733 DMX XLR SOCKET(5PIN) (BOM#269) 270 PTJ61103641 HEAT SINK NET HOLDER (BOM#270) 271 PTJ61103626 HANDLE SUPPORT PLATE-LEFT (BOM#272) 273 PTJ61103625 HANDLE SUPPORT PLATE-RIGHT (BOM#273) 274 PTJ62000511A HANDLE (BOM#275) 275 PTJ62000511A HANDLE (BOM#276)			
258 PTJ61108818 OMEGA BRACKET (BOM#258) 259 PTJ72000076 ANTENNA (BOM#259) 260 PTJ61101752 ANTENNA FIXING PLATE (BOM#260) 261 PTJ62000590 ANTENNA HOLDER (BOM#261) 262 PTJ61103642 ANTENNA SUPPORT PLATE (BOM#262) 263 PTJ62000097A ANTENNA SNAP (BOM#263) 264 PTJ61103571A POWER SOCKET PLATE (BOM#264) 265 PTJ33300053 IP POWER IN/OUT SOCKET (BOM#264) 266 PTJ61202090 REAR BASE PLATE (BOM#266) 267 PTJ33300062 FUSE HOLDER (BOM#267) 268 PTJ21001426 ETHERNET CONNECTOR (BOM#268) 269 PTJ21003733 DMX XLR SOCKET(5PIN) (BOM#269) 270 PTJ61103641 HEAT SINK NET HOLDER (BOM#270) 271 PTJ61103626 HANDLE SUPPORT PLATE-LEFT (BOM#272) 273 PTJ61103625 HANDLE SUPPORT PLATE-RIGHT (BOM#273) 274 PTJ62000514A BASE COVER (BOM#274) 275 PTJ62000511A HANDLE (BOM#275) 276 PTJ21003971B MPCB (BOM#276)	258 PTJ61108818 OMEGA BRACKET (BOM#258) 259 PTJ72000076 ANTENNA (BOM#259) 260 PTJ61101752 ANTENNA FIXING PLATE (BOM#260) 261 PTJ62000590 ANTENNA HOLDER (BOM#261) 262 PTJ61103642 ANTENNA SUPPORT PLATE (BOM#262) 263 PTJ62000097A ANTENNA SNAP (BOM#263) 264 PTJ61103571A POWER SOCKET PLATE (BOM#264) 265 PTJ33300053 IP POWER IN/OUT SOCKET (BOM#265) 266 PTJ61202090 REAR BASE PLATE (BOM#266) 267 PTJ33300062 FUSE HOLDER (BOM#267) 268 PTJ21001426 ETHERNET CONNECTOR (BOM#268) 269 PTJ21003733 DMX XLR SOCKET(5PIN) (BOM#269) 270 PTJ61103641 HEAT SINK NET HOLDER (BOM#270) 271 PTJ61103626 HANDLE SUPPORT PLATE-LEFT (BOM#272) 273 PTJ61103625 HANDLE SUPPORT PLATE-RIGHT (BOM#273) 274 PTJ62000514A BASE COVER (BOM#274) 275 PTJ62000511A HANDLE (BOM#275) 276 PTJ21003971B MPCB (BOM#276)			
259 PTJ72000076 ANTENNA (BOM#259) 260 PTJ61101752 ANTENNA FIXING PLATE (BOM#260) 261 PTJ62000590 ANTENNA HOLDER (BOM#261) 262 PTJ61103642 ANTENNA SUPPORT PLATE (BOM#262) 263 PTJ62000097A ANTENNA SNAP (BOM#263) 264 PTJ61103571A POWER SOCKET PLATE (BOM#264) 265 PTJ33300053 IP POWER IN/OUT SOCKET (BOM#265) 266 PTJ61202090 REAR BASE PLATE (BOM#266) 267 PTJ33300062 FUSE HOLDER (BOM#267) 268 PTJ21001426 ETHERNET CONNECTOR (BOM#268) 269 PTJ21003733 DMX XLR SOCKET(5PIN) (BOM#269) 270 PTJ61103641 HEAT SINK NET HOLDER (BOM#270) 271 PTJ61103640 HEAT SINK NET (BOM#271) 272 PTJ61103626 HANDLE SUPPORT PLATE-LEFT (BOM#272) 273 PTJ62000514A BASE COVER (BOM#274) 275 PTJ62000511A HANDLE (BOM#275) 276 PTJ21003971B MPCB (BOM#276) 277 PTJ62100111 BUTTON COVER (BOM#278) 278<	259 PTJ72000076 ANTENNA (BOM#259) 260 PTJ61101752 ANTENNA FIXING PLATE (BOM#260) 261 PTJ62000590 ANTENNA HOLDER (BOM#261) 262 PTJ61103642 ANTENNA SUPPORT PLATE (BOM#262) 263 PTJ62000097A ANTENNA SNAP (BOM#263) 264 PTJ61103571A POWER SOCKET PLATE (BOM#264) 265 PTJ33300053 IP POWER IN/OUT SOCKET (BOM#265) 266 PTJ61202090 REAR BASE PLATE (BOM#266) 267 PTJ33300062 FUSE HOLDER (BOM#267) 268 PTJ21001426 ETHERNET CONNECTOR (BOM#268) 269 PTJ21003733 DMX XLR SOCKET(5PIN) (BOM#269) 270 PTJ61103641 HEAT SINK NET HOLDER (BOM#270) 271 PTJ61103640 HEAT SINK NET (BOM#271) 272 PTJ61103626 HANDLE SUPPORT PLATE-LEFT (BOM#272) 273 PTJ61103625 HANDLE SUPPORT PLATE-RIGHT (BOM#273) 274 PTJ62000514A BASE COVER (BOM#276) 275 PTJ62000511A HANDLE (BOM#276) 276 PTJ21003971B MPCB (BOM#276)			,
260 PTJ61101752 ANTENNA FIXING PLATE (BOM#260) 261 PTJ62000590 ANTENNA HOLDER (BOM#261) 262 PTJ61103642 ANTENNA SUPPORT PLATE (BOM#262) 263 PTJ62000097A ANTENNA SNAP (BOM#263) 264 PTJ61103571A POWER SOCKET PLATE (BOM#264) 265 PTJ33300053 IP POWER IN/OUT SOCKET (BOM#265) 266 PTJ61202090 REAR BASE PLATE (BOM#266) 267 PTJ33300062 FUSE HOLDER (BOM#267) 268 PTJ21001426 ETHERNET CONNECTOR (BOM#268) 269 PTJ21003733 DMX XLR SOCKET(5PIN) (BOM#269) 270 PTJ61103641 HEAT SINK NET HOLDER (BOM#270) 271 PTJ61103640 HEAT SINK NET (BOM#271) 272 PTJ61103626 HANDLE SUPPORT PLATE-LEFT (BOM#272) 273 PTJ6103625 HANDLE SUPPORT PLATE-RIGHT (BOM#273) 274 PTJ62000514A BASE COVER (BOM#274) 275 PTJ62000511A HANDLE (BOM#275) 276 PTJ21003971B MPCB (BOM#276) 277 PTJ62100111 BUTTON COVER (BOM#277) 278 PTJ61202092 FRONT BASE COVER (BOM#278) <td>260 PTJ61101752 ANTENNA FIXING PLATE (BOM#260) 261 PTJ62000590 ANTENNA HOLDER (BOM#261) 262 PTJ61103642 ANTENNA SUPPORT PLATE (BOM#262) 263 PTJ62000097A ANTENNA SNAP (BOM#263) 264 PTJ61103571A POWER SOCKET PLATE (BOM#264) 265 PTJ33300053 IP POWER IN/OUT SOCKET (BOM#265) 266 PTJ61202090 REAR BASE PLATE (BOM#266) 267 PTJ33300062 FUSE HOLDER (BOM#267) 268 PTJ21001426 ETHERNET CONNECTOR (BOM#268) 269 PTJ21003733 DMX XLR SOCKET(5PIN) (BOM#269) 270 PTJ61103641 HEAT SINK NET HOLDER (BOM#270) 271 PTJ61103640 HEAT SINK NET (BOM#271) 272 PTJ61103626 HANDLE SUPPORT PLATE-LEFT (BOM#272) 273 PTJ62000514A BASE COVER (BOM#274) 275 PTJ62000511A HANDLE (BOM#275) 276 PTJ21003971B MPCB (BOM#276) 277 PTJ62100111 BUTTON COVER (BOM#277) 278 PTJ61000827 USB ADAPTER PLATE (BOM#279)</td> <td></td> <td></td> <td></td>	260 PTJ61101752 ANTENNA FIXING PLATE (BOM#260) 261 PTJ62000590 ANTENNA HOLDER (BOM#261) 262 PTJ61103642 ANTENNA SUPPORT PLATE (BOM#262) 263 PTJ62000097A ANTENNA SNAP (BOM#263) 264 PTJ61103571A POWER SOCKET PLATE (BOM#264) 265 PTJ33300053 IP POWER IN/OUT SOCKET (BOM#265) 266 PTJ61202090 REAR BASE PLATE (BOM#266) 267 PTJ33300062 FUSE HOLDER (BOM#267) 268 PTJ21001426 ETHERNET CONNECTOR (BOM#268) 269 PTJ21003733 DMX XLR SOCKET(5PIN) (BOM#269) 270 PTJ61103641 HEAT SINK NET HOLDER (BOM#270) 271 PTJ61103640 HEAT SINK NET (BOM#271) 272 PTJ61103626 HANDLE SUPPORT PLATE-LEFT (BOM#272) 273 PTJ62000514A BASE COVER (BOM#274) 275 PTJ62000511A HANDLE (BOM#275) 276 PTJ21003971B MPCB (BOM#276) 277 PTJ62100111 BUTTON COVER (BOM#277) 278 PTJ61000827 USB ADAPTER PLATE (BOM#279)			
261 PTJ62000590 ANTENNA HOLDER (BOM#261) 262 PTJ61103642 ANTENNA SUPPORT PLATE (BOM#262) 263 PTJ62000097A ANTENNA SNAP (BOM#263) 264 PTJ61103571A POWER SOCKET PLATE (BOM#264) 265 PTJ33300053 IP POWER IN/OUT SOCKET (BOM#265) 266 PTJ61202090 REAR BASE PLATE (BOM#266) 267 PTJ33300062 FUSE HOLDER (BOM#267) 268 PTJ21001426 ETHERNET CONNECTOR (BOM#268) 269 PTJ21003733 DMX XLR SOCKET(5PIN) (BOM#269) 270 PTJ61103641 HEAT SINK NET HOLDER (BOM#270) 271 PTJ61103640 HEAT SINK NET (BOM#271) 272 PTJ61103626 HANDLE SUPPORT PLATE-LEFT (BOM#272) 273 PTJ61103625 HANDLE SUPPORT PLATE-RIGHT (BOM#273) 274 PTJ62000514A BASE COVER (BOM#274) 275 PTJ62000511A HANDLE (BOM#275) 276 PTJ21003971B MPCB (BOM#276) 277 PTJ62100111 BUTTON COVER (BOM#277) 278 PTJ61202092 FRONT BASE COVER (BOM#278)	261 PTJ62000590 ANTENNA HOLDER (BOM#261) 262 PTJ61103642 ANTENNA SUPPORT PLATE (BOM#262) 263 PTJ62000097A ANTENNA SNAP (BOM#263) 264 PTJ61103571A POWER SOCKET PLATE (BOM#264) 265 PTJ33300053 IP POWER IN/OUT SOCKET (BOM#265) 266 PTJ61202090 REAR BASE PLATE (BOM#266) 267 PTJ33300062 FUSE HOLDER (BOM#267) 268 PTJ21001426 ETHERNET CONNECTOR (BOM#268) 269 PTJ21003733 DMX XLR SOCKET(5PIN) (BOM#269) 270 PTJ61103641 HEAT SINK NET HOLDER (BOM#270) 271 PTJ61103640 HEAT SINK NET (BOM#271) 272 PTJ61103626 HANDLE SUPPORT PLATE-LEFT (BOM#272) 273 PTJ61103625 HANDLE SUPPORT PLATE-RIGHT (BOM#273) 274 PTJ62000514A BASE COVER (BOM#274) 275 PTJ62000511A HANDLE (BOM#275) 276 PTJ21003971B MPCB (BOM#276) 277 PTJ62100111 BUTTON COVER (BOM#277) 278 PTJ61202092 FRONT BASE COVER (BOM#278) 279 PTJ21000827 USB ADAPTER PLATE (BOM#279)			
262 PTJ61103642 ANTENNA SUPPORT PLATE (BOM#262) 263 PTJ62000097A ANTENNA SNAP (BOM#263) 264 PTJ61103571A POWER SOCKET PLATE (BOM#264) 265 PTJ33300053 IP POWER IN/OUT SOCKET (BOM#265) 266 PTJ61202090 REAR BASE PLATE (BOM#266) 267 PTJ33300062 FUSE HOLDER (BOM#267) 268 PTJ21001426 ETHERNET CONNECTOR (BOM#268) 269 PTJ21003733 DMX XLR SOCKET(5PIN) (BOM#269) 270 PTJ61103641 HEAT SINK NET HOLDER (BOM#270) 271 PTJ61103640 HEAT SINK NET (BOM#271) 272 PTJ61103626 HANDLE SUPPORT PLATE-LEFT (BOM#272) 273 PTJ61103625 HANDLE SUPPORT PLATE-RIGHT (BOM#273) 274 PTJ62000514A BASE COVER (BOM#274) 275 PTJ62000511A HANDLE (BOM#275) 276 PTJ21003971B MPCB (BOM#276) 277 PTJ62100111 BUTTON COVER (BOM#277) 278 PTJ61202092 FRONT BASE COVER (BOM#278)	262 PTJ61103642 ANTENNA SUPPORT PLATE (BOM#262) 263 PTJ62000097A ANTENNA SNAP (BOM#263) 264 PTJ61103571A POWER SOCKET PLATE (BOM#264) 265 PTJ33300053 IP POWER IN/OUT SOCKET (BOM#265) 266 PTJ61202090 REAR BASE PLATE (BOM#266) 267 PTJ33300062 FUSE HOLDER (BOM#267) 268 PTJ21001426 ETHERNET CONNECTOR (BOM#268) 269 PTJ21003733 DMX XLR SOCKET(5PIN) (BOM#269) 270 PTJ61103641 HEAT SINK NET HOLDER (BOM#270) 271 PTJ61103640 HEAT SINK NET (BOM#271) 272 PTJ61103626 HANDLE SUPPORT PLATE-LEFT (BOM#272) 273 PTJ61103625 HANDLE SUPPORT PLATE-RIGHT (BOM#273) 274 PTJ62000514A BASE COVER (BOM#274) 275 PTJ62000511A HANDLE (BOM#275) 276 PTJ21003971B MPCB (BOM#276) 277 PTJ62100111 BUTTON COVER (BOM#277) 278 PTJ61202092 FRONT BASE COVER (BOM#278) 279 PTJ21000827 USB ADAPTER PLATE (BOM#279)			
263 PTJ62000097A ANTENNA SNAP (BOM#263) 264 PTJ61103571A POWER SOCKET PLATE (BOM#264) 265 PTJ33300053 IP POWER IN/OUT SOCKET (BOM#265) 266 PTJ61202090 REAR BASE PLATE (BOM#266) 267 PTJ33300062 FUSE HOLDER (BOM#267) 268 PTJ21001426 ETHERNET CONNECTOR (BOM#268) 269 PTJ21003733 DMX XLR SOCKET(5PIN) (BOM#269) 270 PTJ61103641 HEAT SINK NET HOLDER (BOM#270) 271 PTJ61103640 HEAT SINK NET (BOM#271) 272 PTJ61103626 HANDLE SUPPORT PLATE-LEFT (BOM#272) 273 PTJ61103625 HANDLE SUPPORT PLATE-RIGHT (BOM#273) 274 PTJ62000514A BASE COVER (BOM#274) 275 PTJ62000511A HANDLE (BOM#275) 276 PTJ21003971B MPCB (BOM#276) 277 PTJ62100111 BUTTON COVER (BOM#277) 278 PTJ61202092 FRONT BASE COVER (BOM#278)	263 PTJ62000097A ANTENNA SNAP (BOM#263) 264 PTJ61103571A POWER SOCKET PLATE (BOM#264) 265 PTJ33300053 IP POWER IN/OUT SOCKET (BOM#265) 266 PTJ61202090 REAR BASE PLATE (BOM#266) 267 PTJ33300062 FUSE HOLDER (BOM#267) 268 PTJ21001426 ETHERNET CONNECTOR (BOM#268) 269 PTJ21003733 DMX XLR SOCKET(5PIN) (BOM#269) 270 PTJ61103641 HEAT SINK NET HOLDER (BOM#270) 271 PTJ61103640 HEAT SINK NET (BOM#271) 272 PTJ61103626 HANDLE SUPPORT PLATE-LEFT (BOM#272) 273 PTJ61103625 HANDLE SUPPORT PLATE-RIGHT (BOM#273) 274 PTJ62000514A BASE COVER (BOM#274) 275 PTJ62000511A HANDLE (BOM#275) 276 PTJ21003971B MPCB (BOM#276) 277 PTJ62100111 BUTTON COVER (BOM#277) 278 PTJ61202092 FRONT BASE COVER (BOM#278) 279 PTJ21000827 USB ADAPTER PLATE (BOM#279)			• •
264 PTJ61103571A POWER SOCKET PLATE (BOM#264) 265 PTJ33300053 IP POWER IN/OUT SOCKET (BOM#265) 266 PTJ61202090 REAR BASE PLATE (BOM#266) 267 PTJ33300062 FUSE HOLDER (BOM#267) 268 PTJ21001426 ETHERNET CONNECTOR (BOM#268) 269 PTJ21003733 DMX XLR SOCKET(5PIN) (BOM#269) 270 PTJ61103641 HEAT SINK NET HOLDER (BOM#270) 271 PTJ61103640 HEAT SINK NET (BOM#271) 272 PTJ61103626 HANDLE SUPPORT PLATE-LEFT (BOM#272) 273 PTJ6103625 HANDLE SUPPORT PLATE-RIGHT (BOM#273) 274 PTJ62000514A BASE COVER (BOM#274) 275 PTJ62000511A HANDLE (BOM#275) 276 PTJ21003971B MPCB (BOM#276) 277 PTJ62100111 BUTTON COVER (BOM#277) 278 PTJ61202092 FRONT BASE COVER (BOM#278)	264 PTJ61103571A POWER SOCKET PLATE (BOM#264) 265 PTJ33300053 IP POWER IN/OUT SOCKET (BOM#265) 266 PTJ61202090 REAR BASE PLATE (BOM#266) 267 PTJ33300062 FUSE HOLDER (BOM#267) 268 PTJ21001426 ETHERNET CONNECTOR (BOM#268) 269 PTJ21003733 DMX XLR SOCKET(5PIN) (BOM#269) 270 PTJ61103641 HEAT SINK NET HOLDER (BOM#270) 271 PTJ61103640 HEAT SINK NET (BOM#271) 272 PTJ61103626 HANDLE SUPPORT PLATE-LEFT (BOM#272) 273 PTJ61103625 HANDLE SUPPORT PLATE-RIGHT (BOM#273) 274 PTJ62000514A BASE COVER (BOM#274) 275 PTJ62000511A HANDLE (BOM#275) 276 PTJ21003971B MPCB (BOM#276) 277 PTJ62100111 BUTTON COVER (BOM#277) 278 PTJ61202092 FRONT BASE COVER (BOM#278) 279 PTJ21000827 USB ADAPTER PLATE (BOM#279)			,
265 PTJ33300053 IP POWER IN/OUT SOCKET (BOM#265) 266 PTJ61202090 REAR BASE PLATE (BOM#266) 267 PTJ33300062 FUSE HOLDER (BOM#267) 268 PTJ21001426 ETHERNET CONNECTOR (BOM#268) 269 PTJ21003733 DMX XLR SOCKET(5PIN) (BOM#269) 270 PTJ61103641 HEAT SINK NET HOLDER (BOM#270) 271 PTJ61103640 HEAT SINK NET (BOM#271) 272 PTJ61103626 HANDLE SUPPORT PLATE-LEFT (BOM#272) 273 PTJ61103625 HANDLE SUPPORT PLATE-RIGHT (BOM#273) 274 PTJ62000514A BASE COVER (BOM#274) 275 PTJ62000511A HANDLE (BOM#275) 276 PTJ21003971B MPCB (BOM#276) 277 PTJ62100111 BUTTON COVER (BOM#277) 278 PTJ61202092 FRONT BASE COVER (BOM#278)	265 PTJ33300053 IP POWER IN/OUT SOCKET (BOM#265) 266 PTJ61202090 REAR BASE PLATE (BOM#266) 267 PTJ33300062 FUSE HOLDER (BOM#267) 268 PTJ21001426 ETHERNET CONNECTOR (BOM#268) 269 PTJ21003733 DMX XLR SOCKET(5PIN) (BOM#269) 270 PTJ61103641 HEAT SINK NET HOLDER (BOM#270) 271 PTJ61103640 HEAT SINK NET (BOM#271) 272 PTJ61103626 HANDLE SUPPORT PLATE-LEFT (BOM#272) 273 PTJ61103625 HANDLE SUPPORT PLATE-RIGHT (BOM#273) 274 PTJ62000514A BASE COVER (BOM#274) 275 PTJ62000511A HANDLE (BOM#275) 276 PTJ21003971B MPCB (BOM#276) 277 PTJ62100111 BUTTON COVER (BOM#277) 278 PTJ61202092 FRONT BASE COVER (BOM#278) 279 PTJ21000827 USB ADAPTER PLATE (BOM#279)			,
266 PTJ61202090 REAR BASE PLATE (BOM#266) 267 PTJ33300062 FUSE HOLDER (BOM#267) 268 PTJ21001426 ETHERNET CONNECTOR (BOM#268) 269 PTJ21003733 DMX XLR SOCKET(5PIN) (BOM#269) 270 PTJ61103641 HEAT SINK NET HOLDER (BOM#270) 271 PTJ61103640 HEAT SINK NET (BOM#271) 272 PTJ61103626 HANDLE SUPPORT PLATE-LEFT (BOM#272) 273 PTJ61103625 HANDLE SUPPORT PLATE-RIGHT (BOM#273) 274 PTJ62000514A BASE COVER (BOM#274) 275 PTJ62000511A HANDLE (BOM#275) 276 PTJ21003971B MPCB (BOM#276) 277 PTJ62100111 BUTTON COVER (BOM#277) 278 PTJ61202092 FRONT BASE COVER (BOM#278)	266 PTJ61202090 REAR BASE PLATE (BOM#266) 267 PTJ33300062 FUSE HOLDER (BOM#267) 268 PTJ21001426 ETHERNET CONNECTOR (BOM#268) 269 PTJ21003733 DMX XLR SOCKET(5PIN) (BOM#269) 270 PTJ61103641 HEAT SINK NET HOLDER (BOM#270) 271 PTJ61103640 HEAT SINK NET (BOM#271) 272 PTJ61103626 HANDLE SUPPORT PLATE-LEFT (BOM#272) 273 PTJ61103625 HANDLE SUPPORT PLATE-RIGHT (BOM#273) 274 PTJ62000514A BASE COVER (BOM#274) 275 PTJ62000511A HANDLE (BOM#275) 276 PTJ21003971B MPCB (BOM#276) 277 PTJ62100111 BUTTON COVER (BOM#277) 278 PTJ61202092 FRONT BASE COVER (BOM#278) 279 PTJ21000827 USB ADAPTER PLATE (BOM#279)			,
267 PTJ33300062 FUSE HOLDER (BOM#267) 268 PTJ21001426 ETHERNET CONNECTOR (BOM#268) 269 PTJ21003733 DMX XLR SOCKET(5PIN) (BOM#269) 270 PTJ61103641 HEAT SINK NET HOLDER (BOM#270) 271 PTJ61103640 HEAT SINK NET (BOM#271) 272 PTJ61103626 HANDLE SUPPORT PLATE-LEFT (BOM#272) 273 PTJ61103625 HANDLE SUPPORT PLATE-RIGHT (BOM#273) 274 PTJ62000514A BASE COVER (BOM#274) 275 PTJ62000511A HANDLE (BOM#275) 276 PTJ21003971B MPCB (BOM#276) 277 PTJ62100111 BUTTON COVER (BOM#277) 278 PTJ61202092 FRONT BASE COVER (BOM#278)	267 PTJ33300062 FUSE HOLDER (BOM#267) 268 PTJ21001426 ETHERNET CONNECTOR (BOM#268) 269 PTJ21003733 DMX XLR SOCKET(5PIN) (BOM#269) 270 PTJ61103641 HEAT SINK NET HOLDER (BOM#270) 271 PTJ61103640 HEAT SINK NET (BOM#271) 272 PTJ61103626 HANDLE SUPPORT PLATE-LEFT (BOM#272) 273 PTJ61103625 HANDLE SUPPORT PLATE-RIGHT (BOM#273) 274 PTJ62000514A BASE COVER (BOM#274) 275 PTJ62000511A HANDLE (BOM#275) 276 PTJ21003971B MPCB (BOM#276) 277 PTJ62100111 BUTTON COVER (BOM#277) 278 PTJ61202092 FRONT BASE COVER (BOM#278) 279 PTJ21000827 USB ADAPTER PLATE (BOM#279)			•
268 PTJ21001426 ETHERNET CONNECTOR (BOM#268) 269 PTJ21003733 DMX XLR SOCKET(5PIN) (BOM#269) 270 PTJ61103641 HEAT SINK NET HOLDER (BOM#270) 271 PTJ61103640 HEAT SINK NET (BOM#271) 272 PTJ61103626 HANDLE SUPPORT PLATE-LEFT (BOM#272) 273 PTJ61103625 HANDLE SUPPORT PLATE-RIGHT (BOM#273) 274 PTJ62000514A BASE COVER (BOM#274) 275 PTJ62000511A HANDLE (BOM#275) 276 PTJ21003971B MPCB (BOM#276) 277 PTJ62100111 BUTTON COVER (BOM#277) 278 PTJ61202092 FRONT BASE COVER (BOM#278)	268 PTJ21001426 ETHERNET CONNECTOR (BOM#268) 269 PTJ21003733 DMX XLR SOCKET(5PIN) (BOM#269) 270 PTJ61103641 HEAT SINK NET HOLDER (BOM#270) 271 PTJ61103640 HEAT SINK NET (BOM#271) 272 PTJ61103626 HANDLE SUPPORT PLATE-LEFT (BOM#272) 273 PTJ61103625 HANDLE SUPPORT PLATE-RIGHT (BOM#273) 274 PTJ62000514A BASE COVER (BOM#274) 275 PTJ62000511A HANDLE (BOM#275) 276 PTJ21003971B MPCB (BOM#276) 277 PTJ62100111 BUTTON COVER (BOM#277) 278 PTJ61202092 FRONT BASE COVER (BOM#278) 279 PTJ21000827 USB ADAPTER PLATE (BOM#279)			
269 PTJ21003733 DMX XLR SOCKET(5PIN) (BOM#269) 270 PTJ61103641 HEAT SINK NET HOLDER (BOM#270) 271 PTJ61103640 HEAT SINK NET (BOM#271) 272 PTJ61103626 HANDLE SUPPORT PLATE-LEFT (BOM#272) 273 PTJ61103625 HANDLE SUPPORT PLATE-RIGHT (BOM#273) 274 PTJ62000514A BASE COVER (BOM#274) 275 PTJ62000511A HANDLE (BOM#275) 276 PTJ21003971B MPCB (BOM#276) 277 PTJ62100111 BUTTON COVER (BOM#277) 278 PTJ61202092 FRONT BASE COVER (BOM#278)	269 PTJ21003733 DMX XLR SOCKET(5PIN) (BOM#269) 270 PTJ61103641 HEAT SINK NET HOLDER (BOM#270) 271 PTJ61103640 HEAT SINK NET (BOM#271) 272 PTJ61103626 HANDLE SUPPORT PLATE-LEFT (BOM#272) 273 PTJ61103625 HANDLE SUPPORT PLATE-RIGHT (BOM#273) 274 PTJ62000514A BASE COVER (BOM#274) 275 PTJ62000511A HANDLE (BOM#275) 276 PTJ21003971B MPCB (BOM#276) 277 PTJ62100111 BUTTON COVER (BOM#277) 278 PTJ61202092 FRONT BASE COVER (BOM#278) 279 PTJ21000827 USB ADAPTER PLATE (BOM#279)			•
270 PTJ61103641 HEAT SINK NET HOLDER (BOM#270) 271 PTJ61103640 HEAT SINK NET (BOM#271) 272 PTJ61103626 HANDLE SUPPORT PLATE-LEFT (BOM#272) 273 PTJ61103625 HANDLE SUPPORT PLATE-RIGHT (BOM#273) 274 PTJ62000514A BASE COVER (BOM#274) 275 PTJ62000511A HANDLE (BOM#275) 276 PTJ21003971B MPCB (BOM#276) 277 PTJ62100111 BUTTON COVER (BOM#277) 278 PTJ61202092 FRONT BASE COVER (BOM#278)	270 PTJ61103641 HEAT SINK NET HOLDER (BOM#270) 271 PTJ61103640 HEAT SINK NET (BOM#271) 272 PTJ61103626 HANDLE SUPPORT PLATE-LEFT (BOM#272) 273 PTJ61103625 HANDLE SUPPORT PLATE-RIGHT (BOM#273) 274 PTJ62000514A BASE COVER (BOM#274) 275 PTJ62000511A HANDLE (BOM#275) 276 PTJ21003971B MPCB (BOM#276) 277 PTJ62100111 BUTTON COVER (BOM#277) 278 PTJ61202092 FRONT BASE COVER (BOM#278) 279 PTJ21000827 USB ADAPTER PLATE (BOM#279)			,
271 PTJ61103640 HEAT SINK NET (BOM#271) 272 PTJ61103626 HANDLE SUPPORT PLATE-LEFT (BOM#272) 273 PTJ61103625 HANDLE SUPPORT PLATE-RIGHT (BOM#273) 274 PTJ62000514A BASE COVER (BOM#274) 275 PTJ62000511A HANDLE (BOM#275) 276 PTJ21003971B MPCB (BOM#276) 277 PTJ62100111 BUTTON COVER (BOM#277) 278 PTJ61202092 FRONT BASE COVER (BOM#278)	271 PTJ61103640 HEAT SINK NET (BOM#271) 272 PTJ61103626 HANDLE SUPPORT PLATE-LEFT (BOM#272) 273 PTJ61103625 HANDLE SUPPORT PLATE-RIGHT (BOM#273) 274 PTJ62000514A BASE COVER (BOM#274) 275 PTJ62000511A HANDLE (BOM#275) 276 PTJ21003971B MPCB (BOM#276) 277 PTJ62100111 BUTTON COVER (BOM#277) 278 PTJ61202092 FRONT BASE COVER (BOM#278) 279 PTJ21000827 USB ADAPTER PLATE (BOM#279)			* * * * * * * * * * * * * * * * * * * *
272 PTJ61103626 HANDLE SUPPORT PLATE-LEFT (BOM#272) 273 PTJ61103625 HANDLE SUPPORT PLATE-RIGHT (BOM#273) 274 PTJ62000514A BASE COVER (BOM#274) 275 PTJ62000511A HANDLE (BOM#275) 276 PTJ21003971B MPCB (BOM#276) 277 PTJ62100111 BUTTON COVER (BOM#277) 278 PTJ61202092 FRONT BASE COVER (BOM#278)	272 PTJ61103626 HANDLE SUPPORT PLATE-LEFT (BOM#272) 273 PTJ61103625 HANDLE SUPPORT PLATE-RIGHT (BOM#273) 274 PTJ62000514A BASE COVER (BOM#274) 275 PTJ62000511A HANDLE (BOM#275) 276 PTJ21003971B MPCB (BOM#276) 277 PTJ62100111 BUTTON COVER (BOM#277) 278 PTJ61202092 FRONT BASE COVER (BOM#278) 279 PTJ21000827 USB ADAPTER PLATE (BOM#279)			, ,
273 PTJ61103625 HANDLE SUPPORT PLATE-RIGHT (BOM#273) 274 PTJ62000514A BASE COVER (BOM#274) 275 PTJ62000511A HANDLE (BOM#275) 276 PTJ21003971B MPCB (BOM#276) 277 PTJ62100111 BUTTON COVER (BOM#277) 278 PTJ61202092 FRONT BASE COVER (BOM#278)	273 PTJ61103625 HANDLE SUPPORT PLATE-RIGHT (BOM#273) 274 PTJ62000514A BASE COVER (BOM#274) 275 PTJ62000511A HANDLE (BOM#275) 276 PTJ21003971B MPCB (BOM#276) 277 PTJ62100111 BUTTON COVER (BOM#277) 278 PTJ61202092 FRONT BASE COVER (BOM#278) 279 PTJ21000827 USB ADAPTER PLATE (BOM#279)			
274 PTJ62000514A BASE COVER (BOM#274) 275 PTJ62000511A HANDLE (BOM#275) 276 PTJ21003971B MPCB (BOM#276) 277 PTJ62100111 BUTTON COVER (BOM#277) 278 PTJ61202092 FRONT BASE COVER (BOM#278)	274 PTJ62000514A BASE COVER (BOM#274) 275 PTJ62000511A HANDLE (BOM#275) 276 PTJ21003971B MPCB (BOM#276) 277 PTJ62100111 BUTTON COVER (BOM#277) 278 PTJ61202092 FRONT BASE COVER (BOM#278) 279 PTJ21000827 USB ADAPTER PLATE (BOM#279)			, ,
275 PTJ62000511A HANDLE (BOM#275) 276 PTJ21003971B MPCB (BOM#276) 277 PTJ62100111 BUTTON COVER (BOM#277) 278 PTJ61202092 FRONT BASE COVER (BOM#278)	275 PTJ62000511A HANDLE (BOM#275) 276 PTJ21003971B MPCB (BOM#276) 277 PTJ62100111 BUTTON COVER (BOM#277) 278 PTJ61202092 FRONT BASE COVER (BOM#278) 279 PTJ21000827 USB ADAPTER PLATE (BOM#279)			
276 PTJ21003971B MPCB (BOM#276) 277 PTJ62100111 BUTTON COVER (BOM#277) 278 PTJ61202092 FRONT BASE COVER (BOM#278)	276 PTJ21003971B MPCB (BOM#276) 277 PTJ62100111 BUTTON COVER (BOM#277) 278 PTJ61202092 FRONT BASE COVER (BOM#278) 279 PTJ21000827 USB ADAPTER PLATE (BOM#279)			•
277 PTJ62100111 BUTTON COVER (BOM#277) 278 PTJ61202092 FRONT BASE COVER (BOM#278)	277 PTJ62100111 BUTTON COVER (BOM#277) 278 PTJ61202092 FRONT BASE COVER (BOM#278) 279 PTJ21000827 USB ADAPTER PLATE (BOM#279)			•
278 PTJ61202092 FRONT BASE COVER (BOM#278)	278 PTJ61202092 FRONT BASE COVER (BOM#278) 279 PTJ21000827 USB ADAPTER PLATE (BOM#279)			·
	279 PTJ21000827 USB ADAPTER PLATE (BOM#279)			,
	·			
. ,	280 PTJ61009570 CLAMP LOCK PLATE (BOM#280)			• • •
280 P1J61009570 CLAMP LOCK PLATE (BOM#280)		280	P1J61009570	CLAMP LOCK PLATE (BOM#280)

281	PTJ49900019	FUSE (BOM#281)
-	PTJ14000684	Color chipsassembly
-	PTJ14000685	CYAN COLOR FILTER ASSEMBLY
-	PTJ14000687	MAGENTA COLOR FILTER ASSEMBLY
-	PTJ14000689	YELLOW COLOR FILTER ASSEMBLY
-	PTJ14000691	CTO COLOR FILTER ASSEMBLY
103-001	PTJ32202579A	COLOR CHIP-Congo Blue 2 (BOM#103-001)
103-002	PTJ32202574A	COLOR CHIP-Dark Red (BOM#103-002)
103-003	PTJ32202575A	COLOR CHIP-Ambra Dorato (BOM#103-003)
103-004	PTJ32202576A	COLOR CHIP-Deep- Green (BOM#103-004)
103-005	PTJ32202577A	COLOR CHIP-Bright Blue (BOM#103-005)
103-006	PTJ32202578A	COLOR CHIP-Congo Blue 1 (BOM#103-006)
90-001	PTJ32202559	ROTATION GOBOS 1 (BOM#90-001)
90-002	PTJ32202560	ROTATION GOBOS 2 (BOM#90-002)
90-003	PTJ32202561	ROTATION GOBOS 3 (BOM#90-003)
90-004	PTJ32202562	ROTATION GOBOS 4 (BOM#90-004)
90-005	PTJ32202563	ROTATION GOBOS 5 (BOM#90-005)
90-006	PTJ32202564	ROTATION GOBOS 6 (BOM#90-006)
90-007	PTJ32202573	WATER WAVE GLASS (BOM#90-007)
91-001	PTJ32202565	FIXATION GOBOS 1 (BOM#91-001)
91-002	PTJ32202566	FIXATION GOBOS 2 (BOM#91-002)
91-003	PTJ32202567	FIXATION GOBOS 3 (BOM#91-003)
91-004	PTJ32202568	FIXATION GOBOS 4 (BOM#91-004)
91-005	PTJ32202569	FIXATION GOBOS 5 (BOM#91-005)
91-006	PTJ32202570	FIXATION GOBOS 6 (BOM#91-006)
91-007	PTJ32202571	FIXATION GOBOS 7 (BOM#91-007)
91-008	PTJ32202572	FIXATION GOBOS 8 (BOM#91-008)