





A



B







EXPLODED DIAGRAM REF STATIC	PART NUMBER	DESCRIPTION
1	PTH110100004352	bearing (BOM#1)
2	PTH070200012097	silicone ring (BOM#2)
3	PTH010203004658	bearing cover (BOM#3)
4	PTH010101013789	pan lock (BOM#4)
5	PTH010201010601	gasket (BOM#5)
6	PTH010504000505	base front cover (BOM#6)
7	PTH030100004756	display PCB (BOM#7)
8	PTH010102019316	display press board (BOM#8)
9	PTH050101004374	touch glass (BOM#9)
10	PTH021900000007	ITO conductive filter (BOM#10)
11	PTH070200012175	display gasket (BOM#11)
12	PTH070200012176	display front cover gasket (BOM#12)
13	PTH010504000496	display front cover (BOM#13)
14	PTH030100004608	switch PCB (BOM#14)
15	PTH040301010978	PSU (BOM#15)
16	PTH040301010904	PSU (BOM#16)
17	PTH010102014082	PSU press board (BOM#17)
18	PTH010102014083	PSU press board 2 (BOM#18)
19	PTH010102019027	fan blocker (BOM#19)
20	PTH210200014987	fan assembly (BOM#20)
21	PTH010201010465	bearing fasten part (BOM#21)
22	PTH010101013790	pan bearing press board (BOM#22)
23	PTH120305010761	barrier ring (BOM#23)
24	PTH070100011657	fan bracket (BOM#24)
25	PTH021800000002	battery (BOM#25)
26	PTH010203004662	base wire cover (BOM#26)
27	PTH070200012070	support gasket (BOM#27)
28	PTH010504000503	quick lock IP cover (BOM#28)
29	PTH120500000017	nut (BOM#29)
30	PTH070200012197	gasket (BOM#30)
31	PTH070200012177	base gasket (BOM#31)
32	PTH010101013907	base board (BOM#32)
33	PTH070200000054	machine foot (BOM#33)
34	PTH010101013685	quick lock mat board (BOM#34)
35	PTH010405010198	quick lock hanging bracket (BOM#35)
36	PTH030100004452	wireless PCB (BOM#36)
37	PTH010302000139	standoff (BOM#37)
38	PTH030100004366	switch PCB (BOM#38)
39	PTH010102012834	USB press board (BOM#39)
40	PTH210200015007	USB assembly (BOM#40)
41	PTH080400000071	connector cover (BOM#41)
42	PTH030100004658	DMX PCB (BOM#42)
43	PTH010102000409	DMX PCB mat (BOM#43)
44	PTH080400000015	connector (BOM#44)
45	PTH070200012129	display front cover gasket (BOM#45)
46	PTH010201010290	DMX board (BOM#46)
47	PTH080500000027	USB-C connector (BOM#47)
48	PTH021200004580	antenna (BOM#48)
49	PTH080500000013	connector (BOM#49)

50	PTH080500000016	connector (BOM#50)
51	PTH070200000012	fuse cap (BOM#51)
52	PTH021000010964	fuse (BOM#52)
53	PTH070200011814	valve (BOM#53)
54	PTH210200013526	fuse holder (BOM#54)
55	PTH120202000007	nut (BOM#55)
56	PTH010101011374	arm cover board (BOM#56)
57	PTH210200014988	fan assembly (BOM#57)
58	PTH030100000098	magnetic sensor (BOM#58)
59	PTH010101012401	pan magnetic sensor bracket (BOM#59)
60	PTH010302000140	standoff (BOM#60)
61	PTH010101012579	pan bracket (BOM#61)
62	PTH010102014667	stopper board (BOM#62)
63	PTH010201000086	pan stopper (BOM#63)
64	PTH010203004660	pan axis (BOM#64)
65	PTH010102001369	pan positioning pad (BOM#65)
66	PTH010102012411	pan positioning board (BOM#66)
67	PTH010203004412	gear (BOM#67)
68	PTH150400000004	magnet (BOM#68)
69	PTH010203004552	pan magnetic sensor post (BOM#69)
70	PTH010203004559	tilt axis 2 (BOM#70)
71	PTH070200012162	silicone ring (BOM#71)
72	PTH070200012073	silicone ring (BOM#72)
73	PTH010504000240	arm bracket (BOM#73)
74	PTH070200012088	silicone ring (BOM#74)
75	PTH070200000019	tilt oil seal (BOM#75)
76	PTH010203004551	tilt bushing (BOM#76)
77	PTH110100004354	bearing (BOM#77)
78	PTH120305000019	axis circlip (BOM#78)
79	PTH010101013479	tilt wiring bracket (BOM#79)
80	PTH070200011989	arm gasket (BOM#80)
81	PTH010504000241	arm cover (BOM#81)
82	PTH030100004664	pan/tilt motor PCB (BOM#82)
83	PTH151000004310	silicone pad (BOM#83)
84	PTH040100003848	motor (BOM#84)
85	PTH010101012543	pan motor bracket (BOM#85)
86	PTH010101011923	motor bracket accessory 1 (BOM#86)
87	PTH010101011924	motor bracket accessory 2 (BOM#87)
88	PTH010102012235	pan optocoupler mat board (BOM#88)
89	PTH030100004657	optocoupler PCB (BOM#89)
90	PTH010102000387	optocoupler bracket (BOM#90)
91	PTH210200013476	pan belt press wheel (BOM#91)
92	PTH090200000023	belt (BOM#92)
93	PTH210200013970	pan/tilt driving wheel (BOM#93)
94	PTH110100004355	bearing (BOM#94)
95	PTH070200012086	silicone ring (BOM#95)
96	PTH070200011798	oil seal (BOM#96)
97	PTH010101011386	pan bearing press board (BOM#97)
98	PTH010203011501	arm bracket bushing (BOM#98)
99	PTH010203004547	pick fixing 2 (BOM#99)
100	PTH120105000006	screw (BOM#100)
101	PTH070200000067	PVC cover (BOM#101)

102	PTH010101011369	pan lock pick (BOM#102)
103	PTH010102012233	shrapnel (BOM#103)
104	PTH070200012123	silicone ring (BOM#104)
105	PTH070200012081	silicone ring (BOM#105)
106	PTH010203004541	screw press board (BOM#106)
107	PTH010101011911	screw mat (BOM#107)
108	PTH010102018017	mat chip (BOM#108)
109	PTH210200015615	tilt lock kit assembly (BOM#109)
110	PTH070200012145	gasket (BOM#110)
111	PTH010102015022	tilt motor bracket (BOM#111)
112	PTH090200000058	belt (BOM#112)
113	PTH010203004970	optocoupler bracket (BOM#113)
114	PTH030100004402	magnetic sensor (BOM#114)
115	PTH010102012236	tilt positioning chip (BOM#115)
116	PTH010102012237	tilt stopper board (BOM#116)
117	PTH010102015724	tilt stopper board pad (BOM#117)
118	PTH150400000009	magnet (BOM#118)
119	PTH010203004413	gear (BOM#119)
120	PTH010101011388	tilt bearing press board (BOM#120)
121	PTH010203004556	tilt axis 1 (BOM#121)
122	PTH070100011648	lens cover (BOM#122)
123	PTH050101004357	objective lens (BOM#123)
124	PTH070200012121	silicone ring (BOM#124)
125	PTH010201010656	lens bracket (BOM#125)
126	PTH070200012209	lens holder gasket (BOM#126)
127	PTH151000004334	thermal pad (BOM#127)
128	PTH010102018901	front fix board (BOM#128)
129	PTH010102018898	driver board mounting board (BOM#129)
130	PTH030100004720	motor driver PCB (BOM#130)
131	PTH130700000005	moisture tablet (BOM#131)
132	PTH070200012069	head cover gasket (BOM#132)
133	PTH010504000508	head cover (BOM#133)
134	PTH010504000507	head side cover (BOM#134)
135	PTH010102018902	wire barrier 1 (BOM#135)
136	PTH010101011370	tilt lock (BOM#136)
137	PTH010101013028	fan light shield (BOM#137)
138	PTH210200015314	fan assembly (BOM#138)
139	PTH010101012887	fan light shield (BOM#139)
140	PTH060300004325	LED module (BOM#140)
141	PTH210200014993	fan assembly (BOM#141)
142	PTH010101013849	fan mounting bracket (BOM#142)
143	PTH010102019341	fan mounting bracket (BOM#143)
144	PTH010203000296	light source bracket post (BOM#144)
145	PTH070200011787	silicone strip (BOM#145)
146	PTH030100004713	LED driver PCB (BOM#146)
147	PTH010504000130	light source (BOM#147)
148	PTH070200012087	silicone ring (BOM#148)
149	PTH010101011910	light source stopper (BOM#149)
150	PTH070100004500	wiring cover (BOM#150)
151	PTH010101012386	safety cable hook (BOM#151)
152	PTH010101011911	screw mat (BOM#152)
153	PTH070200012122	silicone ring (BOM#153)

154	PTH010503010805	heat sink (BOM#154)
155	PTH210200015044	fan assembly (BOM#155)
156	PTH210200014991	fan assembly (BOM#156)
157	PTH010203006305	bearing press ring (BOM#157)
158	PTH210200014931	rotating gobo wheel with gobos (BOM#158)
159	PTH030100004618	magnetic sensor (BOM#159)
160	PTH090200010775	belt (BOM#160)
161	PTH090200004290	belt (BOM#161)
162	PTH010203000570	gear (BOM#162)
163	PTH010203011969	bearing mat ring (BOM#163)
164	PTH210200014932	color wheel (BOM#164)
165	PTH010203011973	CMY axis (BOM#165)
166	PTH110100004399	bearing (BOM#166)
167	PTH010203006517	gear (BOM#167)
168	PTH210104011094	CTO set (BOM#168)
169	PTH090200004164	belt (BOM#169)
170	PTH010203004578	static gobo wheel mat board (BOM#170)
171	PTH010203000317	gear (BOM#171)
172	PTH110100004390	bearing (BOM#172)
173	PTH210200015085	Yellow set (BOM#173)
174	PTH210104011095	Cyan set (BOM#174)
175	PTH010203000581	gear (BOM#175)
176	PTH090200004292	belt (BOM#176)
177	PTH210104011093	magenta set (BOM#177)
178	PTH090200004213	belt (BOM#178)
179	PTH010203011977	gear (BOM#179)
180	PTH030100004406	magnetic sensor (BOM#180)
181	PTH2020302431221	magnetic sensor (BOM#181)
182	PTH010203011971	CMY axis 2 (BOM#182)
183	PTH010203011970	CMY axis 1 (BOM#183)
184	PTH090200000035	belt (BOM#184)
185	PTH010302000078	standoff (BOM#185)
186	PTH010301000223	standoff (BOM#186)
187	PTH010101013762	gobo motor bracket (BOM#187)
188	PTH010102012882	screw board (BOM#188)
189	PTH010203005200	fixing block 2 (BOM#189)
190	PTH151000004357	thermal pad (BOM#190)
191	PTH030100004672	motor driver PCB (BOM#191)
192	PTH010203005201	fixing block 1 (BOM#192)
193	PTH040100003862	motor (BOM#193)
194	PTH040100003865	motor (BOM#194)
195	PTH040100003878	motor (BOM#195)
196	PTH040100003877	motor (BOM#196)
197	PTH050304000498	color filter (BOM#197)
198	PTH050304000499	color filter (BOM#198)
199	PTH050304000500	color filter (BOM#199)
200	PTH050304000501	color filter (BOM#200)
201	PTH050304000502	color filter (BOM#201)
202	PTH050302000002	color filter (BOM#202)
203	PTH050304000503	color filter (BOM#203)
204	PTH010102019199	color wheel (BOM#204)
205	PTH050401004279	metal gobo (BOM#205)

206	PTH050402000725	glass gobo (BOM#206)
207	PTH050402000722	glass gobo (BOM#207)
208	PTH050402000721	glass gobo (BOM#208)
209	PTH050402000723	glass gobo (BOM#209)
210	PTH050402000726	glass gobo (BOM#210)
211	PTH050402000724	glass gobo (BOM#211)
212	PTH050403010782	metal gobo (BOM#212)
213	PTH050403010781	metal gobo (BOM#213)
214	PTH050403010783	metal gobo (BOM#214)
215	PTH010403004023	gobo wheel, no gobos (BOM#215)
216	PTH010203011524	animation wheel axis (BOM#216)
217	PTH110100004381	bearing (BOM#217)
218	PTH010102019100	animation bracket (BOM#218)
219	PTH010203011495	animation mat ring (BOM#219)
220	PTH010203000230	animation axis press ring (BOM#220)
221	PTH010203000236	press wheel mat ring (BOM#221)
222	PTH010203001176	gear (BOM#222)
223	PTH010203000945	gear (BOM#223)
224	PTH090100000011	belt (BOM#224)
225	PTH010203000234	animation axis (BOM#225)
226	PTH110100004383	bearing (BOM#226)
227	PTH010203011778	animation blocker (BOM#227)
228	PTH010203005135	gear (BOM#228)
229	PTH050401004191	metal gobo (BOM#229)
230	PTH210200014992	fan assembly (BOM#230)
231	PTH010203011777	animation wheel press chip (BOM#231)
232	PTH090200000061	belt (BOM#232)
233	PTH010203000167	static gobo wheel press ring (BOM#233)
234	PTH010203000583	gear (BOM#234)
235	PTH110100004380	bearing (BOM#235)
236	PTH210104011076	static gobo wheel (BOM#236)
237	PTH010101013819	gobo wheel light shield (BOM#237)
238	PTH010102019467	gobo wheel mat board (BOM#238)
239	PTH080100000124	connector (BOM#239)
240	PTH010101013774	gobo motor bracket 2 (BOM#240)
241	PTH010301003807	standoff (BOM#241)
242	PTH010203011968	static gobo wheel axis (BOM#242)
243	PTH010302000072	standoff (BOM#243)
244	PTH080100000125	connector (BOM#244)
245	PTH040100003868	motor (BOM#245)
246	PTH040100003866	motor (BOM#246)
247	PTH010101013775	zoom light shield (BOM#247)
248	PTH050101004358	zoom (BOM#248)
249	PTH010101013773	zoom bracket (BOM#249)
250	PTH010101013776	prism light shield (BOM#250)
251	PTH010101013778	prism light shield (BOM#251)
252	PTH010302000049	standoff (BOM#252)
253	PTH010302000060	standoff (BOM#253)
254	PTH210200015095	linear prism assembly,include prism lens (BOM#254)
255	PTH090200004175	belt (BOM#255)
256	PTH210200015094	8-facet prism assembly,include prism lens (BOM#256)
257	PTH010203004291	gear (BOM#257)

258	PTH010203004401	gear (BOM#258)
259	PTH010101013804	prism reset board (BOM#259)
260	PTH120304000001	prism spring (BOM#260)
261	PTH120301000006	spring (BOM#261)
262	PTH010101013840	light shield (BOM#262)
263	PTH010203012107	flange (BOM#263)
264	PTH010201010654	focus lens bracket (BOM#264)
265	PTH030100004673	switch PCB (BOM#265)
266	PTH010301000155	standoff (BOM#266)
267	PTH070200011925	black cap (BOM#267)
268	PTH010102014575	connector clip (BOM#268)
269	PTH040100003858	motor (BOM#269)
270	PTH040100003870	motor (BOM#270)
271	PTH040100003869	motor (BOM#271)
272	PTH010102018897	head front bracket (BOM#272)
273	PTH050101004359	focus (BOM#273)
274	PTH040100003875	motor (BOM#274)
275	PTH010102018904	motor adjust board (BOM#275)
276	PTH010203000853	gear (BOM#276)
277	PTH010203011966	focus lens bracket (BOM#277)
278	PTH010504000500	belt press board (BOM#278)
279	PTH010101013779	belt installation board (BOM#279)
280	PTH090200000031	belt (BOM#280)
281	PTH210200015270	zoom pulley set (BOM#281)
282	PTH150400000001	magnet (BOM#282)
283	PTH010101013780	belt barrier (BOM#283)
284	PTH010102019050	zoom light shield (BOM#284)
285	PTH010101013818	zoom light shield (BOM#285)
286	PTH010101013832	slider light shield (BOM#286)
287	PTH010101013686	belt barrier (BOM#287)
288	PTH010203011967	zoom lens bracket (BOM#288)
289	PTH010102018076	slider barrier (BOM#289)
290	PTH090200004287	belt (BOM#290)
291	PTH010101013486	zoom belt install board (BOM#291)
292	PTH010102018899	motor adjust board (BOM#292)
293	PTH040100003857	motor (BOM#293)
294	PTH110200011603	slider (BOM#294)
295	PTH010101013761	focus bracket (BOM#295)
296	PTH030100004583	magnetic sensor (BOM#296)
297	PTH210200014994	fan assembly (BOM#297)
298	PTH050501003556	linear prism lens (BOM#298)
299	PTH010401000082	prism assembly, no prism lens (BOM#299)
300	PTH050502000004	frost (BOM#300)
301	PTH010101013945	prism light shield (BOM#301)
302	PTH010401000081	prism assembly, no prism lens (BOM#302)
303	PTH050501003552	prism (BOM#303)