










EXPLODED DIAGRAM REF STATIC	PART NUMBER	DESCRIPTION
1	PTH1060100524781	base front cover PRO-740-C01 (BOM#1)
2	PTH1010102523881	base back board PRO-740-A01-03 (BOM#2)
3	PTH2030700526051	Power supply PSU H63-UP400S32 (BOM#3)
4	PTH1010102523901	base side board PRO-740-A01-04 (BOM#4)
5	PTJ3020018004	Quick Lock Nut 42x24x6.5 (BOM#5)
6	PTJ5014950170	dust filter for quick lock 41.32311.6 (BOM#6)
7	PTH02100600	fan vent 66 (BOM#7)
8	PTH0200601206010	fan DFM6010B (BOM#8)
9	PTH1010202533451	pan axis bracket PRO-740-B05 (BOM#9)
10	PTHTOP715BZ01	pan axis TOP-715-BZ01 (BOM#10)
11	PTH1040000241401	pan bushing TOP-715IW-715 LED Moving Wash,TOP-715 Z LED Moving Spot,TOP-635IW-635 LED Moving Zoom Wash (BOM#11)
12	PTH2020302275041	DMX PCB ADMX017 (BOM#12)
13	PTH2030103282343	ZOOM Motor 4 pin female small white connector -Short length wire
13	PTH2020302530651	PCB MK013 4031 (BOM#13)
14	PTH2021900109181	plastic standoff 44 2.8 (BOM#14)
15	PTH2020302521821	display PCB ADISP019 (BOM#15)
16	PTH1060200181811	display board cover CD-C39322.5 (BOM#16)
17	PTF1001002302	power in connector NAC3MPA-1 (BOM#17)
18	PTF1001002202	Power out connector NAC3MPB-1 (BOM#18)
19	PTJ3027001001	fuse base FH1-B-MW (BOM#19)
20	5AMPGMA	fuse 5A 520 250V (BOM#20)
21	PTH1010102523861	display board bracket PRO-740-A01-02 (BOM#21)
22	PTH1010102523841	base board PRO-740-A01-01 (BOM#22)
23	PTH1010102523941	safety rope cover board PRO-740-A01-06 (BOM#23)
24	PTH1010102523961	safety rope mat board PRO-740-A01-05 (BOM#24)
25	PTH1010102284961	safety rope board M-515-A01-12 (BOM#25)
26	PTH2090400171491	machine foot 158 (BOM#26)
27	PTH1040000230891	Omega hanging bracket V3, Taller bracket CD-D13 140mm (BOM#27)(Replaced by PTH010405010191)
27	PTH210200014412	Omega hanging bracket V2, Shorter with 6mm washer CD-D13 140mm (BOM#27) (Replaced by PHT010405010191)
28	PTH01060100382191	arm cover PRO-715-C04 (BOM#28)
29	PTH1010401412951	standoff 562 M3 (BOM#29)
30	PTH1010102229011	tilt wire press board PRO-715-A02-07 (BOM#30)
31	PTH2091302169561	circlip 24 (BOM#31)
32	PTH2040000541021	tilt bushing PRO-740 LED Moving Wash (BOM#32)
33	PTH1010102524021	tilt bracket PRO-740-A02-03 (BOM#33)
34	PTHTOP715BZ05	tilt axis 2 TOP-715-BZ05 (BOM#34)
35	PTH1060100524791	arm top cover PRO-740-C02 (BOM#35)
36	PTHTOP715BZ03	tilt axis 1 TOP-715-BZ03 (BOM#36)
37	PTH1010102524001	tilt motor bracket PRO-740-A02-02 (BOM#37)
38	PTH1010202510051	gear DL-355-02 (BOM#38)
39	PTH2090101177962	synchronization belt 3M-357-8mm (BOM#39)
40	PTH2020302424271	optocoupler PCB GD006 (BOM#40)
41	PTH1010202523761	tilt optocoupler bracket PRO-740-B02 (BOM#41)
42	PTH2040000541041	tilt driving wheel PRO-740 LED Moving Wash (BOM#42)
43	PTH1010102524081	tilt motor adjust bracket PRO-740-A02-06 (BOM#43)
44	PTH2030103534391	motor 17HEF4104-25-500 (BOM#44)
45	PTH1010102524041	arm front board PRO-740-A02-04 (BOM#45)
46	PTH2040000541011	pan driving wheel PRO-740 LED Moving Wash (BOM#46)
47	PTH2090101524731	belt 3M-255-7mm (BOM#47)
48	PTHTOP715A0207	pan orientation mat chip TOP-715-A02-07 (BOM#48)
49	PTHTOP715A0206	pan orientation chip TOP-715-A02-06 (BOM#49)
50	PTH1010202229091	mat cover PRO-715-B03 (BOM#50)
51	PTH1010401229701	standoff 568 M3 (BOM#51)
52	PTH1010102523981	arm connection bracket PRO-740-A02-01 (BOM#52)
53	PTH1010401209671	standoff 537 M3 (BOM#53)
54	PTH2040000541031	pan driving wheel PRO-740 LED Moving Wash (BOM#54)
55	PTH1010202523751	pan optocoupler bracket PRO-740-B01 (BOM#55)
56	PTH2020302380561	optocoupler PCB GD005 (BOM#56)
57	PTH2090601168501	spring 6270.8 (BOM#57)
58	PTH1010102229031	pan motor fix bracket PRO-715-A02-08 (BOM#58)
59	PTH1010102229051	pan motor fix bracket PRO-715-A02-09 (BOM#59)
60	PTH1010102524061	pan motor bracket PRO-740-A02-05 (BOM#60)
61	PTH2030103534601	motor 17HEF4105-25-500 (BOM#61)
62	PTH2091500530281	silicone CP300-6236 62365mm (BOM#62)
63	PTH2020302544811	pan tilt PCB MH219 (BOM#63)
64	PTH1060100524811	head back cover PRO-740-C04 (BOM#64)
65	PTH2090500170781	fan vent 99 (BOM#65)
66	PTH2030201101341	fan DFH9025B 12V .40A 2-Pin Female (BOM#66)
67	PTH1010502523731	heat sink CD-Z23 (BOM#67)
68	PTH1010102524101	head side bracket PRO-740-A03-01 (BOM#68)
69	PTH2020302544781	LED PCB LJB049 (BOM#69)
70	PTH2041200524761	light guide SD02-LP40V2-D295085 (BOM#70)
71	PTH2040000547131	frost PRO-740 LED Moving Wash (BOM#71)
72	PTH2081200308972	rubber shake proof screw 817 (BOM#72)
73	PTH20301032823411	Zoom Motor #1 25PM30013-01 (BOM#73) BlueRGB 3 inch / 5 cm 4 pin female small white connector short wire

74	PTH1010202523771	slide cover PRO-740-B03 (BOM#74)
75	PTH1010202523791	shake proof slider PRO-740-B04 (BOM#75)
76	PTH1010202376671	shake proof screw LG-3.5-109 (BOM#76)
77	PTH1010202510731	slider block IW-740-B04 (BOM#77)
78	PTH1060100524821	lens bottom cover PRO-740-C05 (BOM#78)
79	PTH2040900524751	7 in 1 cluster CD-F10 (BOM#79)
80	PTH1060100533461	lens top cover PRO-740-C06 (BOM#80)
81	PTH1060100524801	head front cover PRO-740-C03 (BOM#81)
-	PTF2700003804	NEUTRIK POWER CABLE 1.5M - 5FT (POWERCON TO EDISON)
-	PTH010405010191	Omega Bracket CD-D23-140 Version 4
-	PTH100700000913	PCB MH219 Wire
-	PTH2020302586531	3pin Connector PCB
-	UPLOAD08	UPLOAD08/MR UPLOAD (CPMOVEUP) ***Order from Location 1***