

EXPLODED DIAGRAM REF STATIC	FIXTURE	PART NUMBER	DESCRIPTION
1	STRIKESABER	PTJ4020200409	TOP COVER (BOM#1)
1	STRIKESABER	PTJ4020200409	TOP COVER (BOM#1)
2	STRIKESABER	PTJ3020200332A	ORGANIC RING (BOM#2)
2	STRIKESABER	PTJ3020200332A	ORGANIC RING (BOM#2)
3	STRIKESABER	PTJ4010304212	REFLECT CUP COVER (BOM#3)
3	STRIKESABER	PTJ4010305966	REFLECT CUP COVER (BOM#3)
4	STRIKESABER	PTJ3030100271	IRON PROP (BOM#4)
4	STRIKESABER	PTJ3030100271	IRON PROP (BOM#4)
5	STRIKESABER	PTJ4020200408	REFLECT CUP (BOM#5)
5	STRIKESABER	PTJ4020200408	REFLECT CUP (BOM#5)
6	STRIKESABER	PTJ4020200407	LIGHT GUIDE (BOM#6)
6	STRIKESABER	PTJ4020200407	LIGHT GUIDE (BOM#6)
7	STRIKESABER	PTJ3010500276	LED W/ Cables (BOM#7)
7	STRIKESABER	PTJ30105002762	LED With Cable Assembly 4 Pin BWYR female white connector (BOM#7)
8	STRIKESABER	PTJ2020202530A	DRIVER PCB A (BOM#8)
8	STRIKESABER	PTJ2020203404	DRIVER PCB A (BOM#8)
9	STRIKESABER	PTJ4010304213	SIDE PANEL FOR HOUSING (BOM#9)
9	STRIKESABER	PTJ4010304213	SIDE PANEL FOR HOUSING (BOM#9)
10	STRIKESABER	PTJ4010304204	HOUSING (BOM#10)
10	STRIKESABER	PTJ4010305967	HOUSING (BOM#10)
11	STRIKESABER	PTJ3022100062	PLASTIC PANEL (BOM#11)
11	STRIKESABER	PTJ3022100062	PLASTIC PANEL (BOM#11)
12	STRIKESABER	PTJ3020400288	POWER SUPPLY (BOM#12)
12	STRIKESABER	PTJ3020400288	POWER SUPPLY (BOM#12)
13	STRIKESABER	PTJ3027001001	Panel mount fuse holder (BOM#13)
13	STRIKESABER	PTJ3027001001	FUSE HOLDER (BOM#13)
14	STRIKESABER	3.15AMPGMA	T3.15AL250V FUSE (BOM#14)
14	STRIKESABER	3.15AMPGMA	FUSE (BOM#14)
15	STRIKESABER	PTJ4010402130	SIDE PANEL 1 FOR HOUSING BASE (BOM#15)
15	STRIKESABER	PTJ4010402130	SIDE PANEL 1 FOR HOUSING (BOM#15)
16	STRIKESABER	PTF1001002302	POWER IN SOCKET (BOM#16)
16	STRIKESABER	PTF1001002302	POWER IN SOCKET (BOM#16)
17	STRIKESABER	PTJ2020202367	DMX IN PCB (BOM#17)
17	STRIKESABER	PTJ2020202367	DMX IN PCB (BOM#17)
18	STRIKESABER	PTJ4010302041	COVER FOR POWER SOCKET (BOM#18)
18	STRIKESABER	PTJ4010302041	COVER FOR POWER SOCKET (BOM#18)
19	STRIKESABER	PTJ4010402133	HOUSING BASE 1 (BOM#19)
19	STRIKESABER	PTJ4010402584	HOUSING BASE 1 (BOM#19)
20	STRIKESABER	PTJ4010304211B	SIDE PANEL 2 FOR HOUSING BASE (BOM#20)
20	STRIKESABER	PTJ4010304211B	SIDE PANEL 2 FOR HOUSING (BOM#20)
21	STRIKESABER	PTJ4020200073	HOUSING LEG (BOM#21)
21	STRIKESABER	PTJ4020200073	HOUSING LEG (BOM#21)
22	STRIKESABER	PTJ3021700232	STANDING BRACKET SCREW (BOM#22)
22	STRIKESABER	PTJ4010304209	STANDING BRACKET (BOM#22)
22	STRIKESABER	PTJ4010304209	STANDING BRACKET (BOM#22)
23	STRIKESABER	PTJ4010304208	HANGING BRACKET (BOM#23)
23	STRIKESABER	PTJ4010304208	HANGING BRACKET (BOM#23)
24	STRIKESABER	PTJ5011120010	HANGING BRACKET KNOB (BOM#24)
24	STRIKESABER	PTJ5011120010	HANGING BRACKET KNOB (BOM#24)
25	STRIKESABER	PTJ4010402129	HOUSING 2 (BOM#25)
25	STRIKESABER	PTJ4010402585	HOUDING 2 (BOM#25)
26	STRIKESABER	PTJ3001001006	STAND OFF (BOM#26)
26	STRIKESABER	PTJ3001001006	STAND OFF (BOM#26)
27	STRIKESABER	PTJ3020200073	DISPLAY CLEAR LENS (BOM#27)
27	STRIKESABER	PTJ3020200073	DISPLAY CLEAR LENS (BOM#27)
28	STRIKESABER	PTJ3019001043	BUTTON COVER (Big) (BOM#28)
28	STRIKESABER	PTJ3019001043	BUTTON COVER (Big) (BOM#28)
29	STRIKESABER	PTJ2020202406A	MPCB (BOM#29)
29	STRIKESABER	PTJ2020202406A	MPCB (BOM#29)
30	STRIKESABER	PTJ4010402131	SIDE PANEL 3 FOR HOUSING BASE (BOM#30)
30	STRIKESABER	PTJ4010402131	SIDE PANEL 3 FOR HOUSING BASE (BOM#30)
31	STRIKESABER	PTF1001002202	POWER OUT SOCKET (BOM#31)
31	STRIKESABER	PTF1001002202	POWER OUT SOCKET (BOM#31)
32	STRIKESABER	PTJ2020202368	DMX OUT PCB (BOM#32)
32	STRIKESABER	PTJ2020202368	DMX OUT PCB (BOM#32)

33	STRIKESABER	PTJ3021700480	PLASTIC RING (BOM#33)
33	STRIKESABER	PTJ3021700476	PLASTIC RING (BOM#33)
34	STRIKESABER	PTJ4010304207	BRACKET STAND (BOM#34)
34	STRIKESABER	PTJ4010304207	BRACKET STAND (BOM#34)
35	STRIKESABER	PTJ4010304215	SLING (BOM#35)
35	STRIKESABER	PTJ4010304215	SLING (BOM#35)
36	STRIKESABER	PTJ4010304216	HOUSING COVER (BOM#36)
36	STRIKESABER	PTJ4010304216	HOUSING COVER (BOM#36)
37	STRIKESABER	PTJ2020201330	DISPLAY PCB (BOM#37)
37	STRIKESABER	PTJ2020201330	DISPLAY PCB (BOM#37)
38	STRIKESABER	PTJ2020202482A	DRIVER PCB B (BOM#38)
38	STRIKESABER	PTJ3080100194A	NUT FOR CLAMP LOCK (BOM#38)
39	STRIKESABER	PTF2700003804	NEUTRIK POWER CABLE 1.5M - 5FT (BOM#39)
39	STRIKESABER	PTJ4010302997	CLAMP LOCK (BOM#39)
40	STRIKESABER	PTJ3050102423	INNER BOX (BOM#40)
40	STRIKESABER	PTJ4010104836	BASE PLATE FOR CLAMP LOCK (BOM#40)
41	STRIKESABER	PTJ4010305968	SIDE PANEL 5 (BOM#41)
42	STRIKESABER	PTJ3050601346	QRG (BOM#42)
42	STRIKESABER	PTJ3021700400	CARD FOR CLAMP LOCK (BOM#42)
43	STRIKESABER	PTJ4010103453	BASE PLATE FOR OMEGA BRACKET (BOM#43)
44	STRIKESABER	PTJ3080100152	Quick Lock Black Srew For OMEGA BRACKET (BOM#44)
45	STRIKESABER	PTJ2020203405	DRIVER PCB B (BOM#45)
46	STRIKESABER	PTF2700003804	NEUTRIK POWER CABLE 1.5M - 5FT (BOM#46)
47	STRIKESABER	PTJ3050102423	INNER BOX (BOM#47)
49	STRIKESABER	PTJ3050601620	QRG (BOM#49)
	STRIKESABER	PTJ21000246	MPCB - DISPLAY PCB ASSEMBLY