
1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
59
60
61

EXPLODED DIAGRAM REF STATIC	FIXTURE	PART NUMBER	DESCRIPTION
1	WELLBATTEN14	PTJ61108803A	BAR (BOM#1)
2	WELLBATTEN14	PTJ61108304	SHADOW SHIELD (BOM#2)
3	WELLBATTEN14	PTJ32301421	FRONT GLASS (BOM#3)
4	WELLBATTEN14	PTJ32600871	RUBBER FOR GLASS (BOM#4)
5	WELLBATTEN14	PTJ32301151A	LEN C (BOM#5)
6	WELLBATTEN14	PTJ32100580A	STAND OFF (BOM#6)
7	WELLBATTEN14	PTJ21003928B	LED PCB (BOM#7)
8	WELLBATTEN14	PTJ61108804B	HEAT SINK (BOM#8)
9	WELLBATTEN14	PTJ61107588B	SIDE PANEL B RIBBON (BOM#9)
10	WELLBATTEN14	PTJ32500141A	SPRING (BOM#10)
11	WELLBATTEN14	PTJ32600872B	CUSHION RUBBER C FOR SIDE PANEL (BOM#11)
12	WELLBATTEN14	PTJ61107587D	SIDE PANEL B (BOM#12)
13	WELLBATTEN14	PTJ32100542A	STAND OFF (BOM#13)
14	WELLBATTEN14	PTJ61009067A	BATTERY COVER (BOM#14)
15	WELLBATTEN14	PTJ43100105	BATTERY (BOM#15)
16	WELLBATTEN14	PTJ53001975	FORM GASKET (BOM#16)
17	WELLBATTEN14	PTJ32600721	CUSHION RUBBER FOR BATTERY BOX (BOM#17)
18	WELLBATTEN14	PTJ61010383	POWER HOLDER A (BOM#18)
19	WELLBATTEN14	PTJ34000346	THERMAL PADS (BOM#19)
20	WELLBATTEN14	PTJ33000229	PSU (BOM#20)
21	WELLBATTEN14	PTJ33300048B	RUBBER FOR IP POWER IN SOCKET (BOM#21)
22	WELLBATTEN14	PTJ33300056A	POWER IN SOCKET (BOM#22)
23	WELLBATTEN14	PTJ42000159B	DMX CONNECTOR(5PIN,MALE) (BOM#23)
24	WELLBATTEN14	PTJ21004407D	MPCB (BOM#24)
25	WELLBATTEN14	PTJ32000016A	HM SCREW (BOM#25)
26	WELLBATTEN14	PTJ32000376	LOCKING WASHER (BOM#26)
27	WELLBATTEN14	PTJ32000375A	GASKET (BOM#27)
28	WELLBATTEN14	PTJ61202037	BATTERY BOX (BOM#28)
29	WELLBATTEN14	PTJ23200241A	BUTTON ASSEMBLY (BOM#29)
30	WELLBATTEN14	PTJ32001338	NUT (BOM#30)
31	WELLBATTEN14	PTJ61107589D	BOTTOM PLATE FOR BRACKET (BOM#31)
32	WELLBATTEN14	PTJ61106710	HANGING BRACKET KNOB (BOM#32)
33	WELLBATTEN14	PTJ32000415A	NYLON WASHER (BOM#33)
34	WELLBATTEN14	PTJ32000413	NYLON WASHER (BOM#34)
35	WELLBATTEN14	PTJ61107590B	STAND BRACKET (BOM#35)
36	WELLBATTEN14	PTJ61106103	CLAMP LOCK (BOM#36)
37	WELLBATTEN14	PTJ72000132B	NUT CAP (BOM#37)
38	WELLBATTEN14	PTJ34100163	VALVE (BOM#38)
39	WELLBATTEN14	PTJ23200240A	BUZZER ASSEMBLY (BOM#39)
40	WELLBATTEN14	PTJ33300063	USB CONNECTOR (BOM#40)
41	WELLBATTEN14	PTJ32301300E	DISPAY LENS (BOM#41)
42	WELLBATTEN14	PTJ21004397	NFC SENSOR BOARD (BOM#42) Blue Board
43	WELLBATTEN14	PTJ42000158B	DMX CONNECTOR(5PIN,FEMALE) (BOM#43)
44	WELLBATTEN14	PTJ33300049	RUBBER FOR IP POWER OUT SOCKET (BOM#44)
45	WELLBATTEN14	PTJ33300058A	POWER OUT SOCKET (BOM#45)
46	WELLBATTEN14	PTJ61010524	HOLDER C FOR MPCB (BOM#46)
47	WELLBATTEN14	PTJ32700209A	MYLAR (BOM#47)
48	WELLBATTEN14	PTJ61010384	POWER HOLDER B (BOM#48)
49	WELLBATTEN14	PTJ32500110	SPRING (BOM#49)
50	WELLBATTEN14	PTJ61110477	SAFETY PIN (BOM#50)
51	WELLBATTEN14	PTJ61107585A	BUTTON PLATE (BOM#51)
52	WELLBATTEN14	PTJ32600982	BUTTON RUBBER (BOM#52)
53	WELLBATTEN14	PTJ32600720C	RUBBER FOR SPRING PIN (BOM#53)
54	WELLBATTEN14	PTJ31001101A	SPRING PIN B (BOM#54)
55	WELLBATTEN14	PTJ32500200	SPRING (BOM#55)
56	WELLBATTEN14	PTJ32600873B	CUSHION RUBBER D FOR SIDE PANEL (BOM#56)
57	WELLBATTEN14	PTJ61107586D	SIDE PANEL A (BOM#57)