

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
9
21
22

EXPLODED DIAGRAM REF STATIC	FIXTURE	PART NUMBER	DESCRIPTION
1	WELLCONNECT	PTK123020003	Antenna_2.5dB_87xΦ9mm(BOM#1)
2	WELLCONNECT	PTK209120154	Antenna holder_L12xW11xH11(BOM#2)
3	WELLCONNECT	PTK202020083A	Mounter for the antenna holder(BOM#3)
4	WELLCONNECT	PTK209120007	Button cap(BOM#4)
5	WELLCONNECT	PTK5101100035A	Adapter board-AS_AB_Power_B_V1.0(TYPE-C)(BOM#5)
6	WELLCONNECT	PTK5101100036	Adapter board-AS_AB_Signal_A_V1.0(RJ45)(BOM#6)
7	WELLCONNECT	PTK5101070040	DMX PCB(BOM#7)
8	WELLCONNECT	PTK5101140006A	USB board(BOM#8)
9	WELLCONNECT	PTK208060092Z	Acrylic plate (Side / A)_L118xW28xT1(BOM#9)
10	WELLCONNECT	PTK201120164Z	Fixing plate for the battery_L70xW63xH40xT1(BOM#10)
11	WELLCONNECT	PTK125010017	Battery-ICR18650G 2S2P_7.4V_5.2Ah/38.5Wh(BOM#11)
12	WELLCONNECT	PTK201120165Z	Fixing plate_L66xW25xH42xT1.5(BOM#12)
13	WELLCONNECT	PTK205980001Z	Cooling plate(BOM#13)
14	WELLCONNECT	PTK5102030006WC	Main PCB (BOM#14)
15	WELLCONNECT	PTK208060093Z	Acrylic plate (Side / B)_L35xW30xT1(BOM#15)
16	WELLCONNECT	PTK5701010066A	Control PCB (BOM#16)
17	WELLCONNECT	PTK118040004	OLED display(BOM#17)
18	WELLCONNECT	PTK209120153	Rotary encoder button(BOM#18)
19	WELLCONNECT	PTK201050101	Top plate_L178xW175xH58xT2(BOM#19)
20	WELLCONNECT	PTK209010033	Screw PM3x6mm(BOM#20)
21	WELLCONNECT	PTK201060080A	Bottom plate_L170xW127xH44xT2(BOM#21)
22	WELLCONNECT	PTK202010093	Feet_Nylon_ 12xH10(BOM#22)
23	WELLCONNECT	PTK209010039Z	Screw PM3x18mm(BOM#23)
24	WELLCONNECT	PTK209010143Z	Screw PM2.5x6mm(BOM#24)
25	WELLCONNECT	PTK209010144Z	Screw PM2x6mm(BOM#25)
26	WELLCONNECT	PTK209020006Z	Screw KB3x8mm(BOM#26)
27	WELLCONNECT	PTK209020016Z	Screw KM4x8mm(BOM#27)
28	WELLCONNECT	PTK209020065Z	Screw KM3x8mm(BOM#28)
29	WELLCONNECT	PTK209070020Z	Hexagon nylon nut M3_5.5x4mm(BOM#29)
30	WELLCONNECT	PTK209120033	Rubber feet_Φ13x6.5mm(BOM#30)
31	WELLCONNECT	PTK209120155Z	Light guide(BOM#31)
32	WELLCONNECT	PTK302050020Z	EVA foam(BOM#32)
34	WELLCONNECT	PTK125030001	Button cell_3.0V_40mAh(BOM#34)
35	WELLCONNECT	PTK123020004	Antenna adapter cable(BOM#35)
36	WELLCONNECT	PTK132020453	Wire Harness_7 Pin_22AWG_200mm with white connector (BOM#36)
37	WELLCONNECT	PTK132090001	Stranded cable_L=150mm(BOM#37)
38	WELLCONNECT	PTK132040016	USB cable(BOM#38)
39	WELLCONNECT	PTK132020454	Wire Harness_3 Pin_26AWG_200mm(BOM#39)
40	WELLCONNECT	PTK132030002Z	FPC cable(BOM#40)
41	WELLCONNECT	PTK5701020066	TF card(BOM#41)
42	WELLCONNECT	PTK121070202	Male connector_2PIN_2.54mm(BOM#42)
43	WELLCONNECT	PTK209100022Z	Hexagon copper pillar_H5xM3x8(BOM#43)
44	WELLCONNECT	PTK209100153Z	Hexagon copper pillar_H5xM3x12(BOM#44)
45	WELLCONNECT	PTK403810013Z	Inner box(BOM#45)
46	WELLCONNECT	PTK403810012AZ	Outer box(BOM#46)
47	WELLCONNECT	PTK408810001Z	Honeycomb board(BOM#47)
48	WELLCONNECT	PTK130070017	EPSU _100-240VAC_5V_2A(BOM#48)
49	WELLCONNECT	PTK130070004Z	US plug(BOM#49)
50	WELLCONNECT	PTK132040005	Type-A to Type-C cable(BOM#50)
51	WELLCONNECT	PTK401810008AZ	Spec sticker(BOM#51)
	WELLCONNECT	PTK130070017C	Power adapter set incl. adapter - UK & EU Connector - USB Cable