




EXPLODED DIAGRAM REF STATIC	FIXTURE	PART NUMBER	DESCRIPTION
1	WELLPOD2X6	PTJ21003529A	POWER DMX PCB (BOM1)
2	WELLPOD2X6	PTJ61107007D	BASE COVER (BOM2)
3	WELLPOD2X6	PTJ32001542	FOAM GASKET (BOM3)
4	WELLPOD2X6	PTJ03032039	SINGLE WELLPOD2 (BOM4)
5	WELLPOD2X6	PTJ13001939	WELLPOD2X6 Complete Road Case with Charger (BOM#5)
5	WELLPOD2X6	PTJ55000365J	ROAD CASE (BOM5)
6	WELLPOD2X6	PTJ61107735A	MEGNET HOLDER (BOM6)
7	WELLPOD2X6	PTJ39900054A	MEGNET (BOM7)
8	WELLPOD2X6	PTJ61103571A	POWER SOCKET HOLDER (BOM8)
9	WELLPOD2X6	PTJ33300053	IP POWER IN/OUT SOCKET (BOM9)
10	WELLPOD2X6	PTJ61106810	POWER SOCKET PLATE (BOM10)
11	WELLPOD2X6	PTJ3027001001	FUSE HOLDER (BOM11)
12	WELLPOD2X6	PTJ49900002	FUSE (BOM12)
13	WELLPOD2X6	PTJ21003530A	INDICATOR PCB (BOM13)
14	WELLPOD2X6	PTJ33200019	FAN NET (BOM14)
15	WELLPOD2X6	PTJ33200253A	FAN (BOM15)
16	WELLPOD2X6	PTJ61007682B	FAN HOLDER (BOM16)
17	WELLPOD2X6	PTJ21001816	HALL ELEMENT LOCATER J (BOM17)
18	WELLPOD2X6	PTJ61106799C	HALL ELEMENT LOCATER (BOM18)
19	WELLPOD2X6	PTJ61107049G	POWER SUPPLY HOLDER (BOM19)
20	WELLPOD2X6	PTJ21000701	LIGHT SENSATION PCB (BOM20)
21	WELLPOD2X6	PTJ32100523	SPACER SUPPORT (BOM21)
22	WELLPOD2X6	PTJ61007920E	PLATE FOR THE MPCB (BOM22)
24	WELLPOD2X6	PTJ33000426	PSU (BOM24)
25	WELLPOD2X6	PTJ21003531A	DMX PCB (BOM25)
26	WELLPOD2X6	PTJ33000439	PSU (BOM26)
27	WELLPOD2X6	PTJ21003817A	MPCB (BOM27)
28	WELLPOD2X6	PTJ32700174	MYLAR (BOM28)
29	WELLPOD2X6	PTJ32100318	STAND OFF (BOM29)
30	WELLPOD2X6	PTJ61108289A	POWER COVER (BOM30)
31	WELLPOD2X6	PTJ72000565	RFC REMOTE (BOM31)
32	WELLPOD2X6	PTJ21003656	DMX PCB A (BOM23)
32	WELLPOD2X6	PTJ23100149B	POWER CABLE (US) (BOM32)
33	WELLPOD2X6	PTJ54001158A	QRG (BOM33)
34	WELLPOD2X6	PTJ52002440E	OUTER BOX (BOM34)
35	WELLPOD2X6	PTJ32000338	NUT (BOM35)
36	WELLPOD2X6	PTJ32000117	HM SCREW (BOM36)
39	WELLPOD2X6	PTJ21004540B	MPCB & DISPLAY PCB ASSEMBLY (BOM#39)
45	WELLPOD2X6	PTJ39900041	POWER SWITCH (BOM#45)
N/A	WELLPOD2X6	PTJ14000761	Wellpod2X6 Charging plate kit (2plates-Foams:4long/6small)