IR HOMEWOK

1. The frequency of the IR signal is : $1/40,000\,(\mathrm{Hz}) = 0.0000025\,\,\mathrm{second} = 25\,\,\mathrm{us}$

2. Frame one: Start + Device0 + command13

Start + 0b0 + 0b1101

Frame two: Start + Device1 + Command14

Start + 0b01 + 0b1110


Frame three: Start + Device3 + Command8


Start + 0b11 + 0b1000

3. Data Frame:

• Frame one: Start + 0b0 + 0b1101

500us





IR HOMEWOK

