CprE 381 Homework 5

[Note: This homework gives you some more practice with procedure calls and MIPS programming. As a happy coincidence, it will help provide a class-wide test program that I will share with you. Then the homework begins to cover processor design choices.]

1. Processor Implementation Details P&H(4.2) <§4.1>. The basic single-cycle MIPS implementation in Figure 4.2 can only implement some instructions. New instructions can be added to an existing Instruction Set Architecture (ISA), but the decision whether or not to do that depends, among other things, on the cost and complexity the proposed addition introduces into the processor datapath and control. The first three problems in this exercise refer to the new instruction:

Instruction: **JIC** rt, imm

Interpretation: PC = Reg[rt] + sign_extend(imm)

- a. Which existing blocks (if any) can be used for this instruction?
 PC, Instruction Memory, Register File (2 read ports and 1 write port),
 ALU Source B MUX, ALU.
 - b. Which new functional blocks (if any) do we need for this instruction? ALU input A mux, JIC mux.
 - c. What new signals do we need (if any) from the control unit to support this instruction?

Two control signals will be needed, one for ALUSrcA, and the other being JIC (for the JIC mux).

Processor Cycle Time Determination
 Assume the following latencies for the logic blocks in Figure 4.17 from the textbook.

I-Mem	Adder	MUX	ALU	Reg	D-Mem	Sign-	Shift	Control	ALU	AND
				Read		Extend	-		Control	gate
							Left-			
							2			
225ps	85ps	15ps	100	110ps	340ps	15ps	10ps	70ps	15ps	10ps
			ps							

a. Identify and quantify (i.e., give the path through the blocks and the time for that path) the worst-case path for each of the following: an arithmetic R-format instruction, a **lw** instruction, and a conditional branch instruction.

R-format:

Critical path: I-Mem → Reg Read → MUX (ALUSrc) → ALU → MUX (MemReg)

Latency:
$$225ps + 110ps + 15ps + 100ps + 15ps = 465ps$$

lw:

Critical path: I-Mem → Reg Read → ALU → D-Mem → MUX (MemReg) Latency: 225ps +110ps + 100ps + 340ps

+ 15ps = 790ps

Conditional branch:

Critical path: I-Mem → Reg Read → MUX (ALUSrc) → ALU → AND →

MUX (PCSrc)

Latency: 225ps + 110ps + 15ps + 100ps + 10ps + 15ps = 475ps

- b. Rank the following design approaches in terms of which improve the cycle time the most. You **must** justify your ranking.
 - Developing an "extra fast adder" that reduces the Adder and ALU latencies
 - ii. Changing the ISA memory addressing mode to directly use the base register's value (i.e., no offset addition)
 - iii. Designing a lower-latency control unit

The lw instruction causes the critical path by a wide margin (over 250ps), so only by improving the speed of components on \mathbf{lw} 's critical path will help the total cycle time.

- 1. ii The DMEM lies on the **lw** critical path and is the biggest source of latency, meaning that a reduction in delay will provide the greatest improvement to cycle time.
- 2. iii While the control unit does output signals that affect dataflow in the **lw** critical path, it operates in parallel to the dataflow itself, and therefore will provide little if any improvement.
- 3. i While this would improve the latency on the jump / branch paths, our critical path lies with **lw**. Therefore, no improvement would be made with this change.
- 3. Performance Analysis

You are in charge of selecting processors for computing simple Natural Language Processing (NLP) tasks. You are considering two processors, A and B (the only ones you and your roommates can afford) that have the following CPIs:

Instruction Type	Cycles per Instruction				
	Processor A	Processor B			
Arithmetic, Logical, Shifts, Stores	3	3			
Jumps	3	2			
Conditional Branch	3	2			
Loads	3	5			

The following applications are the primary ones that you will need to run on your system:

```
# Application 1:
# This is an implementation of a single stop word index identification #
in a string.
# $a0 contains &string (string is an asciiz array of size string size)
# $al contains &stop_word (stop_word is an asciiz array of size sw_size)
# $a2 contains string_size variable
# $a3 contains sw_size variable
   addiu $t0, $0, 0
   j outer_cond
outer_loop:
   addiu $t1, $0, 0
   jal inner cond
outer_loop_cont:
   subu $t2, $t1, $a3
   ori $at, $0, 1
   sltu
        $t2, $t2, $at
   addiu $t0, $t0, 1
   beq $t2, $0, outer cond
   lui $at, 0x1001
           $a0, $at, 0x19
   ori
   addiu $v0, $0, 4
   syscall
   lui $at, 0
           $at, $at, 1
   ori
   subu $t0, $t0, $at
```

```
addu $a0, $0, $t0
   addiu $v0, $0, 1
   syscall
   j exit
outer_cond:
   subu $t2, $a2, $a3
       $10, $8, $10
   slt
        $t2, 1,
   beq
   outer_loop
   j exit
inner_loop:
   addu $t2, $t0, $t1
   addu $t2, $a0, $t2
   1b $t3, 0($t2)
   addu $t2, $a1, $t1
   lb $t4, 0($t2)
   subu $t2, $t3, $t4
   sltu
        $t2, $0, $t2
   addiu $t1, $t1, 1
   beq
        $t2, 1, outer_loop_cont
inner_cond:
          $t2, $t1, $a3
   slt
   beq $t2, 1, inner_loop
   jr $ra
   exit:
```

```
# Application 2:
```

This is an implementation of simple string tokenizer. # \$a1 contains string_size variable

#\$a2 contains &string (string is an asciiz array of size string_size) #\$a3 contains &delimiter (delimiter is a byte array of size 1)

```
outer_cond:
  addiu $t0, $t0, 1
        $t4, $t0, $a1
  slt
  beq $t4, 1, outer_loop
  j exit
outer_loop:
  addu $t4, $t0, $a2
  lb
        $t4, 0($t4)
  lb
        $t6, 0($a3)
  subu $t5, $t4, $t6
  ori
        $at, $0, 1
  sltu $t5, $t5, $at
  beq $t5, 1, set_ending_index
  addi $at, $0, 0
  subu $t5, $t4, $at
        $at, $0, 1
  ori
  sltu $t5, $t5, $at
  beq $t5, 1, set_ending_index
  j outer_cond
set_ending_index:
```

```
addiu $t3, $t0, 1
  addu $t1, $0, $t2
  j inner_cond
inner_cond:
  slt
        $t4, $t1, $t3
  beq $t4, 1, inner_loop_print
  addiu $a0, $0, '\n'
  addiu $v0, $0, 0xB
  syscall
  j set_starting_index
set_starting_index:
  addu $t2, $0, $t3
  j outer_cond
inner_loop_print:
  addu $t4, $t1, $a2
  lb
        $t4, 0($t4)
  addu $a0, $0, $t4
  addiu $v0, $0, 0xB
  syscall
  addiu $t1, $t1, 1
j inner_cond
exit:
```

a. Consider the two applications above. Calculate the average CPI for each application on each processor (two applications cross two processors means you should have 4 different CPI values). Assume string_size is 20 in both applications, and sw_size is 3 (i.e., the stop word is "the") for application 1.

Application 1:

Here an example string of size 20 with stop word "the" of size 3 is chosen: "CPRE381 is the best!" and M is defined as **sw_size**. The loops are designed to break based on the identification of the starting index of the stop word within a chosen string. This is where the 11 is generated (as it is the location of the 't' within "the" in the chosen string) – meaning the loops will not always run in their entirety! Additionally, syscalls are ignored in the calculations but may be mapped to jumps/branches.

```
A/L/S/S
            Jamp
           addiu
                         $t0, $0, 0
           j outer_cond
         outer_loop:
A/4/5/5
           addiu $t1, $0, 0 } ||+|
           ial inner_cond
         outer_loop_cont:
           subu $t2, $t1, $a3
           ori $at, $0, 1
           altu
           $t2, $t2, $at addiu
A/L/S/S
A/L/S/S
           $t0, $t0, 1
           beg$t2, $0, outer cond lui
            $at, 0x1001
           ori $a0, $at, 0x19
           addiu $v0, $0, 4
           syscall
A/L/5/5
           lui $at, 0
A/L/S/S
A/L/S/S
A/L/S/S
           ori $at, $at, 1 subu
            $t0, $t0, $at
           <u>addu</u> $a0, $0, $t0
           addiu $v0, $0, 1
  Jamp
           syscall
           j exit
         cuter_cond:
A/L/S/S
A/L/S/S
           subu $t2, $a2,
           $a3 glt
  Brench
  Jump
           $10, $8, $10
           beq $t2, 1, outer_loop
           j exit 💡 🦠
         inner_loop:
A/L/S/5
           addu $t2, $t0, $t1
A/4/5/5
           addu $t2, $a0, $t2
  Loads
           lb $t3, 0($t2)
A/L/S/5
           addu $t2, $a1, $t1
 Leads
A/L/S/S
A/L/S/S
A/L/S/S
           1b
                 $t4, 0($t2)
           subu $t2, $t3, $t4
           sltu $t2, $0, $t2
           addiu $t1, $t1, 1
           beg $t2, 1, outer loop cont
         inner_cond:
A/L/S/S
Brench
           slt $t2, $t1, $a3
                 $t2, 1, inner_loop
           beg
                $ga }1
           įr
         exit:
```

Instruction	# Instructions		Frequency	Pro	cessor A	Processor B	
Type				CPI_i	CPI_i*Freq_i	CPI_i	CPI_i*Freq_i
Arithmetic, Logical, Shifts, Stores	9 + 7(11+1) + 6(11+M) + 1(11+M+1) =	192	0.66666667	3	2.0	3	2.0
Jumps	3 + 1(11+1) =	15	0.05208333	3	0.15625	2	0.10416666
Conditional Branch	2(11+1) + 1(11+M) + 1(11+M+1) =	53	0.18402778	3	0.55208333	2	0.36805555
Loads	2(11+M) =	28	0.09722222	3	0.2916666	5	0.4861111

Application 2:

Here an example string of size 20 with delimiter '' (a space) is chosen: "CPRE381 is the best" and M is defined as the number of occurrences of the delimiter AND the null byte at the end of the string (M = 4). Note, the size of the string must include that null byte for this application. N is defined as the string size. Additionally, syscalls are ignored in the calculations but may be mapped to jumps/branches.

```
outer_cond:
 A/L/S/S
             addiu $t0, $t0, 1
 A/L/S/S
                     $t4, $t0,
             slt
   Branch
             $a1
    Jump
                     $t4, 1, outer loop
             beg
             j exit
           outer_loop:
 A/4/5/5
                     $t4, $t0, $a2
             addu
    Loads
                    $t4, 0($t4)
             1b
    Loads
 A/4/5/5
             lb $t6, 0($a3) subu
 A/L/S/S
                 $t5, $t4, $t6 ori
 A/L/S/S
                 $at, $0, 1 sltu
   Brench
                 $t5, $t5, $at
 A/4/5/5
             beg
                     $t5, 1, set ending index
 A/L/S/S
A/L/S/S
             addi
                   $at, $0, 0
 A/L/5/5
             subu
                     $t5, $t4, $at
   Branch
                    $at, $0, 1
             ori
    Jamp
                     $t5, $t5,
             sltu
             $at
             beg
                     $t5, 1, set ending index
             j outer cond } N-M-1
           set_ending_index:
A/L/S/S
             addiu $t3, $t0, 1
 A/L/S/S
             addu $t1, $0, $t2
    Jamp
             j inner cond
           inner cond:
                                                  & W+N
A/4/5/5
             slt $t4, $t1, $t3
   Branch
             beg $t4, 1, inner loop print
A/4/5/5
             addiu $a0, $0, '\n'
A/4/5/S
             addiu $v0, $0, 0xB
             syscall
   Jamp
             j set_starting_index
           set starting index:
A/L/S/S
             addu $t2, $0, $t3
  Jump
             j outer cond
           inner_loop_print:
A/L/S/S
             addu $t4, $t1, $a2
  Loads
             lb.
A/L/S/S
A/L/S/S
             $t4, 0($t4) addu
             $a0, $0, $t4 addiu
A/4/5/5
             $v0, $0, 0xB
  Jump
             syscall
             addiu $t1, $t1, 1
             j inner cond
           exit:
```

Instruction	# Instructions			Pro	cessor A	Processor B	
Туре			Frequency	CPI_i	CPI_i*Freq_i	CPI_i	CPI_i*Freq_i
Arithmetic, Logical, Shifts, Stores	6(N) + 4(N-1) + 4(N-M) + 5(M) + 1(M+N) =	304	0.62167689	3	1.86503	3	1.86503
Jumps	1+ 1(N-M- 1)+ 3(M)+ 1(N)	48	0.09815951	3	0.294478	2	0.196319
Conditional Branch	1(N) + 1(N-1) + 1(N-M) + 1(N+M) +	79	0.16155419	3	0.484662	2	0.323108
Loads	2(N-1) + 1(N) =	58	0.11860941	3	0.355828	5	0.593047
Total		489	1	Average CPI	3	Average CPI	2.977505

b. Which processor has better performance? [Careful answering this part...it is a tricksy professor question.] Provide the quantitative evidence of "better performance" and include a description of how you evaluated the two applications together. What would the relative frequencies have to be between the two processors in order for their performance to be identical (i.e., calculate the "breakeven frequency")?

Remember that Execution Time = # insts * CPI * cycle time. So, assuming both processors have the same cycle time, Processor B has slightly better performance for BOTH applications since the Average CPI is lower for both applications (3 vs 2.958333 or 2.977505).

In order for the processors to have equal performance on application 1, you would set the Execution Time equations equal:

```
ET_ProcA = # insts_App1 * CPI_App1_ProcA * cycle time_ProcA= # insts_App1 * CPI_App1_ProcB * cycle time_ProcB = ET_ProcB
```

```
Freq_B/Freq_A = CPI_App1_ProcB/CPI_App1_ProcA = 0.986111
```

Likewise for the processors to have equal performance on application 2: Freq_B/Freq_A = CPI_App2_ProcB/CPI_App2_ProcA = 0.992501

Note that to actually consider what the overall performance of the entire workload on each processor is, you would want to consider the number of expected executions for each application times. If application 1 was 75% of all executions, the relative frequency would be 0.75 * (288 + 489)) * 0.986111 + (1 - 0.75 * (489 / (288 + 489))) * 0.992501 = 0.430287. Overall, these applications have fairly similar behavior.