CprE 381 Homework 3

[Note: This homework gives you more practice with the MIPS assembly language. When you are asked to assemble a program, you can try running it on SPIM/MARS to confirm it works. However, make sure you have it running in Bare Machine configuration so that your machine code matches the ISA.]

1. MIPS Machine Code

a. The following instruction (count or cnt) is not included in the MIPS instruction set:

```
cnt $t0, $t1
# The first operand is rt, the second operand is rd
# if (M[R[rt]] >= 0)
# R[rt] = R[rt]+1, R[rd] = R[rd] + 1, PC=PC
```

If this instruction were to be implemented in the MIPS instruction set, what is the most appropriate instruction format? Explain why. Provide a sequence of MIPS instructions that performs the same operation. Ungraded, but examworthy: Postulate why this instruction wasn't included the MIPS ISA (there is a general philosophical reason and at least one very specific technical reason). Since cnt requires two register operands it could be either an R-type or an I-type instruction (a J-type instruction has no register operands). It might be useful to use an I-type instruction with the immediate as 1 for use when incrementing the register operands, but this would not be particularly elegant.

One possible implementation:

```
j cond
loop:
    addi $t0, $t0, 1
    addi $t1, $t1, 1
cond:
          $at, 0($t0)
    1b
    slti $at, $at, 0
                             \# M[R[rt]] < 0
          $at, $zero, loop
                             \# !(M[R[rt]] < 0) =
                             (M[R[rt]] >= 0)
                             # PC = PC really means
                             keep executing the
                             functionality of the
                             instruction until the
                             condition doesn't match
                             and then allow the
                             default PC=PC+4 to move
```

One thing to be careful of is that you can't just perform the increment instructions first since they happen conditionally, even when the instruction is first executed. An alternative approach starts with a conditional branch and then unconditionally jumps back at the end, but that requires an additional instruction to be executed for each execution of the cnt instruction.

The likely reason that MIPS doesn't provide such an instruction is that it is doing multiple operations at once--a conditional evaluation, a memory operation, two register increments, and a conditional non-PC+4 PC update. Each of these operations would require separate hardware in an implementation or would require a more complex microcoded hardware design. Very specifically, the cnt instruction would require two registers in the register file to be written (since you've already done your Lab 2, you should appreciate why this would cause a hardware issue). In either case, this could hurt performance. Another reason could possibly be that it complicates the job of a compiler to choose when to use this complex instruction versus the simpler sequences (this instruction is only useful in very limited cases).

b. Translate the following MIPS assembly into machine code providing the following for each instruction. First, identify the instruction's format. Second, provide the decimal value for each instruction field. Third, provide the hex encoding of the entire instruction. Assume Begin is at 0×0.0400000 . begin:

```
addi $s1, $zero, 321
addi $s0, $zero, -32768
loop:
    sra $s0, $s0, 5
    addiu $s1, $s1, 1
    slti $t0, $s0, -1
    bne $t0, $zero, loop
    j begin
```

1. addi \$s1, \$zero, 321						
I-format						
Opcode (6) rs (5) rt (5) Imm (16)						
8	\$zero=0 \$s1=17 321					
0010 00						
0x20110141						

	2. addi	\$s0, \$z	ero, -32768
I-format			
Opcode (6)	rs (5)	rt (5)	Imm (16)
8	\$zero=0	\$s1=16	-32768

0010 00	00 000	1 0000	1000 0000	0000 0000
0x20108000				

3. sra \$s0, \$s0, 5						
R-format						
Opcode	rs (5)	rt (5)	rd (5)	shamt(5)	func	
(6)					(6)	
0 Unused=0 \$s0=16 \$s0=16 5 3						
0000 00 00 000 1 0000 1000 0 001 01 00 00						
0x00108143	3					

4 . addiu \$s1, \$s1, 1						
I-format						
Opcode (6)	rs (5)	rt (5)	Imm (16)			
9	\$s1=17	\$s1=17	1			
0010 01	10 001	1 0001	0000 0000 0000 0001			
0x26310001		•				

5. slti \$t0, \$s0, −1						
I-format						
Opcode (6) rs (5) rt (5) Imm (16)						
10	\$s0=16 \$t0=8 -1					
0010 10						
0X2A08FFFF	0X2A08FFFF					

6. bne \$t0, \$zero, loop						
I-format						
Opcode (6) rs (5) rt (5) Imm (16)						
5	\$t0=8	\$zero=0	-4			
0001 01						
0x1500FFFC						

	8. j begin
J-format	
Opcode (6)	Target address (26)
2	Bits 27:2 of 0x00400000
0000 10	00 0001 0000 0000 0000 0000
0x08100000	

c. We've discussed in class and on Canvas that you cannot load an arbitrary 32 bit integer (e.g., $0 \times 320 FF1CE$) using a single instruction. Look up the 1ui instruction and provide a two-instruction sequence that loads $0 \times 320 FF1CE$ into \$t0. Then, assuming that 1ui is not supported by the ISA, provide a valid

three-instruction sequence that loads $0 \times 320 FF1CE$ into \$t0. Translate these into MIPS machine code providing the same steps as part 1.b.

lui \$t0, 0xFEED
ori \$t0, \$t0, 0x3210

lui \$t0, 0xFEED						
I-format						
Opcode (6)	rs (5)	rt (5)	Imm (16)			
15	Unused=0	\$t0=8	65261			
0011 11	00 000	0 1000	1111 1110 1110 1101			
0x3C08FEED						

ori \$t0, \$t0, 0x3210						
I-format						
Opcode (6)	Opcode (6) rs (5) rt (5) Imm (16)					
13 \$t0=8 \$t0=8 12816						
0011 01						
0x35083210						

ori \$t0, \$zero, 0xFEED
sll \$t0, \$t0, 16
ori \$t0, \$t0, 0x3210

ori \$t0, \$zero, 0xFEED						
I-format						
Opcode (6)	rs (5)	rt (5)	Imm (16)			
13	\$zero=0 \$t0=8 65261					
0011 01	00 000	0 1000	1111 1110 1110 1101			
0x3408FEED						

sl1 \$t0, \$t0, 16							
R-format	R-format						
Opcode	rs (5)	rt (5)	rd (5)	shamt(5)	func		
(6)					(6)		
0	Unused=0	\$t0=8	\$t0=8	16	0		
0000 00	00 000	0 1000	0100 0	100 00	00 0000		
0x00084400)						

ori \$t0, \$t0, 0x3210			
I-format			
Opcode (6)	rs (5)	rt (5)	Imm (16)
13	\$t0=8	\$t0=8	12816
0011 01	01 000	0 1000	0011 0010 0001 0000
0x35083210			

- 2. MIPS Programming with procedures [I suggest you actually simulate this program using the provided version of MARS to confirm that they work. Do not simply copy these from online examples or from the result of a compiler. **YOU MUST COMMENT WHAT YOU ARE DOING**.]
 - a. Write a MIPS program that iteratively (i.e., using a for loop) calculates the Fibonacci number, F_N , for an inputted number, N (this is the same functionality as your high-level program from HW0 Q2c). Have N be an integer entered by a user and print F_N to the console. [See MARS lecture companion files for an example of how to read an integer in MARS and print an output.] See prob2a.s for one solution.
 - b. Write a second MIPS program that recursively calculates F_N (i.e., using a procedure that calls itself with an updated argument). Make sure to follow the convention presented in lecture. Specifically, use the appropriate saved vs temporary registers, argument passing registers, return value registers, and a basic stack frame with appropriate alignment. See prob2b.s for one solution (there are many ways to do this).
 - c. How many instructions (i.e., dynamic instructions) were executed in your two different programs? Briefly show your calculations. [MARS has a tool that can count instructions, which I suggest you use to verify that your hand calculations are reasonably close.]

For the iterative version, there six instructions in the case of N=1. Every additional iteration requires an additional six instructions. So the total instruction count is 6*N for N>1.

For the recursive version, there are 3 instructions to setup and call the initial function, 4 instructions executed in the base case, and 12 instructions to execute each non-base call. So # insts = 7+12*(N-2). For example, N=10 executes the original call, 1 base case call (N=2), and 8 non-base case calls.