

SYSTEM WIRING DIAGRAMS

Air Conditioning Circuits

1997 BMW 328i

SYSTEM WIRING DIAGRAMS

Anti-lock Brake Circuits, W/ Traction Control (1 of 2)

1997 BMW 328i

SYSTEM WIRING DIAGRAMS

Anti-lock Brake Circuits, W/ Traction Control (2 of 2)

1997 BMW 328i

SYSTEM WIRING DIAGRAMS

Anti-lock Brake Circuits, W/O Traction Control

1997 BMW 328i

SYSTEM WIRING DIAGRAMS
Drive-Away Protection (EWS II)
1997 BMW 328i

SYSTEM WIRING DIAGRAMS

Forced Entry Circuit

1997 BMW 328i

SYSTEM WIRING DIAGRAMS
Body Computer Module Circuit
1997 BMW 328i

SYSTEM WIRING DIAGRAMS

On-Board Computer Circuit

1997 BMW 328i

SYSTEM WIRING DIAGRAMS

Computer Data Lines

1997 BMW 328i

SYSTEM WIRING DIAGRAMS

Auxiliary Cooling Fan Circuit

1997 BMW 328i

SYSTEM WIRING DIAGRAMS

Cruise Control Circuit

1997 BMW 328i

SYSTEM WIRING DIAGRAMS

Defogger Circuit

1997 BMW 328i

SYSTEM WIRING DIAGRAMS

2.8L, Engine Performance Circuits (1 of 2)

1997 BMW 328i

SYSTEM WIRING DIAGRAMS

2.8L, Engine Performance Circuits (2 of 2)

1997 BMW 328i

SYSTEM WIRING DIAGRAMS

Back-up Lamps Circuit

1997 BMW 328i

SYSTEM WIRING DIAGRAMS

Exterior Light Circuit (1 of 3)

1997 BMW 328i

SYSTEM WIRING DIAGRAMS

Exterior Light Circuit (2 of 3)

1997 BMW 328i

SYSTEM WIRING DIAGRAMS

Exterior Light Circuit (3 of 3)

1997 BMW 328i

SYSTEM WIRING DIAGRAMS
Ground Distribution Circuit (1 of 5)
1997 BMW 328i

SYSTEM WIRING DIAGRAMS
Ground Distribution Circuit (2 of 5)
1997 BMW 328i

SYSTEM WIRING DIAGRAMS
Ground Distribution Circuit (3 of 5)
1997 BMW 328i

SYSTEM WIRING DIAGRAMS
Ground Distribution Circuit (4 of 5)
1997 BMW 328i

SYSTEM WIRING DIAGRAMS
Ground Distribution Circuit (5 of 5)
1997 BMW 328i

SYSTEM WIRING DIAGRAMS

Headlight Circuit (1 of 2)

1997 BMW 328i

SYSTEM WIRING DIAGRAMS

Headlight Circuit (2 of 2)

1997 BMW 328i

SYSTEM WIRING DIAGRAMS

Horn Circuit

1997 BMW 328i

SYSTEM WIRING DIAGRAMS
Instrument Cluster Circuit (1 of 2)
1997 BMW 328i

SYSTEM WIRING DIAGRAMS
Instrument Cluster Circuit (2 of 2)
1997 BMW 328i

SYSTEM WIRING DIAGRAMS

Interior Light Circuit (1 of 2)

1997 BMW 328i

SYSTEM WIRING DIAGRAMS

Interior Light Circuit (2 of 2)

1997 BMW 328i

SYSTEM WIRING DIAGRAMS
Power Distribution Circuit (1 of 5)
1997 BMW 328i

SYSTEM WIRING DIAGRAMS
Power Distribution Circuit (2 of 5)
1997 BMW 328i

SYSTEM WIRING DIAGRAMS
Power Distribution Circuit (3 of 5)
1997 BMW 328i

SYSTEM WIRING DIAGRAMS
Power Distribution Circuit (4 of 5)
1997 BMW 328i

SYSTEM WIRING DIAGRAMS
Power Distribution Circuit (5 of 5)
1997 BMW 328i

SYSTEM WIRING DIAGRAMS

Power Door Lock Circuit

1997 BMW 328i

SYSTEM WIRING DIAGRAMS

Power Mirror Circuit

1997 BMW 328i

SYSTEM WIRING DIAGRAMS

Heated Seats Circuit

1997 BMW 328i

SYSTEM WIRING DIAGRAMS

Power Seat Circuit

1997 BMW 328i

SYSTEM WIRING DIAGRAMS

Sunroof Circuit

1997 BMW 328i

SYSTEM WIRING DIAGRAMS

Power Window Circuit (1 of 2)

1997 BMW 328i

SYSTEM WIRING DIAGRAMS

Power Window Circuit (2 of 2)

1997 BMW 328i

SYSTEM WIRING DIAGRAMS

Shift Interlock Circuit

1997 BMW 328i

SYSTEM WIRING DIAGRAMS

Charging Circuit

1997 BMW 328i

SYSTEM WIRING DIAGRAMS

Starting Circuit

1997 BMW 328i

SYSTEM WIRING DIAGRAMS
Supplemental Restraint Circuit
1997 BMW 328i

SYSTEM WIRING DIAGRAMS

A/T Circuit (1 of 2)

1997 BMW 328i

SYSTEM WIRING DIAGRAMS

A/T Circuit (2 of 2)

1997 BMW 328i

SYSTEM WIRING DIAGRAMS

Transmission Circuit (1 of 2)

1997 BMW 328i

SYSTEM WIRING DIAGRAMS

Transmission Circuit (2 of 2)

1997 BMW 328i

SYSTEM WIRING DIAGRAMS

Warning System Circuits

1997 BMW 328i

SYSTEM WIRING DIAGRAMS

Wiper/Washer Circuit, Canada

1997 BMW 328i

SYSTEM WIRING DIAGRAMS

Wiper/Washer Circuit, USA

1997 BMW 328i