

Thank you for your purchase, here are some notes on the install

- *The red oval is a solder blob to short D0 to ground (or solder the D0 wire to the bottom pad)
- *Make sure the yellow through hole is soldered, a small wire can help if you have issues, or you can add a solder blob to the motherboard hole before placing the LPC board
- 1) Install the pin header and LPC board at the same time by taping the pin header to the front of the board, this will make the install much easier
- 2) Make sure to align the edge holes before soldering anything in place Email me kekule@chimericsystems.com if you have more questions