

Thank you for your purchase, here are some notes on the install

- \*The red oval is a solder blob to short D0 to ground
- \*Make sure the yellow through hole is soldered, a small wire can help if you have issues, or you can add a solder blob to the motherboard hole before placing the LPC board
- 1) Install the pin header and LPC board at the same time by taping the pin header to the front of the board, this will make the install much easier

Email me kekule@chimericsystems.com if you have more questions