```
smacc::Orthogonal

    stateMachine

  - clientBehaviors
  - clients
  + setStateMachine()
   + addClientBehavior()
   + onEntrv()
   + onExit()
  + getName()
   + createClient()
  + requiresComponent()
  + requiresClient()
   + aetClients()
   + getClientBehaviors()
   onInitialize()
sm viewer sim::OrNavigation
```

+ onInitialize()