


**Industrial PC** 

# PPC-J1900-190-R



PN: PPC-J1900-190-R

## Contents

| 1. PPC-J1900-190-R               | 3  |
|----------------------------------|----|
| 1.1. Product Overview            | 4  |
| 1.2. Ordering Options            | 5  |
| 1.2.1. Operating System          | 5  |
| 1.2.2. Optional Features         | 5  |
| 1.3. Hardware Features           | 6  |
| 1.4. Power Input                 | 7  |
| 1.5. Touch screen                | 7  |
| 1.6. Connectivity                | 8  |
| 1.6.1. RS232/485/GPIO Connectors | 8  |
| 1.6.2. USB HOST Connectors       | 9  |
| 1.6.3. LAN Connectors            | 9  |
| 1.6.4. HDMI Connector            | 10 |
| 1.7. Mounting Procedure          | 10 |
| 1.8. Mechanical Specifications   | 10 |
| 1.9. Disclaimer                  | 11 |
| 1.10. Technical Support          | 11 |

# PPC-J1900-190-R



Front View



**Rear View** 

PPC-J1900-190-R Product Overview



Side View 1



Side View 2

## **Product Overview**

The PPC-j1900 series PPC-J1900-190-R is a rugged, high-quality NEMA 4X/IP65-compliant industrial panel PC. It features a 19.0" resistive touch screen with a resolution of 1280 x 1024 pixels.

#### **Key Applications**

- Human Machine Interface HMI
- Industrial Automation
- Process Control

PPC-J1900-190-R Ordering Options

- Smart Grid Management
- CNC Manufacturing
- Environmental Monitoring
- Machine Vision Inspection
- · ATM, Kiosk, Infotainment...

The PPC-J1900-190-R Industrial Panel PC is powered by Intel<sup>®</sup> Celeron<sup>®</sup> J1900 quad-core CPU and equipped with a broad range of connectivity options, allowing it to meet highly demanding application requirements in harsh industrial or outdoor environments.

A specially designed magnesium-aluminum alloy housing with fins for increased heat dissipation serves as a passive cooler, eliminating the need for built-in fans. The fan-less design reduces noise, as well as the maintenance costs and efforts, increasing reliability at the same time.



#### **A** Caution

Be careful when handling the product while it is operating: the back panel might become hot under heavy CPU load.

## **Ordering Options**

Most of the Chipsee products can be customized during the ordering process. The product will be shipped with the pre-installed factory defaults if no extra requirements are specified. The table in the Hardware Features section provides information about the default options bundled with the product.



#### Note

You can order The PPC-J1900-190-R Industrial Panel PC from the official **Chipsee Store** or from your nearest distributor.

#### Operating System

By default, PPC-J1900-190-R comes with the Linux operating system (OS) pre-installed. A different OS can be selected during the ordering process. In addition to Linux, PPC-J1900-190-R also supports Windows 7 and Windows 10 OS.

#### **Optional Features**

The PPC-J1900-190-R Industrial Panel PC does not include WiFi/BT and/or 3G/4G modules by default. The Wi-Fi/BT module is optional and can be selected during the ordering process.

PPC-J1900-190-R Hardware Features

A 3G/4G LTE module is not available at the Chipsee store for this product. However, it can be obtained from specialized third-party suppliers.



#### Warning

Installation, repair, and maintenance tasks should be performed by trained personnel only. Chipsee does not bear any responsibility for damage caused by inadequate handling of the product.

### Hardware Features

The PPC-J1900-190-R Industrial Panel PC offers a broad range of performance and connectivity options for scalable integration, providing expandability according to future needs. Some of the key features are listed in the table below.

| PPC-J1900-190-R   |                                                                        |  |
|-------------------|------------------------------------------------------------------------|--|
| СРИ               | Intel® Celeron® J1900, 2GHz, Quad-Core, 2MB Cache, TDP=10W             |  |
| GPU               | Intel® HD integrated GPU, 512MB shared memory                          |  |
| RAM               | Default 4GB, maximum supported 8GB, DDR3L 1333 SO-DIMM                 |  |
| Display           | 19.0" LCD, resolution 1280 x 1024 px, brightness 400 cd/m <sup>2</sup> |  |
| Storage           | Default mSATA 64GB SSD, supports up to 512GB                           |  |
| Touch             | Resistive touch screen                                                 |  |
| USB               | 1 x USB 3.0 HOST, 3 x USB 2.0 HOST ports (Type A)                      |  |
| LAN               | 2 x RJ45, GbE (Intel® l211), Wake on LAN (WoL) support                 |  |
| UART              | Default 4 x RS232 (2 x RS485 optional)                                 |  |
| GPIO              | 8 x General Purpose I/O (GPIO) channels                                |  |
| 3G/4G             | Optional, module available from other manufacturers/stores             |  |
| WiFi/BT           | Optional, module available from the Chipsee store                      |  |
| НДМІ              | 1 x HDMI out                                                           |  |
| SATA              | 1 x mSATA SSD electronic disk supports; 1x SATA 2.5" HDD               |  |
| Power IN          | From 9V to 30V DC                                                      |  |
| Power Consumption | 35W                                                                    |  |
| os                | Default Linux, Windows 7, Windows 10                                   |  |
| Operating Temp.   | From -20°C to +60°C                                                    |  |
| Dimensions        | 447 x 371 x 55mm                                                       |  |
| Mounting          | VESA 100, Panel mounting with fixtures                                 |  |
| Weight            | 5200g                                                                  |  |

Table 196 Table 1: Key Features

PPC-J1900-190-R Power Input

### Power Input

The PPC-J1900-190-R Industrial Panel PC can be powered by a wide range of input voltages: from 9V to 30V DC. The power input connector is a 2-pin, 3.81mm screw terminal (*Figure 1*). The polarity of the power connector is clearly labeled on the housing itself: the '+' sign is the positive, while the '-' sign is the negative power supply input.

The **POWER** button is located next to the power input connector and can be used to switch the power ON or OFF.

The power input section of PPC-J1900-190-R features a range of protection features, including over-current, over-voltage, power surge, and reverse polarity protection, allowing it to meet stringent industrial safety regulations.



Figure 807: Figure 1: Power Input Section



If the product is used to control some key processes, it is highly recommended to use an Uninterruptible Power Supply (UPS) to prevent critical data loss.

### Touch screen

PPC-J1900-190-R is equipped with a resistive touch screen. The resistive touch screen is an ideal option for harsh industrial conditions due to its high immunity against high temperature, dirt, and dust. In addition, it does not require any special material to be operated; the resistive touch screen can be used with regular rubber gloves, fingers, or a plastic stylus.

**Size/Type:** 19.0" high-temperature resistant, five-wire analog resistive touch screen

Surface Hardness: 3H

**Service Life (MTBF):** 35 million click events

**Light Transmittance:** > 81%

PPC-J1900-190-R Connectivity


## Connectivity

There are many connectivity options available on the PPC-J1900-190-R industrial PC. It has 4 x USB Type A connectors configured as HOSTS, 1 x HDMI port, 2 x RJ45 connectors supporting Gigabit Ethernet (GbE), and up to 4 x RS232 connectors, of which two can be configured in the RS485 mode. There are also 8 x GPIO channels for various user-defined purposes.

#### RS232/485/GPIO Connectors

The PPC-J1900-190-R Industrial Panel PC has 2 x 9-pin D-sub connectors and 1 x 16-pin 3.81mm connector with pluggable terminal block (*Figure 2*). Two 9-pin D-sub connectors labeled as **COM1** and **COM2** can be configured either as RS232 or RS485 communication interfaces.

The bottom row of terminals on the terminal block is labeled as **COM3/4**. These terminals are configured as two additional RS232 interfaces by default. The upper row of terminals on the terminal block represents eight **GPIO** channels, labeled as **GPIO** (0 ... 7).



**Figure 808:** Figure 2: Connectivity Section - 2 x D-sub Connectors & 16-pin Double-Row Pluggable Terminal Block



The default configuration of the PPC-J1900-190-R industrial PC is 4 x RS232 interfaces and 8 x GPIO channels. If you need different configuration, please contact Chipsee Technical Support at **support@chipsee.com** 

PPC-J1900-190-R USB HOST Connectors

#### **USB HOST Connectors**

PPC-J1900-190-R is equipped with 3 x USB 2.0 connectors and 1 x USB 3.0 HOST connector. The **USB** connectors are configured as shown in *Figure 3*. The data throughput of the USB 3.0 interface can reach up to 4.8 Gbps, while the USB 2.0 interfaces are limited to 480 Mbps.

Although fully compatible with USB 2.0 devices, the USB 3.0 interface provides 10 times more data transfer bandwidth than USB 2.0, making it best suited for fast peripherals that can utilize its full potential.



Figure 809: Figure 3: USB HOST Connectors

#### LAN Connectors

2 x **LAN (RJ45) connectors** (*Figure 4*) provide Ethernet connectivity over standardized Ethernet cables. The integrated two-port Ethernet interface supports 10/100/1000BASE-T/TX specifications with automatic speed negotiation and Wake on LAN (WoL) functionality. Power over Ethernet (PoE) is not supported.



Figure 810: Figure 4: 2 x RJ45 GbE LAN Connectors



Use CAT5 or better cables to achieve full data throughput over maximum distance defined by the 1000BASE-T standard (100m).

PPC-J1900-190-R HDMI Connector

#### **HDMI** Connector

The PPC-J1900-190-R Industrial Panel PC is equipped with 1 x **HDMI** connector. The HDMI connector (*Figure 5*) allows connecting an additional (external) monitor. HDMI output resolution can be configured by the software.



Figure 811: Figure 5: HDMI Connector


## Mounting Procedure

The PPC-J1900-190-R Industrial Panel PC supports VESA 100 x 100 mounting pattern with 4 x M4 screws, enabling simplified installation onto any standard VESA mounting rack. Other mounting options might also be supported according to the table in the Hardware Features section.

You can find detailed information about mounting in the Mount IPC Guide.

## Mechanical Specifications

The outer mechanical dimensions of The PPC-J1900-190-R Industrial Panel PC are 447 x 371 x 55mm (W x L x H). Please refer to the technical drawing in the figure below for details related to the specific product measurements.



#### Disclaimer

This document is provided strictly for informational purposes. Its contents are subject to change without notice. Chipsee assumes no responsibility for any errors that may occur in this document. Furthermore, Chipsee reserves the right to alter the hardware, software, and/or specifications set forth herein at any time without prior notice and undertakes no obligation to update the information contained in this document.

While every effort has been made to ensure the accuracy of the information contained herein, this document is not guaranteed to be error-free. Further, it does not offer any warranties or conditions, whether expressed orally or implied in law, including implied warranties and conditions of merchantability or fitness for a particular purpose. We specifically disclaim any liability with respect to this document, and no contractual obligations are formed either directly or indirectly by this document.

Despite our best efforts to maintain the accuracy of the information in this document, we assume no responsibility for errors or omissions, nor for damages resulting from the use of the information herein. Please note that Chipsee products are not authorized for use as critical components in life support devices or systems.

## **Technical Support**

If you encounter any difficulties or have questions related to this document, we encourage you to refer to our other documentation for potential solutions. If you cannot find the solution you're looking for, feel free to contact us. Please email Chipsee Technical Support at **support@chipsee.com**, providing all relevant information. We value your queries and suggestions and are committed to providing you with the assistance you require.