



Industrial PC

# Debian 10 OS on RK3399

## User Manual

For RK3399 Products

Content can change at anytime, check our website for latest information of this product.

[www.chipsee.com](http://www.chipsee.com)

# Contents

---

|                                               |   |
|-----------------------------------------------|---|
| Debian 10 OS                                  | 3 |
| 1. Backup Your OS Image For Bulk Installation | 4 |
| 1.1. Prepare for backup                       | 4 |
| 1.2. Prepare a Bootable SD Card               | 4 |
| 1.3. Backup Your eMMC                         | 5 |
| 1.4. Generate New Image File                  | 6 |
| 2. Disclaimer                                 | 8 |
| 3. Technical Support                          | 8 |

# Debian 10 OS

## Debian 10 OS on RK3399 User Manual



This is the software manual for RK3399 Chipsee industrial PC. If you've never developed on this hardware with a Debian 10 OS, this manual can get you started quickly.

# Backup Your OS Image For Bulk Installation

If you have finished developing your software, and plan to “copy” the whole system to many other Chipsee industrial PCs, you can backup the OS to an image file, just like the **.img** file you downloaded from Chipsee, or the OS we installed in the factory for you before shipping. And then you can flash it to many more devices.

## Prepare for backup

We will use **SDDiskTool** to flash a bootable SD card, let your Chipsee PC boot from this SD card, then use this system to backup your OS image (the whole content on eMMC rootfs partition). You will need:

- **SDDiskTool** ([Click to download](#)).
- 16GB or larger micro SD card.
- SD card reader (to be used on your HOST PC).
- A Windows PC to run the SDDiskTool.
- A (X86 or X86\_64) Linux HOST PC or virtual machine to make a new img file (make sure there is 25GB or more free space on the disk for the following process).
- Two **Chipsee prebuilt image**, one is the image that you are developing your software on, the other is a prebuilt-xxx-sd-xx.img, if you cannot find the prebuilt-xxx-sd-xx.img of your device, you can use just the prebuilt-xxx-emmc-xx.img temporarily, we will release the sd image later.

### Note

More on the prebuilt image: the core idea of backup is to “swap” your data and the prebuilt data. So we will need to download a prebuilt image that you’re developing your software on (the OS image that you’re currently using on the Chipsee PC), unpack that image, swap the data, then repack the image.

### Note


We will use the prebuilt-xxx-emmc-xx.img (eMMC firmware) to boot the device from an SD card (imagine the old time people use a WinPE USB stick to boot and backup Windows!), but the image for eMMC has one known bug: it will need reboot a few times to get the SD partition to be mounted on “/”. We will release one new image for SD called prebuilt-xxx-sd-xx.img in the future. But at the moment we can still get by with the eMMC image in an SD card. (For *7 inch RK3399(EPC/PPC-A72-070-C)* user, you can select prebuilt-xxx-sd-xx.img now.)

## Prepare a Bootable SD Card

On your Windows PC, we open SD\_Firmware\_Tool.exe to process 1,2,3,4,5 steps to create a bootable SD card.

You need to download the Chipsee prebuilt image as we mentioned earlier. Find the one that fits your screen size in [Chipsee prebuilt image](#) page.

Once the SD card is flashed, Windows will show a warning to let you format the unrecognized partition, **ignore or cancel** it because the SDDiskTool creates some partitions that Windows doesn't recognize.



*Follow the 5 steps on SDDisktool*

## Backup Your eMMC

Insert this SD card into the SD slot of the Chipsee PC and power it on, the Chipsee PC will boot into the system on the SD card (may need to reboot multiple times to boot from SD card, because of a known bug in the eMMC firmware, we will release a firmware for SD card in the future), we can use this system to backup the whole contents on eMMC rootfs partitions.

Use the way you like to execute the following commands, for example, serial debug or ssh. You can connect a keyboard and mouse to the Chipsee device and run them in the command line as well.

The eMMC rootfs partition is `/dev/mmcblk2p8`. We will backup the contents in `/dev/mmcblk2p8`.

| NAME         | MAJ:MIN | RM | SIZE  | RO | TYPE | MOUNTPOINT                                 | # lsblk | mmcblk1 is SD Card |
|--------------|---------|----|-------|----|------|--------------------------------------------|---------|--------------------|
| mmcblk1      | 179:0   | 0  | 14.9G | 0  | disk |                                            |         |                    |
| └─mmcblk1p1  | 179:1   | 0  | 4M    | 0  | part |                                            |         |                    |
| └─mmcblk1p2  | 179:2   | 0  | 4M    | 0  | part |                                            |         |                    |
| └─mmcblk1p3  | 179:3   | 0  | 4M    | 0  | part |                                            |         |                    |
| └─mmcblk1p4  | 179:4   | 0  | 32M   | 0  | part |                                            |         |                    |
| └─mmcblk1p5  | 179:5   | 0  | 32M   | 0  | part |                                            |         |                    |
| └─mmcblk1p6  | 179:6   | 0  | 32M   | 0  | part |                                            |         |                    |
| └─mmcblk1p7  | 179:7   | 0  | 64M   | 0  | part |                                            |         |                    |
| └─mmcblk1p8  | 179:8   | 0  | 14G   | 0  | part | /                                          |         |                    |
| └─mmcblk1p9  | 179:9   | 0  | 763M  | 0  | part |                                            |         |                    |
| mmcblk2      | 179:32  | 0  | 14.6G | 0  | disk |                                            |         |                    |
| └─mmcblk2p1  | 179:33  | 0  | 4M    | 0  | part |                                            |         |                    |
| └─mmcblk2p2  | 179:34  | 0  | 4M    | 0  | part |                                            |         |                    |
| └─mmcblk2p3  | 179:35  | 0  | 4M    | 0  | part |                                            |         |                    |
| └─mmcblk2p4  | 179:36  | 0  | 32M   | 0  | part |                                            |         |                    |
| └─mmcblk2p5  | 179:37  | 0  | 32M   | 0  | part |                                            |         |                    |
| └─mmcblk2p6  | 179:38  | 0  | 32M   | 0  | part |                                            |         |                    |
| └─mmcblk2p7  | 179:39  | 0  | 64M   | 0  | part |                                            |         |                    |
| └─mmcblk2p8  | 179:40  | 0  | 14G   | 0  | part |                                            |         |                    |
| └─mmcblk2p9  | 179:41  | 0  | 394M  | 0  | part | /media/linaro/914cdfb4-5d20-40c5-99cd-6310 |         |                    |
| mmcblk2boot0 | 179:64  | 0  | 4M    | 1  | disk |                                            |         |                    |
| mmcblk2boot1 | 179:96  | 0  | 4M    | 1  | disk |                                            |         |                    |
| mmcblk2rpm   | 179:128 | 0  | 4M    | 0  | disk |                                            |         |                    |

The mmcblk1p8(SD Partition) must be mounted on "/", if not, try to un-plug SD and plug SD and try reboot again.

It's one known bugs, we must reboot times to get the mmcblk1p8 be mounted on "/". We will released one image for SD boot to solve this issue in future

mmcblk2 is eMMC

eMMC rootfs partition is **/dev/mmcblk2p8**

```
$ sudo su
# export R00TFS_DEV=/dev/mmcblk2p8
# mkdir /mnt/backuprootfs
# mount $R00TFS_DEV /mnt/backuprootfs/
# cd /mnt/

// sync would take an hour or more depending on the files in your system
# tar --numeric-owner -jcvpf backuprootfs.tar.bz2 backuprootfs && sync
# umount /mnt/backuprootfs
```

Now we have obtained the backup rootfs **backuprootfs.tar.bz2** in the SD card partition

## Generate New Image File

Poweroff the Chipsee PC. Put the SD card into your Linux HOST PC (or virtual machine).

You should find a **/dev/sdX** in your Linux system, for example **/dev/sdb**, which is this SD card, **you should use your actual /dev/sdX here**, if you don't know which sdX is it, check with `df -h` and see which one's size is most likely your SD card.

Now we mount **/dev/sdb8** to find backuprootfs.tar.bz2

```
# mount /dev/sdb8 /mnt/
```

It will be in **/mnt/mnt/backuprootfs.tar.bz2**, we will copy it out to our Linux PC later.

Run the following command to generate a new `.img` file. Make sure you have at least 25GB free space on your Linux PC, the process produces a lot of intermediate files.

```
$ sudo su
# git clone https://gitee.com/chipsee_admin/rk_pack_tools.git
# cd rk_pack_tools
# git checkout master
```

```
// copy the Chipsee prebuilt img file to this directory
# cp prebuilt-xxx.img .
# ./cs-unpack.sh prebuilt-xxx.img

// copy your backup rootfs from SD card to this directory
# cp /mnt/mnt/backuprootfs.tar.bz2 .

// generate rootfs.img file from backuprootfs.tar.bz2
# ./cs-mkrootfs.sh

// generate new img file
# ./cs-pack.sh prebuilt-new-xxx.img
```

 **Warning**

If you see *checksum miss match error* or *Error:<AddFile> write file failed,err=28*, check your harddisk and make sure you have enough free space.

Now you have obtained your new img file prebuilt-new-xxx.img in the current folder, use this img file to flash other devices.

## Disclaimer

**This document is provided strictly for informational purposes. Its contents are subject to change without notice. Chipsee assumes no responsibility for any errors that may occur in this document. Furthermore, Chipsee reserves the right to alter the hardware, software, and/or specifications set forth herein at any time without prior notice and undertakes no obligation to update the information contained in this document.**

**While every effort has been made to ensure the accuracy of the information contained herein, this document is not guaranteed to be error-free. Further, it does not offer any warranties or conditions, whether expressed orally or implied in law, including implied warranties and conditions of merchantability or fitness for a particular purpose. We specifically disclaim any liability with respect to this document, and no contractual obligations are formed either directly or indirectly by this document.**

**Despite our best efforts to maintain the accuracy of the information in this document, we assume no responsibility for errors or omissions, nor for damages resulting from the use of the information herein. Please note that Chipsee products are not authorized for use as critical components in life support devices or systems.**

## Technical Support

If you encounter any difficulties or have questions related to this document, we encourage you to refer to our other documentation for potential solutions. If you cannot find the solution you're looking for, feel free to contact us. Please email Chipsee Technical Support at [support@chipsee.com](mailto:support@chipsee.com), providing all relevant information. We value your queries and suggestions and are committed to providing you with the assistance you require.