BOM for ODS-MPSv0.1.0 Components

Compor					Manufacturer	Manufacturer Link		Supplier			ShenZhen			EasyED/		
O ID	Image	Component Name	Mounting Type	Manufacturer	Part #	Link	Supplier	Part # ODS-	Supplier Link	Supplier Description	OPL MPN	Component Notes	Quantity	BOM ID	Designator	Notes
1	15	Motion Plane v0.1.0	Fastener	Seeed Studio			Team		https://github.c	Motion Plane v0.1.0 for Squid			1	N/A		
2	5	2x20 Female Header, Tall Stacking	PTH	Sullins Connector Solutions	PPPC202LFH N-M53 RC	https://media.d	Pololu	2749	https://www.po	Stackable 0.100" Female Header with Extra		Next version will replace with SMT headers.	3		6 C1,C3,C2	The female side should be on the underside of the board, while the male pins should stick up.
3	16	SilentStepStick Stepper Driver Board	Daughter Board	Trinamic	TMC2209	https://www.tri	r Digi-Key	1460-1395- ND	https://www.dig	I TMC2209 STEPPER DRIVER BOARD			4	N/A	Driver 1, Driver 2, Driver 3, Driver 4	Solder the UART/PDN jumper pads on the boar first! Then place on the male headers (short ends), confirm correct orientation, and solder.
4	17	1x8 Female Header	SMT	Sullins Connector Solutions		https://www.su	Digi-Key	S5639-ND	https://www.dig	ii CONN HDR 8POS 0.1 GOLD SMD			8		H4, H5, H6, H7, H8, H9, H10, H11	
5	9	1X8 Male Header	PTH	Pololu	965	https://www.po	Pololu	965	https://www.po	0.100" (2.54 mm) Breakaway Male Header: lt 1×40-Pin, Straight, Black		Next version will replace with SMT header. Need to break off appropriate length of header.	8	N/A	H10, H11	Break of appropriate length of header and inser long ends into the female headers.
6	18	100uF Electrolytic Capacitor	SMT	Nichicon	UCD1E470MC L1GS	https://www.nie	Digi-Key	493-6385- 1-ND	https://www.dig	ji CAP ALUM 47UF 20% 25V SMD	UCD1E47 0MCL1GS		4	1	C1,C2,C3, 1 C4	Confirm correct orientation.
7	19	DC Power Jack	SMT	CUI Devices	PJ-037AH- SMT-TR	https://www.cu	i Digi-Key	CP- 037AHPJC T-ND		CONN PWR JACK 2X5.5MM SOLDER			1		5 J5	Solder the SMT pads first, then solder the PTH pins.
8	20	Green Indicator LED	SMT	Everlight Electronics	17- 21SYGC/S530 -E2/TR8	http://www.eve	⊒ Digi-Key	1080-1500- 1-ND	https://www.dig	i LED YELLOW/GREEN CLEAR 0805 SMD	17- 21SYGC/S 530- E2/TR8		2	1:	2 LED1,LED2	Confirm correct orientation.
9	21	1K Resistor	SMT	Yageo	RC1206FR- 071KL	https://www.ya	Digi-Key	311-1.00 KFRCT-ND	https://www.dig	i RES SMD 1K OHM 1% 1/4W 1206	RC1206JR -071KL		2		9 R1,R3	
)	22	100 Resistor	SMT	Yageo	RC1206FR- 07100RL	https://www.ya	g Digi-Key	311- 100FRCT- ND	https://www.dig	ii RES SMD 100 OHM 1% 1/4W 1206	RC1206JR -07100RL		1	1;	3 R2	
1	23	SP4T Mux/Demux	SMT	Nexperia	74HC4052D, 653	https://www.ne	Digi-Key	1727-2808- 1-ND	https://www.dig	IC MUX/DEMUX DUAL 4X1 16SOIC	74HC4052 D,653	In a future version, we'll try using the MS1/MS2 UART addressing system instead of a UART mux/demux.	1	10) U1	Confirm correct orientation.
2	24	1x4 Spring Clamp Terminal Block	SMT	Phoenix Contact	1814650	https://www.ph	Digi-Key	277-10064- 1-ND	https://www.dic	TERM BLOCK 4POS			4		2 J1,J2,J3,J4	First solder the pads on the side, then solder the SMT pins.
3	25	1x6 1.5mm Pitch Right-Angle Header	SMT	JST	S6B-ZR- SM4A-TF(LF) (SN)	http://www.jst-	n Digi-Key	455-1610- 1-ND	https://www.dig	il CONN HEADER SMD R/A 6POS 1.5MM			4		J7,J8,J9, 1 J10	First solder the pads on the side, then solder the SMT pins.
4	28	16 Position 1.5mm Pitch Cable	Wiring	JST	A06ZR06ZR2 8H305B	http://www.jst-	n Digi-Key	455-3043- ND	https://www.dig	ji JUMPER 06ZR-8M-P - 06ZR-8M-P 12"			3	N/A		On the underside of the board. First solder the pads on the side, then solder the SMT pins.
5	26	1x4 KK 254 Male Header	PTH	Molex	22292041	https://www.me	Digi-Key	WM2746- ND	https://www.dig	CONN HEADER VERT 4POS 2.54MM		SMT equivalent does not exist.	1		4 J11	Solder so that the plastic tab is closer to the out perimeter of the board.
3	27	6-Bit Buffer	SMT	Nexperia	74LVC07AD, 118	https://www.ne	Digi-Key	1727-3089- 1-ND	https://www.dig	IC BUFFER NON-INVERT 5.5V 14SO	74LVC07A D,118	Need to read with INPUT_PULLUP pins. Supply Vcc with the input voltage level (5V), from the connector.	2		3 U2,U3	Confirm correct orientation.
7	12	AMP Mini CT Right-Angle Header, 16 position	SMT	TE Connectivity	1-292228-6	https://www.te	Master Electronics	1-292228-6	https://www.ma	SCONN HEADER SMD R/A 16POS 1.5MM		This version has no boss, but the 1-292227-6 version has a boss for alignment and is available on Digikey. The next version will add holes for the boss so we can use 1-292228-6.	1		7 J12	On the underside of the board. First solder the pads on the side, then solder the SMT pins.

BOM for ODS-MPSv0.1.0 Fusion PCBA

Designator	MPN	Quanti	ty Supplier Link	BON ID	Compone ID		ge	Component Name	Manufacturer	Manufacturer Part #	ShenZhen OPL MPN		Ship to Seeed?	Supplier	Supplier Part #	Supplier Description	Mounting Type	Notes
LED1,LED2	17-21SYGC/S530- E2/TR8		2 https://www.digi	<u>i</u> 8	3	20		Green Indicator LED	Everlight Electronics	17- 21SYGC/S530 -E2/TR8	17- 21SYGC/S 530- E2/TR8	Yes		Digi-Key	1080-1500- 1-ND	LED YELLOW/GREEN CLEAR 0805 SMD	SMT	Confirm correct orientation.
R1,R3	RC1206JR-071KL		2 https://www.digi	į	9	21		1K Resistor	Yageo	RC1206FR- 071KL	RC1206JR -071KL	Yes		Digi-Key	311-1.00 KFRCT-ND	RES SMD 1K OHM 1% 1/4W 1206	SMT	
R2	RC1206JR- 07100RL		1 https://www.digi	<u>i</u> 10)	22		100 Resistor	Yageo	RC1206FR- 07100RL	RC1206JR -07100RL	Yes		Digi-Key	311- 100FRCT- ND	RES SMD 100 OHM 1% 1/4W 1206	SMT	
C1,C2,C3,C4	UCD1E470MCL1G S		4 https://www.digi	. 6	3	18		100uF Electrolytic Capacitor	Nichicon	UCD1E470MC L1GS	UCD1E47 0MCL1GS	Yes		Digi-Key	493-6385- 1-ND	CAP ALUM 47UF 20% 25V SMD	SMT	Confirm correct orientation.
H4, H5, H6, H7, H8, H9, H10, H11	NPPC081KFXC-RC		8 https://www.digi	<u>i</u> 4	1	17		1x8 Female Header	Sullins Connector Solutions	NPPC081KFX C-RC		No	Yes	Digi-Key	S5639-ND	CONN HDR 8POS 0.1 GOLD SMD	SMT	
U1	74HC4052D,653		1 https://www.digi	11	1	23	•	SP4T Mux/Demux	Nexperia	74HC4052D, 653	74HC4052 D,653	Yes		Digi-Key	1727-2808- 1-ND	IC MUX/DEMUX DUAL 4X1 16SOIC	SMT	Confirm correct orientation.
J1,J2,J3,J4	1814650)	4 https://www.digi	12	2	24	T.	1x4 Spring Clamp Terminal Block	Phoenix Contact	1814650		No	Yes	Digi-Key	277-10064- 1-ND	TERM BLOCK 4POS	SMT	First solder the pads on the side, then solder the SMT pins.
U2,U3	74LVC07AD,118		2 https://www.digi	i 16	6	27		6-Bit Buffer	Nexperia	74LVC07AD, 118	74LVC07A D,118	Yes		Digi-Key	1727-3089- 1-ND	IC BUFFER NON-INVERT 5.5V 14SO	SMT	Confirm correct orientation.
J7,J8,J9,J10	S6B-ZR-SM4A-TF (LF)(SN)		4 https://www.digi	i 13	3	25		1x6 1.5mm Pitch Right-Angle Header	JST	S6B-ZR- SM4A-TF(LF) (SN)		No	Yes	Digi-Key	455-1610- 1-ND	CONN HEADER SMD R/A 6POS 1.5MM	SMT	First solder the pads on the side, then solder the SMT pins.

BOM for ODS-MPSv0.1.0 Manual Assembly

BOM	Component Image	Component Name	Manufacturer	Manufacturer Part #	Supplier	Supplier Part #	Supplier Link	Supplier Description	ShenZhen OPL MPN	Mounting Type Quant	ity Designator	Notes
1	15	Motion Plane v0.1.0	Seeed Studio		Octopi Team	ODS-		Motion Plane v0.1.0 for Squid		Fastener	1	
17	12	AMP Mini CT Right-Angle Header, 16 position	TE Connectivity	1-292228-6	Master Electronics			CONN HEADER SMD R/A 16POS 1.5MM		SMT	1 J12	On the underside of the board. First solder the pads on the side, then solder the SMT pins.
7	19	DC Power Jack	CUI Devices	PJ-037AH- SMT-TR	Digi-Key	CP- 037AHPJC T-ND	https://www.digi	CONN PWR JACK 2X5.5MM SOLDER		SMT	1 J5	Solder the SMT pads first, then solder the PTH pins.
15	26	1x4 KK 254 Male Header	Molex	22292041	Digi-Key	WM2746- ND	https://www.digi	CONN HEADER VERT 4POS 2.54MM		PTH	1 J11	Solder so that the plastic tab is closer to the outer perimeter of the board.
2	5	2x20 Female Header, Tall Stacking	Sullins Connector Solutions	PPPC202LFH N-M53 RC	Pololu	2749		Stackable 0.100" Female Header with Extra 0.3" Spacer: 2x20-Pin, Straight		PTH	3 C1,C3,C2	The female side should be on the underside of the board, while the male pins should stick up.
5	9	1X8 Male Header	Pololu	965	Pololu	965		0.100" (2.54 mm) Breakaway Male Header: 1×40-Pin, Straight, Black		PTH	H4, H5, H6, H7, H8, 8 H9, H10, H11	Break of appropriate length of header and insert long ends into the female headers.
3	16	SilentStepStick Stepper Driver Board	Trinamic	TMC2209	Digi-Key	1460-1395- ND	https://www.digi	TMC2209 STEPPER DRIVER BOARD		Daughter Board	Driver 1,Driver 2, 4 Driver 3,Driver 4	Solder the UART/PDN jumper pads on the board first! Then place on the male headers (short ends), confirm correct orientation, and solder.
14	28	16 Position 1.5mm Pitch Cable	JST	A06ZR06ZR2 8H305B	Digi-Key	455-3043- ND	https://www.digi	JUMPER 06ZR-8M-P - 06ZR-8M-P 12"		Wiring	3	On the underside of the board. First solder the pads on the side, then solder the SMT pins.

BOM for ODS-MPSv0.1.0 Columns

Name	Column Number
ID	1
Component ID	2
Image	3
Component Name	4
Mounting Type	5
Manufacturer	6
Manufacturer Part #	7
Manufacturer Link	8
Supplier	9
Supplier Part #	10
Supplier Link	11
Supplier Description	12
ShenZhen OPL MPN	13
Component Notes	14
Quantity	15
EasyEDA BOM ID	16
Designator	17
Notes	18

BOM for ODS-MPSv0.1.0 Database Connections

	Spreadsheet Key	Test	Connect
Components	1zAloSpcvtBr9Tql6Yx1EZMmtNOi7asDnlvC0D3OLPuA	ID	ID