MilesTag uMT (Micro MT) Laser Tag System

Wiring Reference for the **UMT** Bundle Starter Kit

This guide covers basic wiring of the components included in the MilesTag UMT Starter Kit (UMT Bundle). The kit includes the following components (subject to change):

1 each: (UMT-MOD) MilesTag CORE module, assembled and tested mainboard


1 each: (SEN-GUN) Gun Sensor, pre-wired

1 each: (SPEAKER) 8-ohm mylar speaker, pre-wired


2 each: (TSAL6100) LED, infrared, high-power 1 each: (MUZ-LED-Y) LED, super-bright, yellow 1 each: (SW-PB-RED) Momentary button, Red 1 each: (SW-TRIGGER) Microswitch, momentary 1 each: (SW-KEY-SPST) Key-lock power switch 1 each: (BATT-6AA) Battery holder, 6 x AA


1 each: (CAB-UMT-PWR) Power cable


1 each: (CAB-4C) Button cable, single-ended 1 each: (CAB-2C) IR LED Cable, single-ended



UMT Bundle Starter Kit










Gun Sensor (SEN-GUN)


4-40 Mounting Stud






Trigger and Reload Buttons







UMT Complete Wiring.

