# Firmware update instructions for the Tacx smart series trainers (android)


This instruction set will guide you thru the steps needed to update a Tacx Smart trainer.

#### Prerequisite:

- A copy of the new firmware .hex file on the Android device/Cloud
- An Android device with Bluetooth low energy capabilities
- The latest version of Nordic's "nRF Master Control Panel (BLE)" application (this app can be found in the <u>play store</u>)
- A Tacx Smart trainer with the power cord plugged in, or in case of the Bushido powered by cycling during the whole procedure. (slow cycling is sufficient)

### Step 1: Set-up the nRF Master Control Panel(BLE)

- Open the nRF Master Control Panel application
- Select the Menu button on your Android device (this can be a dedicated button on a on screen button)
- A menu will pop-up select the **Settings**→**DFU options**






- Set the "Packet receipt noti.." to ON
- Set the "Number of packets" to 2
- Set the "MBR size" to 4096
- Press 2 times the back button to go back to the main menu. (this can be a dedicated button on a on screen button)

## Step 2: Put the trainer in update mode

- Press the "Scan" button
- One or more devices will show in the list
- If no devices is listed, check if you trainer is powered
- Press "connect" next to the trainer with the matching last 4 serial number digits of the trainer you want to update





- Select the "unknown service" with UUID 669aa501-0c....
- Select the arrow that is pointing up next to UUID 669aac01-0c.....


- Fill out the form starting with entering BB
- Press "Add value" and enter:
  - **50** in case of a Vortex
  - 51 in case of a Bushido
  - 24 in case of a Satori
- Press "OK"
- The bluetooth connection will now be closed by the trainer.
- Press the back button to go back to the main menu. (this can be a dedicated button on a on screen button)




# Step 3: Upload new firmware

Note: The Trainer is now in firmware update mode for 30sec.


- Make sure that the application is not scanning for devices Otherwise press "stop scanning"
- Press the Menu button and select "Refresh"
- Press "scan"






- There should appear a "BTL..." or "DFU..." device in the list of scanned devices. Press "Connect" next to this device
- If there is no "BTL..." or "DFU..." device than repeat step 1.

• Press the **DFU button** in the right corner





- Select "Application" from the option list
- Press "OK" to confirm
- **Select** the **firmware** .hex file with your personal file browser


• Press "No" in the "Init packet" screen



Status: UPLOADING...
NOT BONDED


2,0
1,5
1,0
0,5
0,0
kB/s
SPEED
AVG SPEED
3%

This graph shows the progression of the firmware upload



 When the upload is finished the bluetooth will be disconnected by the application.

**Note:** To **reset** the trainer unplug the power cord and re-plug it after 10 seconds. In case of a Bushido stop cycling for **5 minutes** before proceeding to the next step.



- Press "Scan" to find your device
- Press "connect" to connect
- Open the "Device Information" service
- Press the downward arrow
- The version number will appear
- Check if this is the version of the file you uploaded to the trainer
- If the version is not the version you'd expected retry step 1,2,3
- If the version is the correct one you're successfully updated the trainer