Rolled hem



Thread your overlocker according to your manufacturer's directions for a three-thread rolled edge.

Sew around the bottom hem, thereby you cut a stripe of 2 mm of your fabric.



Repeat with the sleeve and neck hems.

Your shirt is done!