Side seam and sleeve seam



Now the sleeve and side seams of one side are pinned together. When pinning, make sure that the sleeve seams of the front and back meet exactly (orange clips).

Starting from the wrist, the suture is sewed together up to the bottom hem. At the transition from the sleeve seam to the side seam please don't sew 'around the corner'. Instead lay the two seams into one line to sew straight.



Repeat with the second side.