Device Status

Blues Notehub Guide


Step 1: Projects Page



 Sign into the Blues Notehub and go to


https://notehub.io/projects

Projects (14)



Double click on one of the projects to open it


Step 2: Devices Menu



• In the "Devices" menu, tick the checkbox for the device, then click the "View" button near the top right of the page.

• (Alternatively, doubleclick the device row)

Step 3: Device Status



 The device status should now be visible. Scroll down to see graphs of temperature, voltage, signal strength and message counts.

 Signal strength ranges from 0 to 4 bars, with 4 being the highest signal strength