EE 2004

Week 9 Homework

Solution

Note: As defined in lectures, we denote a pin inside a port as RXY, where X is the port ID ranging from A-E, and Y is the pin number ranging from 0-7.

1. A switch is connected to RB0 and an LED to RB7. Write a program to get the status of the switch and send it to the LED.

```
bsf TRISB, 0; set RB0 as input bcf TRISB, 7; set RB7 as output Again: btfss PORTB, 0 bra Over; RB0 is low bsf PORTB, 7; RB0 is high bra Again

Over: bcf PORTB, 7 bra Again end
```

2. Assume that RB3 is an input and represents whether the door is opened. If it goes LOW, it means that the door is opened. Monitor the bit continuously. Whenever it goes LOW, send a HIGH-to-LOW pulse to RC5 to turn on the buzzer.

```
bsf TRISB, 3; make RB3 an input
bcf TRISC, 5; make RC5 an output

HERE: btfsc PORTB, 3; keep monitoring RB3 for low
bra HERE; stay in the loop if high
bsf PORTC, 5; make RC5 H and L.
bcf PORTC, 5
end
```

- 3. Write a program to generate a square wave of 50Hz frequency and output it to RB5. Use 16-bit mode of Timer 0 in all of the following settings. Assume the clock frequency is 4MHz. Ignore time delay generated by instructions required to detect TMR0IF after the flag is raised.
 - a. Use Timer0 with the maximum prescaler.
 - b. Use Timer0 with no prescaler.
 - c. Use Timer0 with a prescaler = 4.

We need a time delay equals to half of the period of the desired wave = 10ms. We toggle the status of RB5 at the end of each delay of 10ms.

a. Maximum prescaler for Timer0 = 256. Time Delay = (65536-x)*Prescaler*Instruction cycles.

Instruction Period = 1us (4MHz clock frequency) and x denotes the initial value loaded to TMR0 hereafter. Solving the equation: Time Delay = (65536-x)*256*1us = 10,000us yields x = 0xFFD9. Here is the program we should write:

```
bcf
            TRISB, 5
                                   ; Set PB5 as output
      bcf PORTB, 5
                                    ; turn off PORTB.5
                             ; 16-bit
Prescaler=256
      movlw B '00000111'
                                    ; 16-bit, int clk,
      movwf TOCON
Here movlw 0xFF
                                   ; TMROH = 0 \times YY
      movwf TMR0H
      movlw 0xD9
                                   ; TMR0L = 0 \times XX
      movwf TMR0L
     bcf INTCON, TMR0IF
                                   ; Clear timer interrupt flag
     bsf TOCON, TMROON
                                   ; start Timer 0
Again btfss INTCON, TMR0IF
     Again
btg PORTB, 5
bcf TOCOW
           TOCON, TMROON
      bra
                                    ; load TMROH and TMROL again
```

- b. Time Delay = (65536-x)*1*1us = 10,000us yields x = 0xD8F0. Use the above program, just change TMR0 and T0CON.
- c. Time Delay = (65536-x)*4*1us = 10,000us yields x = 0xF63C. Use the above program, just change TMR0 and T0CON.
- 4. If we are generating a square wave on RB7, what are the lowest and the highest frequency that we can be generated using Timer0 in 16-bit mode if we load 0000 to TMR0?

```
The maximum time delay = 65536*256*1us = 16.777216s

Period of the square wave = 2*The maximum time delay

Lowest frequency = 1/Period of the square wave = 0.0298 Hz

The minimum time delay = 65536*1us = 65536us

Period of the square wave = 2*The minimum time delay= 0.131072s

Highest frequency = 1/Period of the square wave = 7.63Hz
```

- 5. Find the TMR0H, TMR0L values needed to generate the following time delays. Assume the clock frequency is 4MHz. Ignore time delay generated by instructions required to detect TMR0IF after the flag is raised.
 - a. 2ms. Use 16-bit, no prescaler mode.
 - b. 5ms. Use 16-bit mode and the largest prescaler possible.
 - c. 0.2ms. Use 8-bit, no prescaler mode. TMR0H is not used. Only specify TMR0L.
 - a. Time Delay = (65536-x)*1*1us = 2000us. x = 0xF830. TMR0H = F8; TMR0L = 30.
 - b. Time Delay = (65536-x)*256*1us = 5000us. x = 0xFFEC. TMR0H = FF; TMR0L = FC.
 - c. Time Delay = (256-x)*1*1us = 200us. x= 0x38.