EE3220 System-on-Chip Design

Tutorial Note 5

ARM Instruction Set



I. Instruction

In this tutorial, we will learn to read official instruction set and get familiar with the basic functions of ARM target. From the instruction, learn the whole usage and functions and apply these to your applications. The objectives are shown as following:


- Learn Instruction Set Architecture (ISA)
- Learn basic instructions of ARM from official
- Learn the usage of official instruction
- Learn the instructions examples in assembly code
- From this tutorial, learn to get familiar with a new target

I. Instruction

- In computer science, an instruction set architecture (ISA), also called computer architecture, is an abstract model of a computer. A device that executes instructions described by that ISA, such as a central processing unit (CPU), or ARM, or other device is called an implementation.
- In general, an ISA defines the supported instructions, data types, registers, the hardware support for managing main memory, fundamental features (such as the memory consistency, addressing modes, virtual memory), and the input/output model of a family of implementations of the ISA.
- An ISA can be extended by adding instructions or other capabilities, or adding support for larger addresses and data values; an implementation of the extended ISA will still be able to execute machine code for versions of the ISA without those extensions. Machine code using those extensions will only run on implementations that support those extensions.

Cortex-M3 Pipeline

- Cortex-M3 has 3-stage fetch-decode-execute pipeline
 - Similar to ARM7
 - Cortex-M3 does more in each stage to increase overall performance



1. Instruction

- The original (and subsequent) Arm implementation was hardwired without microcode, like the much simpler 8-bit 6502 processor used in prior Acorn microcomputers.
- A reduced instruction set computer, or RISC, is a computer with a small, highly optimized set of instructions, rather than the more specialized set often found in other types of architecture, such as in a complex instruction set computer (CISC)
- For example, the 32-bit Arm architecture includes RISC features.

I. Instruction

Features:

- Load/store architecture.
- No support for unaligned memory accesses in the original version of the architecture. Armv6 and later, except some microcontroller versions, support unaligned accesses for half-word and single-word load/store instructions with some limitations, such as no guaranteed atomicity.
- Uniform 16 \times 32-bit register file (including the program counter, stack pointer and the link register).
- Fixed instruction width of 32 bits to ease decoding and pipelining, at the cost of decreased code density. Later, the Thumb instruction set added 16-bit instructions and increased code density.
- Mostly single clock-cycle execution.
- The content we discuss is applied on assembly level



2.ARM Programmer Model

- The state of an ARM system is determined by the content of visible registers and memory.
- A user-mode program can see I5
 32-bit general purpose registers (R0-R14), program counter (PC) and CPSR.
- Instruction set defines the operations that can change the state.

R0	R1	R2	R3
R4	R5	R6	R7
R8	R9	R10	R11
R12	R13	R14	PC

2.ARM Programmer Model


 Among these 16 registers, R13 and R14 have special functions.

R0	R1	R2	R3
R4	R5	R6	R7
R8	R9	R10	R11
R12	R13	R14	PC

- R13 is stack pointer (SP) as a pointer to active stack. A stack pointer is a small register that stores the address of the last program request in a stack. A stack is a specialized buffer which stores data from the top down. As new requests come in, they "push down" the older ones.
- R14 is link register used to store the return address from a subroutine. At other times, LR can be used for other purposes.

2.ARM Programmer Model


- Memory is a linear array from 0 to (2^32-1)
- The content with the format of word, half-word and byte can be saved in the address.
- The structure is shown on the right.



3.ARM Instruction Set

General Rules:

- All operands are 32-bit, coming from registers or literals.
- The result, if any, is 32-bit and placed in a register (with the exception for long multiply which produces a 64-bit result) –
- 3-address format



1		2 8						2									3					1	8	7	6	5	4	3	2 1 0	
	Cond	i	0	0	ı	(Ор	coc	de	S		R	n			F	Rd						(Op	er	and	d 2			Data Processing / PSR Transfer
	Cond		0	0	0	0	0	0	Α	S		R	d			F	₹n				Rs		Т	1	0	0	1		Rm	Multiply
	Cond		0	0	0	0	1	U	Α	S		Rd	Hi			R	dLo)		-	Rn		T	1	0	0	1		Rm	Multiply Long
	Cond	1	0	0	0	1	0	В	0	0		R	n			F	₹d		0	0	0	(0	1	0	0	1		Rm	Single Data Swap
	Cond	1	0	0	0	1	0	0	1	0	1	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	1		Rn	Branch and Exchange
	Cond	i	0	0	0	Р	U	0	W	L		R	n			F	Rd	_	0	0	0	(0	1	S	Н	1		Rm	Halfword Data Transfe register offset
	Cond	1	0	0	0	Р	U	1	W	L		R	n			F	Rd			(Offs	se	t	1	S	Н	1	C	Offset	Halfword Data Transfe immediate offset
	Cond	1	0	1	ı	Р	U	В	W	L		R	n			F	₹d							(Off	se	t	_		Single Data Transfer
	Cond	1	0	1	1																						1			Undefined
	Cond		1	0	0	Р	U	S	W	L		R	n								Re	gi	ste	er	Lis	t	_			Block Data Transfer
	Cond	1	1	0	1	L	T		_		•							Off	set	t										Branch
	Cond	1	1	1	0	Р	U	N	W	L		R	n			С	Rd			С	P#	ŧ					Off	set		Coprocessor Data Transfer
	Cond	1	1	1	1	0		СР	O	ос		CF	₹n			С	Rd			С	P#	ŧ			CP)	0	(CRm	Coprocessor Data Operation
	Cond	I	1	1	1	0	С	Р(Оро	L		CF	₹n			F	Rd			С	P#	ŧ			CP)	1	(CRm	Coprocessor Register Transfer
	Cond		1	1	1	1	T			_					lgı	no	red	by	pr	00	ces	sc	or				_			Software Interrupt
3	3 2	2	2	2	2	2	2	2	2	2	1	1	1	1	1	1	1	1	1	1	9		R	7	6	5	4	3	2 1 0	_

3.ARM Instruction Set

The instruction mainly contains move, arithmetic, logical, comparison and multiply instructions. All operations are shown as following:

Operation		Operation	
Mnemonic	Meaning	Mnemonic	Meaning
ADC	Add with Carry	MVN	Logical NOT
ADD	Add	ORR	Logical OR
AND	Logical AND	RSB	Reverse Subtract
BAL	Unconditional Branch	RSC	Reverse Subtract with Carry
$B\langle cc \rangle$	Branch on Condition	SBC	Subtract with Carry
BIC	Bit Clear	SMLAL	Mult Accum Signed Long
BLAL	Unconditional Branch and Link	SMULL	Multiply Signed Long
$\mathtt{BL}\langle cc angle$	Conditional Branch and Link	STM	Store Multiple
CMP	Compare	STR	Store Register (Word)
EOR	Exclusive OR	STRB	Store Register (Byte)
LDM	Load Multiple	SUB	Subtract
LDR	Load Register (Word)	SWI	Software Interrupt
LDRB	Load Register (Byte)	SWP	Swap Word Value
MLA	Multiply Accumulate	SWPB	Swap Byte Value
VOM	Move	TEQ	Test Equivalence
MRS	Load SPSR or CPSR	TST	Test
MSR	Store to SPSR or CPSR	UMLAL	Mult Accum Unsigned Long
MUL	Multiply	UMULL	Multiply Unsigned Long

4.0 Syntax

For general assembly instructions, the syntax is <instruction> {<cond>} {S} Rd, N General conditions are shown as following:

Mnemonic	Condition	Mnemonic	Condition
CS	Carry S et	CC	Carry Clear
EQ	Equal (Zero Set)	NE	Not E qual (Zero Clear)
VS	Overflow Set	VC	Overflow C lear
GT	Greater T han	LT	Less Than
GE	Greater Than or E qual	LE	Less Than or Equal
PL	Plus (Positive)	ΜI	Minus (Negative)
HI	Higher Than	LO	Lower Than (aka CC)
HS	Higher or S ame (aka CS)	LS	Lower or S ame

4.1 Register Movement

```
<instruction> {<cond>} {S} Rd, N
```

• MOV: Move a 32-bit value into a register

- Rd = N
- MVN: Move the NOT of the 32-bit value into a register $Rd = \sim N$

For example:

```
MOV R0, R2

PRE R0 = 5, R2 = 8

POST R0 = 5, R2 = 5
```

4.2 Operand Instructions

- During the instructions, operand is important in processing. Operand to ALU is routed through the Barrel shifter, it can be modified before it is used.
- Some of the operands are shown as following:

Mnemonic	Description	Shift	Result
LSL	logical shift left	xLSL y	$x \ll y$
LSR	logical shift right	xLSR y	$(unsigned)x \gg y$
ASR	arithmetic right shift	xASR y	$(signed)x \gg y$
ROR	rotate right	xROR y	$((\text{unsigned})x \gg y) \mid (x \ll (32 - y))$
RRX	rotate right extended	<i>x</i> RRX	$(c \text{ flag} \ll 31) \mid ((\text{unsigned})x \gg 1)$

4.2 Operand Instructions


For logical shift right

MOV R0, R2, LSR #2 During this process, R0 = R2 >>2 and R2 is unchanged

For example: the value is 0...0 0011 0000

Before $R2 = 0 \times 00000030$

After $R0 = 0 \times 0000000$ C, $R2 = 0 \times 00000030$





4.3 Arithmetic Instructions

Syntax: <Instruction> {<cond>} {S} Rd, Rn, N

ADC	Add two 32-bit values and carry	Rd = Rn + N + carry
ADD	Add two 32-bit values	Rd = Rn + N
RSB	Reverse subtract of two 32-bit values	Rd = N - Rn
RSC	Reverse subtract with carry of two 32-bit values	Rd = N - Rn - !(carry flag)
SBC	Subtract with carry of two 32-bit values	Rd = Rn - N - !(carry flag)
SUB	Subtract two 32-bit values	Rd = Rn - N

4.4 Logical Instructions

Syntax: <instruction> {<cond>} {S} Rd, Rn, N

AND	Logical bitwise AND of two 32-bit values	Rd = Rn & N
ORR	Logical bitwise OR of two 32-bit values	Rd = Rn N
EOR	Logical exclusive OR of two 32-bit values	Rd = Rn ^ N
BIC	Logical bit clear (AND NOT)	Rd = Rn & ~N



4.5 Comparison Instructions

• These instructions do not generate a result but set condition code bits (N Z C V) in CPSR. Often, a branch operation follows to change the program flow.

Syntax: <instruction> {<cond>} Rn, N

CMN	Compare negated	Flags set as a results of Rn + N
CMP	compare	Flags set as a results of Rn - N
TEQ	Test for equality of two 32-bit values	Flags set as a results of Rn ^ N
TST	Test bits of a 32-bit value	Flags set as a results of Rn & N

4.6 Multiplication Instructions


Syntax: MLA {<cond>} {S} Rd, Rm, Rs, Rn
MUL {<cond>} {S} Rd, Rm, Rs

MLA	Multiply and accumulate	Rd = (Rm * Rs) + Rn
MUL	Multiply	Rd = Rm * Rs

Syntax: <instruction> {<cond>} {S} Rdlo, RdHi, Rm, Rs

SMLAL	Signed multiply and accumulate long	[RdHi, RdLo] = [RdHi, RdLo] + (Rm * Rs)
SMULL	Signed multiply long	[RdHi, RdLo] = (Rm * Rs)
UMLAL	Unsigned multiply accumulate long	[RdHi, RdLo] = [RdHi, RdLo] + (Rm * Rs)
UMULL	Unsigned multiply long	[RdHi, RdLo] = (Rm * Rs)

4.6 Multiplication Instructions



5. Conclusions

- Besides these instructions, there are many kind of instructions when you get touch to a new device with different architecture. For most important issues, please search the instructions from official website.
- For RISC device, assembly code can help comprehend the process on computer
- Follow the syntax when you process your application or calculations.
- To realize further applications, embedded instruction sets such as Thumb instructions suffer from extremely high register pressure because they have small register sets

6. Reference

- Keli official <u>https://www.keil.com/support/man/docs/armasm/armasm_dom1361289850</u> <u>039.htm</u>
- ARM Instruction set https://iitd-plos.github.io/col718/ref/arm-instructionset.pdf
- LR and SP https://developer.arm.com/documentation/dui0801/d/Writing-A32-T32-Assembly-Language/Register-usage-in-subroutine-calls
- https://www.csie.ntu.edu.tw/~cyy/courses/assembly/10fall/lectures/handouts/lec09_ARMisa.pdf
- ARM official data processing instructions
- https://developer.arm.com/documentation/dui0068/b/arm-instruction-reference/arm-general-data-processing-instructions?lang=en