June 1st, 1928

COUNTERBALANCE DATA

Date of Revision

For rules governing counterbalance see page 217.

Classes	Weights to be hung on pins when counterbalancing wheels						Remarks
	1st Wheel	2nd Wheel	3rd Wheel	4th Wheel	5th Wheel	Eccentric crank pin	
507- 542	1291	745				63	Simpled
564	470	989	479			51	
566- 591	411	472	614	411			8-wheel switch
591	502	614	557				6-wheel switch
640, 649	300	480	780	300			Strap or floating bushing main rod
664, 709	300	480	780	300			Strap or floating bushing main rod
729,759,769	275	465	1020	275			Strap type main rod
729,759,769	275	405	1051	275			Floating bushing main rod
789							
824							
825	325	506	970	325			Strap or floating bushing main rod
870							
885	385	600	1520	385		75	Strap main rod
885	385	600	1475	385		75	Floating bushing main rod
900	369	537	1532	497	375	67	Original piston strap main rod
900	391	602	1488	635	396	54	Original piston F.B. main rod
900	344	555	1441	589	348	54	Muchnic piston F.B. main rod
990							
1000	573	1456	565			74	
1014-1050	520	1445	520			75	Strap main rod
1014-1050	520	1430	520			75	Floating bushing main rod
1200	520	1560	520			75	Strap main rod
1200	520	1520	520			75	Floating bushing main rod
1226	497	1523	494			76	Strap main rod
1226	497	1477	494			76	Floating bushing main rod
1270	485	1430	485			60	Strap main rod
1270	485	1386	485			60	Floating bushing main rod
1290	480	1490	480			50	Strap main rod
1290	480	1446	480			50	Floating bushing main rod
1297	510	1525	500			60	Strap main rod
1297	510	1460	510			60	Floating bushing main rod
1309-1337	569	1456	565			102	Floating bushing main rod
1398	598	1658	581			52	
1400	1291	745				63	Simpled
1400,1452	1291	745				63	Simpled
1479,1550	1291	745				63	Simpled
1480	640	1263				00	Simpled
1600	369	537	1532	497	375	67	Original piston strap main rod
1600	391	602	1488	635	395	54	Original piston F.B. main rod
1600	344	555	1441	589	348	54	Muchnic piston F.B. main rod
1674	450	530	800	605	445	70	Muchnic pistons F.B. main rod
1798	394	760	1543	419		70	
1800	506	1727	573			57	Simpled
1900	392	584	1330	386		67	With inside balance and strap main rod
1900	392	584	1310	386		67	Floating bushing main rod
1950	371	538	1322	365		63	Floating bushing main rod
2000,2039	360	540	700				Strap or floating bushing main rod
2100,2110,2122	360	540	700				Strap or floating bushing main rod
2147	340	520	295				
2404	250	350	385	250			

Revised and rewritten October 26, 1940.