7. METHOD OF APPLYING SUPERHEATER FLUES:

Superheater flues are to be applied as shown on Drawing 3H-15173 using tools as shown on the following drawings —

Sectional Prossers 3H-10370

Style A for Copper Ferrules
" S " Setting Flues
" B " Prossering Flues

Beading Tool 3H-15245

Any approved manufacturer's roller expander may be used, five-roller type preferable.

Front ends of superheater flues must be expanded hot before application, to fit snugly into holes in front tube sheet, and must be annealed after expanding

8. SAFE ENDING TUBES AND FLUES:

Tubes and flues will be safe ended in accordance with the practice outlined on Drawing 2H-10791.
Safe ending will be either by butt electric weld or lap roller or hammer weld, butt electric weld preferred.
Safe ends must be of the same thickness (B W G) as new tubes or flues.

9. SWAGING TUBES AND FLUES:

Tube shops will carry specimen safe ends or gauges in sizes varying by one-thirty-second inch and numbered in sizes 1 to 7 for each size of tube or flue as under —

	No. 1	No. 2	No. 3	No. 4	No. 5	No. 6	No. 7
2" Tubes	1 23/32	1 3/4	1 25/32	1 13/16	1 27/32	1 7/8	1 29/32
2¼" Tubes	1 31/32	2	2 1/32	2 1/16	2 3/32	2 1/8	2 5/32
3½" Tubes	2 29/32	2 15/16	2 31/32	3	3 1/32	3 1/16	3 3/32
5 3/8" or 5 1/2" Superheater Flues	4 13/32	4 7/16	4 15/32	4 1/2	4 17/32	4 9/16	4 19/32

The Foreman or individual responsible for ordering the tubes in tube shop will gauge the size of tube holes after copper ferrules are applied and order the swaging according to the number stamped on the gauge

The style and length of swage must be in accordance with diagram No 3, Drawing 3H-15174 for 2" or 2¼" tubes, Drawing 3H 10725 for 3½ tubes and to Drawing 3H 15173 for superheater flues