

# Realtek mDNS User Guide

This document provides guideline to use mDNS module in SDK.

## **Table of Contents**

1	Introdu	uction	. 3
2	D t T!	pes	. 3
	2.1	DNSService"e#	. 3
	2.2	T\$T"ecord"e#	. 3
3	mDNS	%&I	. 3
	3.1	mDNS"esponderInit	. 3
	3.2	mDNS"esponderDeinit	. •
	3.3	mDNS"egisterService	. •
	3.'	mDNSDeregisterService	. 5
	3.5	mDNS(pd teService	. 5
•	Te)t "ecord %&I		. *
	'.1 ·	T\$T"ecord+re te	
	<b>'</b> .2	T\$T"ecordSet, lue	
	<b>'</b> .3	T\$T"ecordDe lloc te	
5	· ·		
	5.1	mDNS&I t#orm+ustomInit	
	5.2	mDNS&I t#ormOostn me	. 9
*	mDNS	1) mple	. 9
_	mDNS:	2i3r r! 2in4ina	10



2015-09-01 3

**Parameters** 

None.

Return Value

I# the #unction succeeds5 the return v lue is 0.

**Remarks** 

None.

## 3.2 mDNSResponderDeinit

This #unction triggers to stop mDNS responder.

### **Syntax**

```
void mDNS"esponderDeinit?
void

«

**Boundary Total Control of the Control of the
```

### **Parameters**

None.

Return Value

None.

### Remarks

Ahen mDNS responder is deinit iliBed5 II registered service 6ill Iso 3e deregistered.

## 3.3 mDNSRegisterService

This #unction triggers to register service to mDNS.

### **Syntax**

```
DNSService"e# mDNS"egisterService?

ch r 7n me5

ch r 7service9t!pe5

ch r 7dom in5

unsigned short port5

T$T"ecord"e# 7t)t"ecord
```

#### **Parameters**

name

Service n me to register.



service\_type

Service t!pe to register.

domain

Service dom in to register.

port

Service port in#orm tion #or the service to register.

txtRecord

Te)t record in#orm tion #or the service to register.

### Return Value

"eturn pointer to the registered service resource i# success5 other6ise return null.

### **Remarks**

None.

## 3.4 mDNSDeregisterService

This #unction triggers to unregister service #rom mDNS.

### **Syntax**

void mDNSDeregisterService?

DNSService"e# service"e#

### **Parameters**

serviceRef

&ointer to the registered service resource.

Return Value

None.

**Remarks** 

None.

## 3.5 mDNSUpdateService

This #unction triggers to upd te the te)t record in service resource.

2015-09-01 5



### **Syntax**

```
void mDNS (pd teService?

DNSService"e# service"e#5

T$T"ecord"e# 7t)t"ecord5

unsigned int ttl
```

### **Parameters**

serviceRef

&ointer to service resource.

txtRecord

Ne6 te)t record to upd te.

ttl

Time-to-live o# this te)t record. Set 0 to use de# ult TT2 setting.

### Return Value

None.

### **Remarks**

None.

## **4 Text Record API**

mDNS services m ! o6n its te)t record. This su3-section lists the provided te)t record %&I.

## 4.1 TXTRecordCreate

This #unction triggers to cre te te)t record.

### **Syntax**

```
void T$T"ecord+re te?
T$T"ecord"e# 7t)t"ecord5
uint1*9t 3u##er2en5
void 73u##er
```

### **Parameters**

txtRecord

&ointer to te)t record resource.

2015-09-01 \*



bufferLen

De# ult 3u##er length.

buffer

De# ult 3u##er ssigned to s ve te)t record d t .

Return Value

None.

Remarks

De# ult 3u##er is not necess r!.

### 4.2 TXTRecordSetValue

This #unction triggers to dd 4e!-v lue p ir to te)t record.

### **Syntax**

```
int T$T"ecordSet, lue?
T$T"ecord"e# 7t)t"ecord5
const ch r 74e!5
uint. 9t v lueSiBe5
const void 7v lue
```

### **Parameters**

txtRecord

&ointer to te)t record resource.

key

+h r cter string o# the 4e! #or p ir

valueSize

SiBe o# 3in r! d t v lue.

value

Cin r! d t v lue #or p ir.

### Return Value

None.

### **Remarks**

Ahen 3u#er in te)t record resource to s ve te)t record d t is not enough5 it 6ill 3e lloc ted d!n mic II!.

2015-09-01 -



\_\_\_\_\_

### 4.3 TXTRecordDeallocate

This #unction triggers to rele se te)t record resource.

### **Syntax**

```
void T$T"ecordDe Iloc te?
T$T"ecord"e# 7t)t"ecord
```

### **Parameters**

txtRecord

&ointer to te)t record resource.

Return Value

None.

Remarks

None.

# 5 Platform Mandatory Implementation

This su3-section lists the m nd tor! #unctions th t developers need to implement. %n e) mple is provided in mDNS&I t#orm.c. The mDNS&I t#ormOtons nd mDNS&I t#ormInet%ddr #unctions re used #or 2AI& 6r pping on htons nd inet9 ddr #unctions 3et6een di##erent versions.

## 5.1 mDNSPlatformCustomInit

This m nd tor! #unction is invo4ed #or custom initi liB tion 6hen mDNS initi liB tion

### **Syntax**

```
void mDNS&I t#orm+ustomInit?
void

&
```

### **Parameters**

None.

Return Value

None.



**Remarks** 

None.

### 5.2 mDNSPlatformHostname

This m nd tor! #unction is invo4ed to get hostn me 6hen mDNS initi liB tion

### **Syntax**

```
ch r 7mDNS&I t#ormOostn me?
void

8
```

#### **Parameters**

None.

### Return Value

Device hostn me in net6or4.

#### **Remarks**

This hostn me 6ill 3e used in mDNS service host in#orm tion.

# 6 mDNS Example

%n e) mple to use the %&ls e)pl ined in previous sections is provided in e) mple9mdns.c. To e)ecute this e) mple utom tic II! 6hen 3ooting5 the +DNEIF91\$%/&219/DNS in pl t#orm9opts.h must 3e en 3led s the #ollo6s. 2Al& IF/& should lso 3e en 3led to support multic st.

```
G7 I6ipopts.h 7G
Hde#ine 2Al&9IF/& 1

G7 pl t#orm9opts.h 7.
Hde#ine +DNEIF91$%/&219/DNS 1
```

In e) mple5 oper tions on mDNS responder nd service re presented. I# device Ai-Ei connection is setup 3! # st reconnect ?&le se re#er to re dme o# # st reconnect e) mple6 the mDNS responder could 3e st rted #ter l& ddress is v il 3le. %n e) mple service is registered5 upd ted. Ein II!5 the mDNS responder is stopped.



```
IP address: 192.168.13.11

Got IP after 3520ms.

WIFI initialized
init_thread(46), Available heap 0x76a0
mDNS Init
mDNS Register service
wait for 30s ...
mDNS Update service
wait for 30s ...
mDNS Definit
```

To discover service in net6or45 the Idns-sdJ comm nd provided in ConKour SDK c n 3e used. ConKour SDK is v il 3le on %pple developer support site5 nd c n 3e do6nlo ded 3! %pple developer. In the #ollo6ing5 Idns-sd -CJ comm nd is used to 3ro6se #or service inst nce o# t!pe I9service1J5 nd service o# I me3 .9service1.9tcp.loc I.J is #ound. Idns-sd -2J comm nd is used to loo4 up this service inst nce5 nd the content o# service te)t record is sho6n. %#ter service upd te oper tion5 the origin I content o# Ite)t1Lte)t19cotent5 te)t2Lte)t29contentJ is upd ted to Ite)t1Lte)t19content9ne6J.

```
C:\Windows\System32)dns-sd -B _service1
Browsing for _service1._tcp
Timestamp
             A/R Flags if Domain
                                                     Service Type
                     3 10 local.
                                                     _service1._tcp.
15:24:18.331 Add
                                                                              ameba
15:24:18.331 Add
                     2 49 local.
                                                     _service1._tcp.
                                                                               ame ba
C:\Windows\System32}dns-sd -L ameba _service1 local
Lookup ameba._service1._tcp.local
15:24:21.750 ameba._service1._tcp.local. can be reached at lwip0.local.:5000 (interf
text1=text1_content text2=text2_content
15:24:21.754 ameba._service1._tcp.local. can be reached at lwip0.local.:5000 (interf
text1=text1_content text2=text2_content
l5:24:50.071 ameba._service1._tcp.local. can be reached at lwip0.local.:5000 (interf
text1=text1_content_new
5:24:50.075 ameba._service1._tcp.local. can be reached at lwip0.local.:5000 (interf
text1=text1_content_new
```

## 7 mDNS Library Linking

The te)t nd d t o# mDNS li3r r! in %me3 SDK is 3uilt in .mdns.te)t nd .mdns.d t sections. The lin4ing o# this li3r r! c n 3e ch nged #or re>uirement 3! modi#!ing the im ge2.ic# #ile. %s the #ollo6ing e) mple #or im ge2.ic#5 dding .mdns.te)t section to .r m9im ge2.te)t 3loc4 nd .mdns.d t section to .r m.d t is #or lin4ing to S''%/. %dding .mdns.te)t nd .mdns.d t



sections to SD"%/ 3loc4 is #or lin4ing to SD"%/. The de# ult setting in im ge2.ic# o# %me3 SDK #or mDNS li3 r r! is lin4ing to SD"%/.

```
G7 2in4 mDNS to S"% / 7G
de#ine 3loc4 .ram_image2.text 6ith #i)ed order: section .in#r .r m.st rt75
                          section .rod t 75
                          3loc4 +&&9INIT5
                          section .mon.r m.te) t75
                          section .h I.#I sh.te)t75
                          section .h l.gpio.te)t75
                          section .te) t75
                          section +DD15
                          section .otg.rom.te)t5
                          section, eneer o3Kect st rtup.o5
                          section 99D2IC9&1"TO"1%D5
                          section .mdns.text
de#ine 3loc4 .ram.data 6ith #i)ed order: section .d t 75
                      section D%T%5
                      section .r m.otg.d t . 5
                      section .i r.init9t 3le5
                      section .mdns.data
                     =8
```

```
G7 2in4 mDNS to SD"%/ 7G

de#ine 3loc4 SDRAM 6ith #i)ed order: section .sdr m.te)t75

section .sdr m.d t 75

section .mdns.text*,

section .mdns.data*
=8
```

2015-09-01 11