
Détermination de l'équation de luminosité intérieure en fonction de la position du volet et de la puissance de la lampe

	Détermination de l
Niveau lampe	Luminosité intérieure
1	0
2	0
3 4	0
5	1
6	1
7 8	3
9	4
10	5
11 12	6 7
13	8
14 15	9 11
16	12
17	14
18 19	16 18
20	20
21	22
22	24 26
24	28
25	31
26 27	33 36
28	39
29	42
30 31	45 48
32	51
33	54
34 35	57 61
36	64
37	68
38 39	72 76
40	80
41	84
42	88 92
44	96
45	101
46 47	105 110
48	115
49	120
50 51	125 130
52	135
53 54	140 145
55	151
56	156
57 58	162 168
59	174
60	180
61 62	186 192
63	198
64	204
65 66	211 217
67	224
68	231
69 70	238 245
71	252
72 73	259 266
74	273
75	281
76 77	288 296
78	304
79	312
80 81	320 328
82	336
83	344
84 85	352 361
86	369
87	378
88 89	387 396
90	405
91	414
92 93	423 432
	441
94	771
94 95	451
94 95 96	451 460
94 95	451



		Consigne	400
		LumExt	400
		C	0
olet ouvei0,05x²-0,0053x+LumEXT		Α	0,0501
it	0,05x ² -0,0053x+(lumEXT/2)	В	0,0132
		delta	0,000174
ermé	0,05x ² -0,0053x	x1	-0,26347
		x2	0