

16. Remove filter A, the spring seat, valve springs, valve holder and poppet valve from the push rod.



