Rear Steering Gearbox

Illustrated Index -

CAUTION:

- 1. Do not apply torque of more than 0.1 kg-m (0.72 lb-ft) to the offset shaft.
- 2. Do not strike the stroke rod.
- 3. Never loosen the offset shaft screw and lock nut screw.
- 4. Do not remove the gearbox cover.
- 5. Use the special tool "Rear Steering Gearbox Center Lock Pin" when removing the rear steering gearbox, and leave it intact except when the gearbox is inspected for function, etc.
- 6. Also use the special tool "Rear Steering Gearbox Center Lock Pin" when removing the front or rear of the center shaft.

