Timing Belt

illustrated index

NOTE:

- Refer to next page for positioning crank and pulley before installing belt.
- Refer to page 5-6, for alternator belt adjustment.
- Refer to page 5-7, for P/S pump belt adjustment.
- Refer to page 5-7, for A/C compressor belt adjustment.
- Mark direction of rotation before removing.

