## **Emission Control System**

## System Troubleshooting Guide -

NOTE: Across each row in the chart, the systems that could be sources of a symptom are ranked in the order they should be inspected starting with ①. Find the symptom in the left column, read across to the most likely source, then refer to the page listed at the top of that column. If inspection shows the system is OK, try the next most likely system ②, etc.

SUB SYSTEM PAGE		CATALYTIC CONVERTER	EGR SYSTEM	POSITIVE CRANKCASE VENTILATION SYSTEM	EVAPORATIVE EMISSION CONTROLS
ROUGH IDLE			1	2	
FREQUENT STALLING	AFTER WARMING UP		1		
POOR PER- FORMANCE	FAILS EMISSION TEST	1			2
	LOSS OF POWER	1)			