Troubleshooting

Symptom Chart —

SYMPTOM		REMEDY
No hot air flow	Blower motor does not run	Perform the flowchart (page 15-7)
	Blower motor runs	Check followings: Clogged heater duct Clogged blower outlet Clogged heater valve Faulty air mix door Out of air mix cable adjustment Faulty thermostat (section 4).
Hot air flow is low	Blower speed does not change	Perform flow chart (page 15-9)
	Blower runs properly	Check followings: Clogged heater duct Clogged blower outlet Incorrect door position
Function does not change	Function control motor does not run	Perform flow chart (page 15-12)
	Function control motor runs	Check for the heater door linkage and cable adjustments.
Recirculation door does not change	Recirculation motor does not run	Perform flow chart (page 15-10)
	Recirculation motor run	Check for the door linkage or per- form flow chart (page 15-10)