Wiring Diagrams

Index -

Air Conditioner Sy	stem	14
ALB System	***************************************	7
A/T Control System	n	13
Battery		1
Carburetor Soleno	ids (Except KS, KX, KZ)	12
Charging System	***************************************	1
Cigarette Lighter .		9
Clock		9
Cooling System	***************************************	<u>د</u>
Cruise Control Sys	tem	71
Dashlight Brightness Control Unit Fuel Pump Carbureted Engine		
Fuei Pump Carbure	eted Engine	13
Fuel Inj	ected Engine	12
Gauges		2
Headlight Washer	System	11
Heater Control Sys	stem	14
Ignition Switch		1
		1
Indicator Lights		
Air Conditioner		12
Cruise Control	Main Switch	11
Hazard Light (E	xcept KQ, KT, KY)	8
Rear Defogger		9
Rear Fog Light	KE	4
	KS, KW, KQ, KT, KY	
4	KB, KF, KG, KX	6
S4 Switch		13
Seat Heater		11
Integrated Contro	Unit	3
Lighting System	KB, KF, KG, KX	6
	KE	
	KS, KW, KQ, KT, KY	5
Lights		
Brake Light		8
Dome Light		. 2
Door Key Light	***************************************	. 3
		. 8
Fog Lights	KE	
	KB, KF, KG, KX	
	KS, KW, KQ, KT, KY	. /
Gauge Light		. 2
	nt	. ຮ
Headlight	KB, KF, KG, KX	
	KE	. 4 -
	KS, KW, KQ, KT, KY	. 5
Ignition Key Light		
Safety Indicator Light		
Trank Light		. 2
Turnsignal Ligi	ht	. ช

GM-CARB Control System	
GM-FI Control System	12
ower Door Lock System	10
ower Door Mirror System	9
ower Window System	10
Rear Window Defogger System	9
Rear Window Wiper/Washer System	10
Safety Indicator	2
Seat Heater System	11
Shift Lever Position Indicator	3
Starting System	1
Stereo Sound System	8
Sunroof System	9
Varning Lights	
ALB Warning	7
Brake Warning	2
Charge Warning	1
Compressor Warning	14
Low Fuel Warning	2
Oil Pressure Warning	3
PGM-FI Warning	12
Seat Belt Reminder	4
Windshield Winer/Washer System	10