


Input Tests -

NOTE:

- · Make sure all connectors are clean and tight.
- · Make all tests from the wire side of the connector with a digital multi-tester.
- Any abnormality found during these tests must be corrected before continuing.

RED (on carbureted car, blank on PGM-FI car)



View from wire side.

Perform the following tests with the A/C control unit's 12P connector disconnected, and the ignition switch, blower switch, and A/C switch ON.

| WIRE POSITION | CIRCUIT | TEST CONDITION | DESIRED RESULTS | CORRECTIVE ACTION IF DESIRED RESULTS AREN'T OBTAINED |
|---------------------------------------|--|--|---|---|
| BLK (7) | Ground | Check for continuity to body ground. | Should have continuity. | Repair open to body ground. |
| YEL/BLK (12) | Power | Check for battery voltage. | Should have battery voltage. | Check #18 fuse; if OK, repair open in YEL/BLK wire. |
| RED/YEL (11) and YEL (10) | Compressor relay A Compressor relay B | Connect both the RED/YEL (11) and YEL (10) wires to the YEL/BLK (12) wire with jumper wires. | The A/C compressor clutch should click. | Check for an open or short in the RED/YEL or YEL wires. |
| BLU (6) | Engine speed | Check for battery voltage. | Should have battery voltage. | Check for an open or short in the BLU wire or a faulty coil. |
| GRN (2) and WHT (1) | Compressor sensor | Check resistance between the GRN and WHT wires (use 20 K scale). | Should be approximately 0.45 to 0.60 ohms on the 20 K scale (450–600 ohms). | Check for open in GRN or WHT wires between the A/C control unit and the compressor pick-up sensor or a faulty pick-up sensor. |
| BRN (8) | Compressor clutch | Check resistance to body ground. | Should be approximately 4 ohms. | Check for an open in the BRN wire between the A/C control unit and the compressor clutch coil or a faulty compressor clutch. |

Perform the following tests with A/C control unit connected, engine running and the A/C system turned ON.

| RED/YEL (11) | Compressor relay A | Check for battery voltage. | Should have battery voltage. | Check the connection to the A/C control unit; if OK, substitute a known-good control unit and retest. |
|-----------------|--------------------|----------------------------|------------------------------|---|
| YEL (10) | Compressor relay B | Check for battery voltage | Should have battery voltage. | Check the connection to the A/C control unit; if OK, substitute a known-good control unit and retest. |
| BRN (8) | Thermal protector | Check for system voltage. | Should have system voltage. | Test thermal protector. |