
Brake Pad



Inspection/Replacement

WARNING Do not use an air hose to blow the brake assembly clean. Use an OSHA-approved vacuum cleaner, to avoid breathing brake dust.

- 1. Remove the front wheels and support the front of car on safety stands.
- 2. Remove caliper bolt, brake hose bolts and pivot caliper up out of the way.



- 3. Remove the pad shim, pad retainers and pads.
- 4. Using a vernier caliper, measure the thickness of each brake pad lining.


Brake Pad Thickness: CARB.

Standard: 9.0 mm (0.34 in)

Service Limit: 3.0 mm (0.12 in)

PGM-FI


Standard: 11.5 mm (0.45 in) Service Limit: 1.6 mm (0.06 in)




NOTE: Measurement does not include pad backing thickness.

5. If lining thickness is less than service limit, replace both pads as a set.

NOTE: Engagement of the brake may require a greater pedal stroke immediately after the brake pads have been replaced as a set. Several applications of the brake pedal will restore the normal pedal stroke.



- 6. Clean the caliper thoroughly; remove any rust, and check for grooves or cracks.
- 7. Install the pad retainers.




Brake Pad

Inspection/Replacement (cont'd) -


- Apply MOLYKOTE M77 or equivalent to both surfaces of the shim and back of the pads.
- 9. Install the brake pads.

NOTE: Apply MOLYKOTE M77 or equivalent between the shims and pads.

10. Install the brake pad shims correctly.



- 11. Push in the piston so that the caliper will fit over the pads.
- 12. Pivot the caliper down into position, then install the caliper bolt and tighten it.




- 13. Connect the brake hose to the knuckle.
- 14. Depress the brake pedal several times to make sure the brakes work, then road-test.

Brake Caliper

Disassembly -

CAUTION:

- Before reassembling, check that all parts are free of dust and other foreign particles.
- Replace parts with new ones whenever specified to do so.
- Use only clean brake fluid.
- Make sure no dirt or other foreign matter is allowed to contaminate the brake fluid.
- Do not mix different brands of brake fluid as they may not be compatible.
- Do not spill brake fluid on the car, it may damage the paint; if brake fluid does contact the paint, wash it off immediately with water.
- Remove the banjo bolt and disconnect the brake hose from the caliper.
- 2. Remove the caliper bolts, then remove the caliper.



33 N·m (3.3 kg-m, 24 lb-ft)
3. Remove the pad spring from the caliper body.

